

UniTerm® Payment Interface Application

UniTerm Integration and Deployment Guide

Revision: 8.3.0

Publication date March 06, 2017

UniTerm Integration and Deployment Guide

Main Street Softworks, Inc.

Revision: 8.3.0

Publication date March 06, 2017

Copyright © 2017 Main Street Softworks, Inc.

Legal Notice

The information contained herein is provided *As Is* without warranty of any kind, express or implied, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. There is no warranty that the information or the use thereof does not infringe a patent, trademark, copyright, or trade secret.

Main Street Softworks, Inc. shall not be liable for any direct, special, incidental, or consequential damages resulting from the use of any information contained herein, whether resulting from breach of contract, breach of warranty, negligence, or otherwise, even if Main Street has been advised of the possibility of such damages. Main Street reserves the right to make changes to the information contained herein at anytime without notice. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Main Street Softworks, Inc.

Table of Contents

1. Revision History	1
2. UniTerm System	5
2.1. Overview	5
2.2. UniTerm Architecture	5
2.3. Design Decisions	6
3. UniTerm Integration and Deployment Overview	7
3.1. Deployment	7
3.2. Versioning	8
3.2.1. Version Scheme	8
3.2.2. Wildcard Versioning	8
3.3. Licensing	9
3.3.1. Registration	9
3.3.2. Device Definition	9
3.3.3. Management	9
3.4. Starting UniTerm	10
3.4.1. Command Line Options	10
3.5. Multiple Instances	10
3.6. Swapping Devices	10
3.7. Configuration Files	11
3.7.1. Location	11
3.7.2. Parameters	12
3.8. Communication	15
3.8.1. Network Communication	15
3.8.2. Android Service Communication	15
3.8.3. Apple iOS	16
3.9. Shutting Down UniTerm	19
3.10. User Setup Permissions and Requirements	19
3.11. Linux OS device access permissions	20
3.11.1. HID devices	20
3.11.2. Serial devices	21
4. UniTerm Protocol	22
4.1. Overview	22
4.2. UniTerm Request Parameters	22
4.2.1. UniTerm Actions (u_action)	26
4.2.2. Interchange/Rate Qualification Requirements	31
4.3. UniTerm Response Parameters	32
4.4. UniTerm Error Codes	34
4.5. UniTerm Status Codes	35
4.6. Tip Prompting	35
4.7. Cash Back Prompting	36
4.8. EBT Processing	36
4.9. QuickChip	37
4.10. Pay at the Table	37
4.11. Signature Capture	38
5. EMV transactions with UniTerm	40
5.1. Transaction Flow and Prompting	40

UniTerm Integration
and Deployment Guide

5.1.1. Swipe prompts to insert	40
5.1.2. Tap prompts to insert	40
5.1.3. Insert prompts to swipe	40
5.1.4. PIN required on Credit Cards	41
5.1.5. Signature not requested	41
5.1.6. Tap transaction run as MSR on chip card, no insert requested	41
5.1.7. Immediate decline without contacting the processor	41
5.2. Common questions	41
5.2.1. How do I add a gratuity/tip to a transaction?	41
5.2.2. What industries are certified for EMV?	42
6. UniTerm Protocol Examples	43
6.1. EMV Transaction [device load]	43
6.1.1. UniTerm Request Data	43
6.1.2. UniTerm Response Data	43
6.2. EMV Transaction [Interac]	44
6.2.1. UniTerm Request Data	44
6.2.2. UniTerm Response Data	44
6.3. Pin Debit (forced) Transaction Request	45
6.3.1. UniTerm Request Data	45
6.3.2. GUI output	46
6.3.3. UniTerm Response Data	46
7. UniTerm Test Application	47
8. UniTerm Code Examples	48
9. UniTerm Hardware Devices (Point of Interaction Devices)	49
9.1. Supported POI Devices	49
9.1.1. Ingenico RBA information	50
9.1.2. Verifone VX XPI information	54
9.1.3. Ingenico CPX/uCPX information	55
9.2. Obtaining Devices	56
9.2.1. Where to source devices with appropriate loads and keys	56
10. Certifications and Device Configurations	58
10.1. Certification List	58
10.2. Configuration Definitions	60
A. UniTerm Device Loading	61
B. EMV Receipt Requirements	63
B.1. Receipt content	63
B.1.1. Base receipt content	63
B.2. Receipt Data Returned by UniTerm	64
B.3. Receipt Data NOT Returned by UniTerm	68
B.4. Signature Line Requirements	68
B.5. Merchant vs Customer Copy	69
B.6. Moneris Requirements	69
B.7. Receipt Examples	69
B.7.1. EMV Insert, Signature Required	69
B.7.2. EMV Insert, PIN Verified	73
B.7.3. EMV Insert, No CVM	76
B.7.4. EMV Insert, Card Decline	79
B.7.5. EMV Insert, Card Removed (Decline)	81
B.7.6. EMV Insert, Interac	83

UniTerm Integration
and Deployment Guide

B.7.7. EMV Contactless, Interac Flash Decline	86
B.7.8. EMV Contactless, Decline	88
C. UniTerm Code Examples	90
C.1. Microsoft C# using libmonetra	90
C.2. Microsoft C# using XML and HttpWebRequest	94
C.3. Java using libmonetra	99
C.4. PHP using libmonetra	103
C.5. Microsoft VB.Net using libmonetra	108
C.6. Microsoft vBScript using XML and MSXML2	112
C.7. Microsoft Visual Basic 6 using libmonetra	116
D. PCI Security and Implementation	121

1 Revision History

Version	Date	Changes
v8.3.0	2017-03-06	<ul style="list-style-type: none"> • New First Data certification for EMV Debit and EMV Contactless • Update recommended RBA versions. • Add new <code>cdcv</code> card holder verification method response.
v8.2.5	2017-01-19	<ul style="list-style-type: none"> • Additional clarifications for use of the iOS framework. • Add <code>DELAYRESPONSE</code> <code>u_flags</code>. • Add <code>fullscreen</code> modifier to <code>guimode</code> configuration.
v8.2.4	2016-12-21	<ul style="list-style-type: none"> • Clarifications for use of the iOS framework. • Various other clarifications and fixes for typos. • Addition of <code>u_flowflags</code> response parameter.
v8.2.3	2016-12-01	<ul style="list-style-type: none"> • Add <code>serialquirks</code> flags for <code>uniterm.ini</code>
v8.2.2	2016-11-15	<ul style="list-style-type: none"> • Add <code>u_foodamount</code> value of <code>maybe</code> for <code>txnstart</code>. • <code>u_cardclass=EBT</code> has been split into <code>EBTFS</code> and <code>EBTCB</code> for clarity. • Add <code>[uniterm]</code> configuration parameter <code>returnbin</code> to return the first 6 digits (in addition to the last 4 digits) of a card number in the <code>txnstart</code> response message so transaction decisions can be made (e.g. health benefits qualification).
v8.2.0	2016-10-17	<ul style="list-style-type: none"> • All references to <code>monetra_uniterm</code> have been changed to just <code>uniterm</code>, including executable names and paths. • Added EMV industry question • Split out <code>u_action</code> values and descriptions into their own section for clarity. • GUI can now use Device Licensing when passing a <code>u_flags</code> or <code>GUIONLY</code> while also passing valid values for <code>device</code> and <code>devicetype</code>. This prevents requiring duplicate licensing for workstations with physical devices that sometimes perform gui card entry. • Ingenico RBA recommended version is now 18.04 • Linux HID device permission section has been added • Asynchronous processing (multiplexing/interleaving transactions on a single connection) is now supported. • QuickChip overview. • USB is now known as HID, all <code>usb</code> references changed, <code>hidlist</code> report parameters and <code>u_device</code> format have also changed • New commands (<code>u_action</code> values): <ul style="list-style-type: none"> • <code>txnstart</code> • <code>txnfinish</code> • <code>deviceupload</code> • <code>deviceprint</code> • <code>devicereboot</code>

Revision History

Version	Date	Changes
		<ul style="list-style-type: none"> • reqsignature • reqconfirm • reqinput <p>Associated request parameters for these new commands:</p> <ul style="list-style-type: none"> • u_b64data • u_filename • u_text • u_message • u_inputtype <p>Associated response parameters for these new commands:</p> <ul style="list-style-type: none"> • u_needreboot • u_confirmed • u_input • u_signature <ul style="list-style-type: none"> • Interchange requirement information. • New/Changed configuration parameters: <ul style="list-style-type: none"> • [monetra] persist_conn - Default changed to "no" • [uniterm] tippercent • [uniterm] cashbackamount • [uniterm] cashbackmax • Note that uniterm.ini isn't actually distributed anymore, instead a template of uniterm_example.ini is provided. • New u_flags: <ul style="list-style-type: none"> • NOTIP • NOCASHBACK • NOCONFIRM • NOSIGNATURE • Section added on Tip processing, including the addition of the u_tip response parameter. • Section added on Cash Back processing, including the addition of the u_cashback response parameter. • Section added on EBT processing, including the addition of the u_foodamount request parameter and u_wasfood response parameter. • The OS-provided SSL/TLS root trust list is now automatically loaded and there is no longer an included caroots directory. • In Deployment, discuss the new standalone installers provided. • Update devicetypes functionality values. • Update Apple iOS integration information for the framework variant. • New Ingenico RBA form of UTASEL.K3Z used. • Add guidance for Pay at the Table. • Add information about automatic signature capture. • Note that CPX/uCPX is limited to UniTerm v8.0, and not supported on v8.2

Revision History

Version	Date	Changes
		<ul style="list-style-type: none"> • Configuration parameter <code>nosigfloor</code> has been changed to <code>nocvmfloor</code> • <code>modifyconfig</code> parameters now use "." as a delimiter instead of "/" • <code>u_action=status</code> request now returns a <code>u_status</code> machine-readable status code • Add section on updating RBA firmware. • Add <code>skipped rcpt_emv_cvm</code> return value
v8.0.3	2016-03-02	<ul style="list-style-type: none"> • Note limitation for asynchronous processing (or lack thereof) • Update status of various certifications • Add sections relating to iOS support • Updated device application version support
v8.0.2	2015-11-16	<ul style="list-style-type: none"> • Update status of various certifications • Add section on obtaining devices. • <code>UID_NOT_FOUND</code> error code addition, and clarify possible <code>u_errorcode</code> values for status requests. • Missing required permission of <code>CARDTYPE</code> added. • Added <code>persist_conn</code> configuration parameter for the <code>[monetra]</code> section. • Added <code>deviceinfo</code> transaction type to request information about the connected device. • Added <code>GIFTPIN u_flags</code> to prompt for PIN entry if a gift card is used.
v8.0.1	2015-09-28	<ul style="list-style-type: none"> • Re-word and clarify configuration information for Ingenico RBA • Clarify fields can be sent in to pre-populate key entry fields in GUI mode. • Receipt should show "CALL ISSUER" for a response code of "CALL". • Cardholder Name on receipts can be printed under the signature line. • Document how to configure an RBA device for contactless. • Remove unused <code>monetra_host</code> and <code>monetra_port</code> variables in example code. • Add touchscreen mode support via <code>[uniterm]</code> config option of <code>guimode=touchscreen</code>. • SSL is no longer a valid communication option for Android. Only Service communication is allowed. • Add <code>ssl_auth_key</code> and <code>ssl_auth_cert</code> configuration parameters for the <code>[monetra]</code> section. • Add <code>ssl_cert_validate</code> configuration parameter for the <code>[monetra]</code> section. • Add <code>ssl_cadir</code> configuration parameter for the <code>[monetra]</code> section. • Verifone recommended XPI version updated to 8.24D. • Ingenico recommended RBA version updated to 15.06.

Revision History

Version	Date	Changes
		<ul style="list-style-type: none">• Ingenico RBA added support for USB-HID.• Update receipt examples to the latest generated by UniTerm Tester.
v8.0.0	2015-08-17	<ul style="list-style-type: none">• Initial revision

2 UniTerm System


2.1. Overview	5
2.2. UniTerm Architecture	5
2.3. Design Decisions	6

2.1 Overview

UniTerm securely handles sensitive cardholder data independent of the merchants application software. In addition, UniTerm provides a simple consistent interface to multiple payment acceptance devices such as card readers, pinpads and terminals.

2.2 UniTerm Architecture

The UniTerm module is accessed via its 'Transaction Request' mode, as described below:



A	Point of sale application calls UniTerm for <code>txnrequest</code> (such as a sale transaction request) and includes basic information such as the amount of the sale and an order-number.
B	UniTerm communicates with devices (such as pinpads and card readers) to retrieve sensitive data, depending on request type (step A).

C	UniTerm sends the full transaction data-set to the Monetra server for further processing.
D	The Monetra server processes the transaction request (such as a sale) against the appropriate end point (for example TSYS) and then sends back the response it receives to the UniTerm module.
E	The UniTerm module then returns the transaction response back to the calling application.

2.3 Design Decisions

UniTerm is designed to run as an independent application running in a separate address space from any integrated applications. The design decisions behind this are due to the PCI PA-DSS and EMV certification requirements, where a clear line can be drawn between the certified application (UniTerm) and the POS without any ambiguity as to if the POS would fall into scope. If this clear line was not drawn, the POS may be required to undergo the extremely intensive and costly EMV Brand Certifications, not to mention fall into scope for PCI PA-DSS.



Note: Due to the nature of iOS, UniTerm is also available as a library under special exception from Visa, which has stated they will not require the POS vendor on iOS to undergo EMV Brand or PCI PA-DSS validations when using UniTerm.

3 UniTerm Integration and Deployment Overview

3.1. Deployment	7
3.2. Versioning	8
3.2.1. Version Scheme	8
3.2.2. Wildcard Versioning	8
3.3. Licensing	9
3.3.1. Registration	9
3.3.2. Device Definition	9
3.3.3. Management	9
3.4. Starting UniTerm	10
3.4.1. Command Line Options	10
3.5. Multiple Instances	10
3.6. Swapping Devices	10
3.7. Configuration Files	11
3.7.1. Location	11
3.7.2. Parameters	12
3.8. Communication	15
3.8.1. Network Communication	15
3.8.2. Android Service Communication	15
3.8.3. Apple iOS	16
3.9. Shutting Down UniTerm	19
3.10. User Setup Permissions and Requirements	19
3.11. Linux OS device access permissions	20
3.11.1. HID devices	20
3.11.2. Serial devices	21

3.1 Deployment

UniTerm is provided to developers during the integration process as either an OS-specific standalone installer, or as an installable license delivered via the Monetra Installer.

For production deployments on platforms other than Android and iOS, UniTerm should be bundled and distributed with the POS system under a distribution license from Main Street Softworks, Inc. Integrators should package the UniTerm directory that is created after UniTerm installation, and distribute that directory packaged together with their own components (e.g. POS application software). The UniTerm directory is self-contained and can be relocated to any path the integrator sees fit, without any additional system dependencies as long as the paths for any sub-directories included with the UniTerm installation (if applicable) are kept in the same relative paths in relation to the UniTerm executable.

It is also acceptable to redistribute the standalone installation package, however, the Monetra Installer method should never be used for production deployments.

For Android deployments, the UniTerm app is available via the Google Play Store, and it may be installed from there without a distribution license. Alternatively, by obtaining a distribution license, the UniTerm software can be provided as a standalone APK package for Android

ARM devices running v4.1.2 or later, or it can be bundled with the application software as a Service component.

For Apple iOS deployments, there are two distribution methods. The first is a framework that can be embedded into an application. Note that for iOS apps using this framework to be accepted into the App Store, Apple as well as the device manufacturers must provide approval for each type of BlueTooth device that will be used with the application. The second distribution method involves installation of the UniTerm application from the iOS App Store and using URL schemes for Inter-Process communication. The UniTerm App has not yet been approved by Apple due to Apple's requirements for each application to have a complete UI meant to be used outside of any features such as URL Schemes, the application is expected to be complete in Q1 2017, however a beta version can be provided upon request. Those interested in the framework for iOS should contact their sales representative.

Please contact sales@monetra.com for guidance on distribution licensing and bundling.

3.2 Versioning

3.2.1 Version Scheme

The versioning scheme employed by UniTerm is formatted as $x.y.z$, where each x , y , and z components are numeric-only version indicators separated by a period. Each numeric component may be from one to three digits in length. All software distribution updates will result in at least one of the components being updated.

The x component of the version indicates the product major version number. The major version component only changes when there are significant feature changes, or the changes impact any part of a security standard, such as PCI PA-DSS.

The y component of the version indicates a product minor version change. The minor version will change when there are minor feature enhancements that do not impact the part of any security standard such as PCI PA-DSS.

The z component of the version indicates a bug-fix release. Bug-fix releases do not change the overall feature-set or functionality of UniTerm, but may include security related fixes such as updates to 3rd party libraries (e.g. cryptographic libraries) distributed with UniTerm.

3.2.2 Wildcard Versioning

PCI PA-DSS requires a specific wildcard versioning definition which corresponds to the release which is being validated for compliance. With this release of UniTerm, the official wildcard versioning is $8.y.z$. The major (x) version number component is fixed at 8, which as per the versioning definition states there will be no major feature changes or changes which impact the PCI PA-DSS standard (e.g. all changes that do not affect the major version number are classified as "no impact" changes). The minor (y) and bug-fix (z) wildcard components comply with the descriptions in the previous section.

Any future change which results in a change to the major version number will have a corresponding PCI PA-DSS validation.

3.3 Licensing

All UniTerm licensing is managed at the server level by the Monetra system with which UniTerm is connected. Since licensing is administered at the server level, there is nothing unique that needs to be deployed with UniTerm on the client side (such as a license or certificate file).

3.3.1 Registration

UniTerm generates unique ids for each connected device in order to send to Monetra to track the number of UniTerm licenses in use.

When UniTerm is started, during the first transaction and every 24hrs thereafter, the unique device ID will be automatically registered with Monetra. If this device is already associated with a UniTerm license, the license meta-data will be updated. If the device is not currently associated with a UniTerm license, Monetra will register this unique device id if a UniTerm license slot is available, otherwise Monetra will reject the registration request and UniTerm will cancel the transaction.

3.3.2 Device Definition

A device is either a physical Point of Interaction device, or a Graphical User Interface of the computer in which UniTerm is running.

Each physical device will consume a UniTerm license, the license is tied to the device serial number. Since the license is tied to the device, the physical device may be transferred to different POS stations without consuming additional licensing.

The use of the GUI mode in UniTerm, whether used with keyboard emulation card readers, for acceptance of manually keyed card entry, will also consume a UniTerm license. This license will be generated based on the unique machine ID or the MAC address of the first NIC. However if a physical customer-facing card entry device is also present, passing the device and devicetype parameters along with a `u_flags` of `GUIONLY` will use the device's licensing rather than registering the workstation itself, thus saving on duplicate licensing for workstations that use both a physical device and GUI modes of operation.



Note: If a physical device is being used and GUI mode is also used, if care is not taken, this will consume 2 UniTerm licenses, one for the physical device and one for the GUI mode of operation. Please see the `u_flags` of `GUIONLY`.

3.3.3 Management

Since UniTerm licensing is managed at the Monetra server, all license administration (view licenses, delete licenses, etc) can be performed using either the Monetra Administrator GUI or via the Monetra API. To more easily help identify and manage licenses, additional data is available in the license list such as: initial creation timestamp, last used timestamp, last used username, device type, and device serial number.



Note: If a UniTerm license (device or GUI) is removed (de-registered) from Monetra, then the license slot is not eligible to be re-used for 7 days. However, if the same [deleted] device is re-presented, it can immediately re-consume the license slot.

3.4 Starting UniTerm

For Desktop based deployments, the UniTerm module must be launched by the POS application software and should not be started at startup. If the POS system does not start UniTerm, then it is possible UniTerm will not be able to obtain screen focus for on-screen prompts.

For Android deployments, UniTerm should be automatically started at Boot, and simply Binding to the already-running service is sufficient.

For iOS deployments, the application is bound to a URL Scheme during installation and will automatically load when the URL Scheme is called.

3.4.1 Command Line Options

When starting UniTerm for Desktop based deployments, there are a few command line options supported that control the behavior.

- `-c` - Full path to the `ini` file to read. If not specified, it searches for the `uniterm.ini` in the paths documented in Section 3.7.
- `-p` - Port for UniTerm to listen on for incoming connections. If not specified, the value in the `ini` file is used. The purpose of this configuration value is to aid in the ability to start multiple UniTerm instances on the same machine with the intention of using GUI mode for multiple user logins (e.g. Terminal Services).
- `-h` - Help options are displayed.

3.5 Multiple Instances

When running UniTerm in conjunction with Citrix or Terminal Services, with the intention of using GUI mode, it is necessary to start multiple instances of UniTerm on the same machine. This can be accomplished by using a different port for each UniTerm instance. The port can either be configured via the command line options or by specifying a different UniTerm `ini` file. The integrated application would then communicate with UniTerm on its own dedicated port to prevent interference with any other UniTerm instances. The dedicated UniTerm instance must still be started by the POS application in that user instance otherwise UniTerm will be unable to display information or prompts.

If using UniTerm in device-only mode, it is recommended to use only a single instance of UniTerm and not start multiple instances. UniTerm is designed to be able to handle multiple transactions across multiple devices without the need for additional instances.

3.6 Swapping Devices

From time to time it may be necessary to swap out devices, whether the device is malfunctioning, being updated to a new firmware load, or simply being relocated. When

a device is swapped, UniTerm needs to be made aware of this, otherwise there could be unexpected behavior. In order to reduce transaction latency as much as possible, the first time a device is used after a fresh UniTerm start, UniTerm performs many queries against the device which may take many seconds to complete. These queries gather device information such as its type and capabilities and ensure the proper configuration parameters are loaded. In extreme cases this first transaction may detect a full device load is necessary which could extend this time to many minutes and result in a device reboot. On all subsequent transactions, these initial steps are stored in an in-memory cache and will not be repeated unless UniTerm is explicitly told to do so. When a device is swapped out, UniTerm may have no way to know this has occurred since it is operating on this cached data.

In order to tell UniTerm that a device has been swapped out, simply send a `u_action=deviceLoad` request or restart UniTerm. Either of these actions will force UniTerm to clear its in-memory cache and connect to the device as if it was the first transaction.

In some cases if the device itself isn't swapped (so the serial number has not changed), but instead the device has been manually cleared, such as when performing a firmware update, additional steps may need to be taken to ensure EMV parameters are loaded. There may be no way for UniTerm to determine if the device has the latest EMV parameters so UniTerm caches the `loadid` associated with the device serial number in the `uniterm.ini`. If this on-disk cache is incorrect because the device was manipulated outside of UniTerm, UniTerm must be informed of this by passing `u_forceload=yes` with the `u_action=deviceLoad` request. The `u_forceload` will tell UniTerm to ignore the `loadid` cache forcibly loading the EMV parameters into the device. In fact, it may be prudent to explicitly use `u_forceload` any time a device is swapped to ensure all data is loaded into the device.

3.7 Configuration Files

There is a single configuration file named `uniterm.ini` that must be configured before UniTerm can be used. Included with UniTerm is a file named `uniterm_example.ini` that can be used as a template.

The `uniterm.ini` file **MUST** be readable and writable by the UniTerm process.

3.7.1 Location

The location of the `uniterm.ini` file may vary from system to system, and the default search paths, listed in priority order, are:

- Windows:
 - `%APPDATA%/UniTerm/uniterm.ini`
 - same path as the `uniterm.exe` executable
- Mac OS X:
 - `~/Library/Application Support/UniTerm/uniterm.ini`
- Linux/Unix:
 - `~/uniterm/uniterm.ini`

- same path as the `uniterm` executable
- iOS/Android: N/A - embedded into the application bundle, meant to be modified via GUI or `u_action=modifyconfig`



Note: If the `uniterm.ini` file cannot be located, or does not have proper read and write access, UniTerm will still start listening on the default port 8123 and return an `INI` related `u_errorcode` on all requests with a description of the issue. It should be noted that once the error has been corrected, UniTerm must be restarted to clear the error condition to force UniTerm to re-read its `INI` file.

3.7.2 Parameters

The parameters in this section are in standard `ini` format grouped by sections. Sections are in the format of "[`section`]". The settings for each section are in key/value pair format of "`key=value`". Each setting and section are delimited from each other using a new line, either Unix `LF` or Windows-style `CRLF` are acceptable.



Note: If editing the example `ini` file on Windows, using `Notepad.exe` is not advised. The example file uses Unix-style line endings that `Notepad.exe` cannot understand so it will make the entire file appear as a single line or otherwise not formatted correctly. It is known that `Wordpad.exe` does in fact understand Unix line endings and can be used successfully.

3.7.2.1 Section: [`monetra`]

- `host`: Required. Hostname/address where Monetra resides
- `port`: Required. Port to connect to Monetra on
- `ssl_cert_validate`: Optional. Controls validation of the Monetra SSL server certificate. Possible Values are:
 - `full` - validate server certificate signature and require the full domain matches the certificate
 - `fuzzy` - validate server certificate signature and only the base domain matches the certificate
 - `validate` - validate only the server certificate signature, do not validate the domain name in the certificate
 - `none` - perform no server certificate validation

If no value is specified, defaults to `none`. Monetra, by default, deploys a self-signed SSL certificate. You must either explicitly deploy a signed certificate (signed by a trusted CA) with Monetra to be able to turn on certificate validation, or add Monetra's self-signed SSL certificate to the trust list (see `ssl_cadir`).

- `ssl_cadir`: Optional. Path to a directory containing a list of the PEM-encoded trusted SSL Certificate Authority roots or individual server certificates to be added to the trust list. If available, the OS-provided trust list will be loaded first and any certificates in the provided directory will be appended. Only used when `ssl_cert_validate` is set to a value other than `none`.

- `ssl_auth_key`: Optional. Path to the SSL client certificate key used for two factor authentication. If not specified, the server will not be able to validate the authenticity of the client, however most deployments will not utilize this level of verification. Must be specified if `ssl_auth_cert` is specified.
- `ssl_auth_cert`: Optional. Path to the SSL client certificate used for two factor authentication. If not specified, the server will not be able to validate the authenticity of the client, however most deployments will not utilize this level of verification. Must be specified if `ssl_auth_key` is specified.
- `persist_conn`: Optional. Whether or not UniTerm should maintain persistent connections to Monetra, or if it should disconnect when there are no active transactions. If not specified, defaults to no.

3.7.2.2 Section: [uniterm]

3.7.2.2.1 Operating Parameters

- `port`: Required on all except Android. Port to listen on for incoming connections.
- `sharedsecret`: Optional. The value specified is the shared secret to use for the communication protocol. A value must be set if one wishes to allow remote connections (along with `localonly=no`), or to enable the `MODIFYCONFIG` command. When this configuration parameter is set, all requests to UniTerm must include the `u_sharedsecret` protocol-level key/value pair set to the same value.
- `localonly`: Optional. If not specified, defaults to yes. If set to no, a `sharedsecret` must also be set and remote connections will be allowed.
- `ssl_cert`: Optional. If not specified attempts to locate `ssl.crt` in the same path as `uniterm.ini`
- `ssl_key`: Optional. If not specified attempts to locate `ssl.key` in the same path as `uniterm.ini`
- `serialquirks`: Optional. Controls how serial connections are handled, some platforms may need special settings to operate reliably, but most systems should not configure these flags. This setting is controlled by a set of pipe (|) delimited flags as listed below:
 - `ignore_termios_failure` - Ignore errors while setting communications settings. This may be necessary on certain types of serial port emulators that do not allow this.
 - `no_flush_on_close` - Do not flush the serial port buffers on close.
 - `no_restore_on_close` - Do not restore the original configuration for the serial port on close.
 - `async_timeout` - When using asynchronous reads, allow the read operation to timeout rather than continue indefinitely, some serial port emulators may lock up without this flag. This flag is ignored when used with `busy_polling`. Windows Only.
 - `busy_polling` - Perform busy polling in a separate thread, rather than using asynchronous reads. This may be necessary for some serial port emulators that do not properly support Overlapped operations. Windows Only.

3.7.2.2.2 Feature Parameters

- `idle_message`: Optional. Set the default idle message displayed on any device when not processing a transaction. This can be overwritten on a per-device level using the `u_deviceidlemessage` parameter in the protocol. This is not supported on all devices.
- `unsupportedcard`: Optional. If not specified, defaults to no. If set to yes, this allows `trackdata` to be returned to the caller for `txnrequest` and `cardrequest` only when the card type is confirmed to be non-financial. This is to allow in-store private-label gift (on `txnrequest`) as well as manager cards. The card must be returned unencrypted from the reader to be supported.
- `nocvmfloor`: Optional. If not specified, defaults to disabled, should be specified as a dollar amount. This configuration value will disable cardholder verification (e.g. PIN or Signature) when the transaction amount is less than this limit. For instance if the value is set to 50.00, and a 40.00 authorization is attempted as a swipe transaction, they will NOT be prompted to sign, however a 60.00 authorization would be prompted to sign. This feature works with EMV contact as well, however EMV Contactless has its own set of limits advertised by Monetra that UniTerm will honor. Applies only to Credit Card purchases.
- `guimode`: Valid options are `normal` and `touchscreen`. A modifier value of `fullscreen` can also be added to force the GUI to be rendered full screen rather than in a window, the modifier will be separated from the mode by a pipe (`|`), for example `touchscreen|fullscreen`. If no `guimode` is specified, it defaults to `normal`. TouchScreen mode enlarges all text in dialogs and provides an on-screen keypad to be used for manual card entry. Only numeric input is allowed in `touchscreen` mode, if an alpha-numeric Postal code needs to be entered (such as for Canada), a keyboard must be used. Normal mode is designed for use at a workstation with a keyboard and mouse.
- `tippercent`: Pipe-delimited (`|`) field containing whole percentage options for choices to be presented to the cardholder, or the keyword "Other" to allow a cardholder to enter a custom amount.

If this setting is configured, it will enable tip prompting unless the `NOTIP u_flags` parameter is passed with the transaction.

Though there is no limit to the number of values that may be requested, the options on the Right will be truncated (except for the `Other` option) if the device is not capable of presenting the number requested. It is therefore recommended that the lowest common denominator of 3 values be presented.

Example: `tippercent=18|20|Other`

- `cashbackamount`: Pipe-delimited (`|`) field containing whole dollar amount options for choices to be presented to the cardholder, or the keyword "Other" to allow a cardholder to enter a custom amount. The maximum dollar amount allowed can be controlled by the `cashbackmax` configuration value.

If this setting is configured, it will enable cash back prompting on supported card types (Debit, EBT Cash Benefits) unless the `NOCASHBACK u_flags` parameter is passed with the transaction.

Though there is no limit to the number of values that may be requested, the options on the Right will be truncated (except for the `Other` option) if the device is not capable of presenting the number requested. It is therefore recommended that the lowest common denominator of 3 values be presented.

Example: `cashbackamount=25|50|Other`

- `cashbackmax`: Maximum cash back amount allowed to be requested. If not specified, defaults to 100.00.
- `returnbin`: Optional. Boolean, defaults to no. If set to yes, this allows UniTerm to return the first 6 digits of the card number as part of the response for `txnstart`. This data can then be used for BIN checking to determine additional card classification such as if it is a health benefits card or qualified Visa card for Debt Repayment.

3.8 Communication

The communication protocol for UniTerm is very similar to that of Monetra. At the heart of the protocol is a simple key/value pair message structure, very similar to the Monetra Client Interface Protocol Specification. In fact, some of these key/value pairs sent to UniTerm are simply passed-through to Monetra for processing.

When communicating with UniTerm, you use standard network communications in Desktop and Server environments (Windows, MacOSX, Linux). For Mobile applications, the communication method is specific to what the OS allows for Inter-Process communication.

3.8.1 Network Communication

UniTerm supports both raw SSL communication with key/value pair transport, or XML over HTTPS. The protocol being used is autodetected by UniTerm on the first message sent by the POS. The standard APIs used with Monetra are also able to be used with UniTerm as they simply facilitate the same key/value pair transport mechanisms as the raw protocols. For more information on the underlying communications protocols or APIs, please reference the communications documentation and API documentation for Monetra.

Normally, UniTerm listens on localhost on port 8123, and as of UniTerm v8.2, listens on both IPv4 and IPv6 if available. It is possible to make UniTerm accept connections from remote machines by configuring a `'sharedsecret='` set to a desired value as well as `'localonly=no'` in the `uniterm.ini`. When a shared secret is configured, all requests to UniTerm must include the `u_sharedsecret` parameter set to this secret value in order to prevent malicious requests.

3.8.2 Android Service Communication

The Android Service communication option utilizes AIDL in order to transmit the key/value pairs for each request to the UniTerm Service. Please see our Android SDK available at <https://www.monetra.com/developers> for an example of how to utilize this communication option.

3.8.3 Apple iOS

There are 2 methods of communication for Apple iOS. The first is an embedded framework with all included dependencies that is linked directly into the iOS application. The framework is available under special distribution license, please contact your sales representative for more information. The second method is an official Apple iOS App Store application that can be installed free and uses URL Schemes for Inter-Process communication, this application is expected to be accepted in Q1 2017, beta versions can be made available upon request.

3.8.3.1 Framework

UniTerm on iOS can be provided bundled as a framework which allows private access to UniTerm's functionality. When building an application, the UniTerm framework itself along with the distributed dependencies (`libmonetra`, `openssl`, `zlib`), as well as the system-provided `ExternalAccessory` Framework and `libresolv.tbd` library must be added to the "Linked Frameworks and Libraries" for your project (In XCode under `Project->General`). The relevant frameworks and dependencies and a complete and working integration example will be provided with the UniTerm iOS Framework distribution.



Note: Both iOS device and simulator builds are provided for integrators. It should be noted, however, that simulator builds do not support External Accessories, so can only be used against IP/Ethernet-enabled devices. It is therefore recommended that developers have both Bluetooth and IP/Ethernet enabled devices for the various phases of development available.

A bundle with auxiliary files that will be installed is also provided. This bundle, called `uniterm.bundle`, must be added to your project in XCode under `Project -> Build Phases -> Copy Bundle Resources`. Within the bundle is a default `uniterm.ini`; this should be edited to reflect the Monetra location that should be used by the app. The `ssl_cadir` parameter should NOT be modified. The `port` parameter in the Uniterm section can be ignored or removed. When used as part of an iOS app connecting to UniTerm using a network connection is not supported. When a new build of UniTerm is distributed with the app, if there are differences in the `uniterm.ini` the new `uniterm.ini` will be merged with the old one. This only applies to the build number of the UniTerm library and not the build number of the app itself.

The app itself must be configured with the "Wireless Accessory Configuration" capability. Also, the `Info.plist` must list all external accessories it will be used with, along with other MFi protocols the device(s) supported advertise to prevent the user from being prompted to search the app store with a list of other applications that support this device. The current list of protocols is configured via Add "Supported external accessory protocols" with the below protocols (`UISupportedExternalAccessoryProtocols`):

- `com.ingenico.easypayemv.spm-transaction` - Actual used protocol
- `com.ingenico.easypayemv.spm-networkaccess`
- `com.ingenico.easypayemv.spm-pppchannel`
- `com.ingenico.easypayemv.barcodereader`
- `com.ingenico.easypayemv.spm-configuration`
- `com.ingenico.easypayemv.spm-sppchannel`

UniTerm Integration and Deployment Overview

- `com.ingenico.easypayemv.printer`

The "Actual used protocol(s)" listed above will be part of the `u_device` in the key/value pairs sent to UniTerm (prefixed with `bt :` for bluetooth, which is used for MFi).



Note: For iOS apps using this framework to be accepted into the App Store, Apple as well as the device manufacturers must provide approval for each type of Bluetooth device that will be used with the application.

3.8.3.1.1 APIs

Function	Description
<code>BOOL uniterm_initialize(void);</code>	Initialize UniTerm. This must be called at app startup and before any other UniTerm functions are called. It is recommended to put it in the AppDelegate's <code>init</code> function.
<code>BOOL uniterm_modify_config(NSDictionary *req);</code>	Modify Configuration. The <code>uniterm.ini</code> file should not be edited directly by the app after initialization. Instead the <code>uniterm_modify_config</code> should be used. This ensures that any UniTerm cached network connections are properly updated. This function must be used because <code>uniterm_run_trans</code> is explicitly blocked from modifying the configuration. Direct modification of the <code>uniterm.ini</code> is possible before <code>uniterm_initialize</code> is called. Both <code>uniterm.ini</code> and <code>uniterm-orig.ini</code> need to be changed. Specifically <code>uniterm-orig.ini</code> should be a copy of the <code>uniterm.ini</code> .
<code>NSDictionary *uniterm_run_trans(NSDictionary *req);</code>	Main interface for running transactions with UniTerm. It accepts UniTerm key value pairs and runs the request. It returns a dictionary of the key value pair responses. This is a blocking function and should be used with <code>dispatch_async</code> . When the call completes it should notify the app that it is finished so the app can take appropriate action with the response.

3.8.3.2 URL Schemes

Apple iOS communication relies on the use of URL Schemes for Inter-Process communication. Information on this communication method can be found at <https://developer.apple.com/library/ios/documentation/iPhone/Conceptual/iPhoneOSProgrammingGuide/Inter-AppCommunication/Inter-AppCommunication.html>.

When an application calls UniTerm's registered URL Scheme, the UniTerm application will present itself in the foreground and process the requested transaction(s). Data passed via the URL scheme is JSON-encoded, containing the key/value pairs that make up a transaction as per this documentation. Multiple requests may be passed in a single message. Part of the request message is a response URL scheme for delivery of the response to the integrated application.

Please see our iOS Demo source code available at <https://www.monetra.com/developers> for an example of how to utilize this communication option.

Please note that Apple does not support the concept of a background service or true inter-process communication in the same way as Android supports, therefore UniTerm must run in the foreground while processing transactions. If this is not acceptable, then please contact us about the Framework version of UniTerm for iOS.

3.8.3.2.1 URL Scheme messaging format

The JSON format is an object with strings for the keys and values. If multiple requests are to be sent at once, each request object may be encapsulated in an array, with each member in the array being a single request. When using request stacking, it is required that a unique `u_id` be passed with each request, which will be returned in the response and must be used for matching, never rely on the response array being in the same order as the request. If not using request stacking, `u_id` is not a required parameter.

Example JSON data:

```
[
  {
    "u_action": "devicetypes",
    "u_id": "1"
  },
  {
    "u_action": "bluetoothlist",
    "u_id": "2"
  },
  {
    "u_action": "version",
    "u_id": "3"
  }
]
```

For URL Schemes, UniTerm uses the `x-callback-url` (<http://x-callback-url.com/>) specification. All requests should be sent to `uniterm://x-callback-url/transaction` and must specify the following parameters:

- `x-source`: Textual name of the calling app.
- `x-success`: Return URL for successful requests. Will be used when UniTerm was able to process a request. This will be returned even when there was an error with the transaction itself such as a decline.
- `x-error`: Return URL on critical errors (such as parse failures). Will be used when there is an error in parsing the request. Such as malformed JSON data.

UniTerm Integration and Deployment Overview

- request: The JSON request data, url-encoded.

Example Request:

```
uniterm://x-callback-url/transaction?
x-source=MyApp&
x-error=myapp://error&
x-success=myapp://result&
request=${URLENCODED-JSONDATA}
```

Example Critical Error:

```
myapp://error?
errorCode=${CODE}&
errorMessage=${MESSAGE}
```

Example Successful Response:

```
myapp://result?
response=${URLENCODED-JSONDATA}
```

3.9 Shutting Down UniTerm

UniTerm should only be shut down if it was started by the POS, and does not apply to Android systems. On Windows, a standard Window shutdown message may be sent, or on Unix a SIGTERM signal may be sent to the UniTerm process. Or universally UniTerm supports a shutdown message via its protocol.

3.10 User Setup Permissions and Requirements

UniTerm requires that sensitive data never be returned from Monetra in order to ensure that the integrated POS is removed from PCI PA-DSS scope. In order to ensure this, UniTerm only allows merchant sub-users to authenticate. Sub users are unique usernames that can be tied to a merchant user with their own individual password, but provided only a subset of the permissions allowed. These unique usernames, when passed to UniTerm, are prefixed with the username of the merchant user and delimited with a colon (:). (e.g. merchuser:subuser).

UniTerm requires the sub user have the `obscure sensitive information` flag set, or it will generate a failure.

UniTerm also requires these permissions to operate:

- CHKPWD
- CARDTYPE
- SALE
- VOID
- REVERSAL

- TERMLoad - Required if supporting EMV, Canadian Interac Debit, or TransArmor
- EMVCOMPLETE - Required only if supporting EMV
- INTERACMAC - Required only if supporting Canadian Interac Debit
- ADMIN:MERCHINFO - Used for populating receipt metadata and determining merchant card brands and capabilities in use
- ADMIN:GETPERMS - Used for verifying account setup.
- ADMIN:IMAGEADD - Only required if device support signature capture.

More permissions may be required based on the POS operations supported. Please consult with your integration and development team for the features used.



Note: Sub users may be created using the Monetra Client GUI after logging in, under Admin
-> SubUserManager

3.11 Linux OS device access permissions

3.11.1 HID devices

Most Linux distributions, by default, do not allow non-root users to access HID devices. Since it is not desirable to run a POS or UniTerm as root, some system changes are required to grant access to normal users. In general, the `udev` subsystem controls device enumeration, so some rules must be added to tell it what permissions to grant for enumerated HID devices.

Before a `udev` rule can be added, a system administrator must determine what group to grant privileges to HID devices. On RedHat based systems, the most suitable pre-existing group name is probably `input`. For Debian based systems, the most suitable pre-existing group name is probably `plugdev`. If no suitable groups are pre-existing, the system administrator should create one with an appropriate name.

Next a file named `/etc/udev/rules.d/99-hid.rules` should be created with contents similar to:

```
KERNEL=="hidraw*", SUBSYSTEM=="hidraw", MODE="0660", GROUP="$group"
```

Of course, replacing `$group` with the desired group name.

Finally, the system administrator should add the user that wishes to run UniTerm to the group, a command to do that might look like:

```
usermod -a -G $group $user
```

Of course, replacing `$group` and `$user` as appropriate. If already logged in as the user being modified, it is necessary to log out and back in for the group membership to be updated.

Once these steps are performed, UniTerm should now be able to run as a non-root user and access HID devices

3.11.2 Serial devices

If the user that runs UniTerm is unable to open a serial device, most likely it is simply a group permissions issue. Both RedHat based and Debian systems use the `dialout` group for serial port access. A system administrator might need to do further research in to what group may be used on their system.

In order to add your user to the appropriate group, a command to do that might look like:

```
usermod -a -G $group $user
```

Of course, replacing `$group` and `$user` as appropriate. If already logged in as the user being modified, it is necessary to log out and back in for the group membership to be updated.

If your distribution is not setting group membership on serial devices during enumeration, it may be necessary to add specific `udev` rules to allow this. Please see the previous section for an example.

4 UniTerm Protocol

4.1. Overview	22
4.2. UniTerm Request Parameters	22
4.2.1. UniTerm Actions (u_action)	26
4.2.2. Interchange/Rate Qualification Requirements	31
4.3. UniTerm Response Parameters	32
4.4. UniTerm Error Codes	34
4.5. UniTerm Status Codes	35
4.6. Tip Prompting	35
4.7. Cash Back Prompting	36
4.8. EBT Processing	36
4.9. QuickChip	37
4.10. Pay at the Table	37
4.11. Signature Capture	38

4.1 Overview

Application software communicates with UniTerm via the UniTerm protocol (which is intentionally similar to the Monetra Client Interface Protocol as they are meant to coexist). The protocol description documents only the key/value pairs that make up a transaction. These key/value pairs can then be transported using one of the supported communications protocols such as the standard Monetra SSL/TLS, possibly using one of our provided APIs to make communication easier, or XML over HTTPS. Usage of our Monetra SSL/TLS protocol is recommended as it allows asynchronous processing (multiple simultaneous, interleaved transactions) via a single connection (as of v8.2). Mobile devices may have their own specific method of transport.





Note: When processing transactions (such as `u_action=txnstart` or `u_action=txnrequest`), UniTerm simply augments the requests made with cardholder data captured either via a device or on-screen, and passes them on to Monetra. A majority of the parameters to be sent are simply pass-through to Monetra and not interpreted by UniTerm in any way; Therefore this guide must be used in conjunction with the Monetra Client Interface Protocol Specification to come up with a complete list of parameters necessary to complete transactions.

4.2 UniTerm Request Parameters

The table below describes the parameters used within the UniTerm protocol.

PARAMETER	VALUE
username	The Monetra username to authenticate as. For security reasons this should be a restricted subuser account.
password	The Monetra password associated with username.
u_action	See UniTerm Actions (u_action) for a complete description of each action.

	<ul style="list-style-type: none"> • deviceload • txnrequest • txnstart • txnfinish • cardrequest • passthrough • cancel • deviceupload • deviceprint • devicereboot • reqsignature • reqconfirm • reqinput • devicetypes • status • seriallist • bluetoothlist • hidlist • shutdown • modifyconfig • version • deviceinfo
<p>u_flags</p>	<p>Txnrequest, Txnstart, Txnfinish and Cardrequest only. Multiple flags may be sent per data ticket request. All flags are separated by a pipe () symbol.</p> <ul style="list-style-type: none"> • ENCRYPTEDONLY - Permit encrypted reader data only. Not valid on cardrequest • DEVICEONLY - Suppresses display of clerk facing prompting and feedback, also known as GUI mode. For instance, on a swipe request, no swipe dialog would be presented nor would the clerk be informed of the status for customer-facing device interaction. <div style="border: 1px solid #ccc; background-color: #f9f9f9; padding: 10px; margin: 10px 0;">  <p>Note: Setting this mode will prevent keyboard emulation readers from working, it will also prevent the ability for accepting clerk keyed input via a keyboard. On Android, iOS, and UniTerm launched in console mode, this flag is automatically implied as they do not support a GUI mode of operation.</p> </div> <ul style="list-style-type: none"> • GUIONLY - Suppresses use of a referenced physical device. This flag can be used to utilize the physical device's UniTerm license for a clerk-facing GUI request, without using the device itself for card input. Without this flag, the GUI would register an additional UniTerm license based on the machine's unique id.

	<ul style="list-style-type: none"> • KEY - Perform capture of manually keyed data. Not valid on <code>cardrequest</code>. If an <code>account</code> or <code>expdate</code> field is passed in on the request to UniTerm, the fields will be pre-populated in GUI mode. <div style="border: 1px solid gray; background-color: #f0f0f0; padding: 5px; margin: 10px 0;">  <p>Note: If a manually keyed EBT card is to be entered for a Food Stamp (SNAP) transaction, <code>u_cardclass</code> with a value of <code>EBTFS</code> must also be provided along with a qualified <code>u_foodamount</code> in order to go through the EBT flow and PIN prompting.</p> </div> <ul style="list-style-type: none"> • AVS - Request AVS data. Only allowed on keyed transactions. If a <code>street</code> or <code>zip</code> field is passed in on the request to UniTerm, the fields will be pre-populated in GUI mode. • CVV - Request for CVV data. Only allowed on keyed transactions. • GIFTPIN - Request a PIN for gift cards, when a gift card is presented. Does nothing if a different card type is presented. • NOTIP - Disable tip prompting if enabled via <code>[uniterm] tippercent</code> configuration. • NOCASHBACK - Disable cash back prompting if enabled via <code>[uniterm] cashbackamount</code> configuration. • NOCONFIRM - When performing a QuickChip finalization via <code>txnfinish</code> do NOT prompt the cardholder to confirm the amount prior to running the authorization. • NOSIGNATURE - If using a signature-capable device, but an integrator does not want to use the auto-signature-capture capabilities in the UniTerm flow, this flag will treat the device as if it is not capable of accepting a signature. The <code>u_need_signature</code> response flag will be set appropriately for the transaction requirements. • DELAYRESPONSE - This flag will cause UniTerm to send the transaction response back to the caller after the device has been closed. The device can be used immediately for a subsequent transaction with this flag, otherwise device closing will happen in the background which will hold a lock on the device for at least 100ms, or possibly longer.
<p><code>u_cardclass</code></p>	<p><code>Txnrequest</code> and <code>Txnstart</code> only. Optional. The card class that is expected (this provides a hint much like flags) to enforce only this card classification be allowed. UniTerm will normally prompt for the card type from the cardholder if it can not be determined based on the card presented. This option can be useful if the POS has already determined the card type prior to requesting UniTerm to process a transactions. If a card is presented that does not match the card class, the transaction will be rejected. Supported classes are:</p>

	<ul style="list-style-type: none"> • CREDIT - Credit card transaction • DEBIT - DEBIT card transaction • EBTFS - Electronic Benefits Food Stamps (SNAP) transaction • EBTCB - Electronic Benefits Cash Benefits transaction • INTERAC - Canadian Interac card transaction • GIFT - Gift card transaction
u_device	<p>Requests: Txnrequest, Txnstart, Cardrequest, DeviceInfo, DeviceLoad, DeviceUpload, DevicePrint, DeviceReboot, ReqSignature, ReqConfirm, ReqInput</p> <p>This specifies the path of the card entry device. Required parameter unless performing a GUI-based action (such as manual keyed entry, or swiping via a keyboard emulation card reader). Required if u_devicetype is provided.</p> <ul style="list-style-type: none"> • HID[:serialnum] - HID (such as USB-HID), takes an optional serial number • SER:port - Serial • BT:mac,[uuid] - Bluetooth • IP:ipaddr:port - IP
u_devicetype	<p>Requests: Txnrequest, Txnstart, Cardrequest, DeviceInfo, DeviceLoad, DeviceUpload, DevicePrint, DeviceReboot, ReqSignature, ReqConfirm, ReqInput</p> <p>The unique device type supported by UniTerm as found via a devicelist request. Required if u_device is provided.</p>
u_language	<p>Txnrequest and Txnstart only. Used to override terminal defaults for display of text prompts. Current choices are "en" or "fr".</p>
u_currency	<p>Txnrequest and Txnstart only. The numeric ISO currency code for EMV transactions (e.g. 840 for USD, 124 for CAD). Defaults to the terminals configured currency. This parameter is used to override the terminals default currency.</p>
u_deviceidlemessage	<p>Txnrequest, Txnstart, or deviceload only. Sets a message that the terminal should display when idle, this will be persistently cached by UniTerm and associated with the device serial number.</p>
u_forceload	<p>deviceload only. Values allowed are yes, no, and full. If not specified defaults to no. A value of yes will force a reload of all EMV parameters even if UniTerm believes the device already has the latest set of parameters. A value of full will additionally force reloading of all other objects UniTerm maintains, including but not limited to, configuration values, forms, and images.</p>

u_id	Txnrequest, Txnstart, TxnFinish, Cardrequest, Status, and Cancel only. A unique id (generated by the calling application) that identifies the transaction. This is used for checking the status or canceling the transaction. Without this id the transaction state cannot be queried.
amount	Txnrequest and TxnFinish only. Transaction amount. Required.
u_b64data	Deviceupload only. Base64-encoded file data to upload. Required.
u_filename	Deviceupload only. Filename of the file to write. Required.
u_text	Deviceprint only. ASCII pre-formatted text to print to receipt printer. Required.
u_message	Reqconfirm only. Textual request message to prompt user for confirmation. Required.
u_inputtype	Reqinput only. Type of user input being requested. Required. Possible values: <ul style="list-style-type: none"> • PHONENUM - Request user to input a phone number. This may be useful for loyalty card prompting. • INVOICENUM - Request user to input an invoice/order/ticket number
u_foodamount	Txnrequest, Txnstart, or Txnfinish only. Dollar amount indicating amount of qualified food purchases for EBT Food Stamps (SNAP). Or during an Txnstart the food amount may not yet be known, but to enable EBT prompting, a special value of maybe may be passed, followed by the the real amount in Txnfinish. If the amount passed in Txnfinish is zero, but EBT Food Stamps was selected by the card holder, the transaction will be aborted.
u_sharedsecret	Required on all transactions if a shared secret is set in the ini file.
monetra.host	Modifyconfig only. Modify the [monetra] host configuration value.
monetra.port	Modifyconfig only. Modify the [monetra] port configuration value.
uniterm.idle_message	Modifyconfig only. Modify the [uniterm] idle_message configuration value.

4.2.1 UniTerm Actions (u_action)

The table below contains the descriptions of each possible UniTerm Action. The AUTH column indicates if the request requires authentication (username/password) or not.

u_action	AUTH?	description
deviceload	Yes	<p>Load a device with EMV and/or Interac parameters. This request will start a terminal download of EMV and/or Interac parameters to load into the device being used. Requires username, password, u_device, and u_devicetype parameters.</p> <p>If the load for the device is identical to the previous load, the load will be skipped.</p> <p>Please note this process may take up to 3 or 4 minutes depending on the processing institution being used and the device being used. The Device may also reboot during this process. It is strongly recommended to call this function when a lane opens, however if it is not called, it will automatically be performed prior to the first transaction.</p> <p>If the device or merchant account does not support EMV or Interac, this command will simply return success.</p> <p>Optionally u_deviceidlemessage may be passed to this as well to set the device's default message if supported by the device.</p>
txnrequest	Yes	<p>Full Transaction Request for card holder data. Request a transaction be performed, all normal Monetra transaction parameters should be included in the request that may be required for processing or to comply with interchange requirements (e.g. action, username, password, amount, nsf, ordernum, etc). Sensitive data, explicitly, should not be sent (e.g. trackdata, account, cvv2, pin) as that data will be retrieved by UniTerm either via the GUI or via a card entry device and forwarded to the Monetra server as part of the transaction request.</p> <p>UniTerm will fully control the transaction flow and user prompting for such a transaction. This request should only be used when card data entry is required as part of the transaction, for other operations passthrough may be a more appropriate action.</p>
txnstart	Yes	<p>Transaction Start Request for card holder data. Request to start a QuickChip transaction, similar in function to a txnrequest message, but does not accept a transaction amount. Needs to be followed up with a txnfinish or cancel request. Once a card is presented and the cardholder has completed any necessary verification and removed their card, a response will be returned with card information metadata such as the card type, some basic EMV card parameters, and the last 4 digits of the card number.</p>

		<p>Though the purpose of this request is to support QuickChip, it still supports non-EMV transactions.</p> <p>A <code>u_id</code> unique parameter is required to be sent with this request for completing the transaction.</p> <p>See QuickChip for more information.</p>
<code>txnfinish</code>	Yes	<p>Transaction Finish Request. Request to finish a QuickChip transaction. Requires the integrator send the same <code>u_id</code> as was sent with the initial <code>txnstart</code> request. The integrator can choose to send additional parameters to pass through to Monetra with this request based on information returned from <code>txnstart</code> (e.g. card type). Will return the same response parameters as <code>txnrequest</code>.</p> <p>See QuickChip for more information.</p>
<code>cardrequest</code>	Yes	<p>Non-Financial Card Entry Request. UniTerm will prompt for card entry, and if it is determined the card is non-financial, it will return the card data. This can be used for manager cards and private label gift cards that are not processed through Monetra. The card must be swiped, and the reader must be configured to return the card in unencrypted form.</p>
<code>passthrough</code>	Yes	<p>This action performs a direct pass-through of parameters to the Monetra server. Only the <code>username</code>, <code>password</code>, and <code>u_action</code> parameters are required. This method will simply proxy requests to the Monetra server and can be used for transaction modifications (e.g. voids) or for pulling reports from Monetra.</p> <p>Do not use this request if cardholder data needs to be retrieved for the transaction.</p> <p>Users may wish to send their requests directly to Monetra rather than using this feature.</p>
<code>cancel</code>	Yes	<p>Will attempt to cancel an outstanding <code>txnrequest</code> or <code>txnstart</code>. Requires <code>username</code>, <code>password</code> and <code>u_id</code> fields which must match the pending request. If the transaction cannot be canceled, such as if it is ineligible (such as when waiting on a response from the Monetra server), or the device doesn't support canceling the outstanding request, <code>u_errorcode</code> will return <code>PENDING_TRAN</code>.</p>
<code>status</code>	Yes	<p>Requests the current status of a pending <code>TXNREQUEST</code> or <code>txnstart/txnfinish</code>. Requires <code>username</code>, <code>password</code> and <code>u_id</code> fields which must match the pending request. This will provide a textual verbiage response suitable for clerk display. Will normally return a <code>u_errorcode</code> of <code>SUCCESS</code> when either the transaction is still in-progress or UniTerm is in a cleanup</p>

		phase after a transaction. Will return a value of <code>UID_NOT_FOUND</code> if the request is no longer being processed.
<code>deviceupload</code>	Yes	Requests uploading the given file to the device at the requested device path. Not all devices support the concept of file uploads. Required parameters are <code>u_b64data</code> , <code>u_filename</code> , and may return <code>u_needreboot=yes</code> to indicate that a device reboot is required for the change to take effect (an automatic reboot will not occur so that additional files that may also require reboot can be uploaded). The <code>u_filename</code> should contain a properly formatted path for the device in use. Some devices like Ingenico RBA just want the filename with no path component.
<code>deviceprint</code>	Yes	Requests printing the given text to a built-in receipt printer if available. The text provided must be formatted properly for the given device. Only plain text receipts are supported. Receipt data is provided via the <code>u_text</code> parameter.
<code>devicereboot</code>	Yes	Requests the device to reboot. Typically this should only be done when an <code>u_needreboot=yes</code> parameter is returned in response to a file upload request.
<code>reqsignature</code>	Yes	Requests the device to prompt for signature capture for non-financial requests. This should only be used outside of a transaction flow (e.g <code>txnrequest</code> or <code>txnstart/txnfinish</code>). For financial transactions, a signature will be automatically captured and stored within Monetra so there is no need to call this function. The signature data will be directly returned to the caller in the <code>u_signature</code> response parameter. Not supported in GUI mode
<code>reqconfirm</code>	Yes	Requests the user confirm a message presented on the screen. The message is supplied via the <code>u_message</code> request parameter, and the response is recorded in the <code>u_confirmed</code> response parameter. Not supported in GUI mode
<code>reqinput</code>	Yes	Requests the user enter the input type specified via <code>u_inputtype</code> . The response data is returned in the <code>u_input</code> response parameter. Supported in both GUI and device mode
<code>devicetypes</code>	No	Will return a comma separated list of device types supported by the UniTerm module. No authentication required. Headers: <ul style="list-style-type: none"> • <code>devicetype</code> - internal device name • <code>manufacturer</code> - textual description of device manufacturer • <code>model</code> - textual description of model

		<ul style="list-style-type: none"> • <code>connectivity</code> - pipe separated list of connectivity methods supported by the device, e.g. <code>SERIAL HID BLUETOOTH IP</code> • <code>functionality</code> - pipe separated list of functionality supported by the device: e.g. <code>EMV MAC E2E KEY SIGNATURE UPLOAD PRINT REBOOT CONFIRM FREEFORM</code> (FreeForm is used by <code>reqinput</code>)
<code>seriallist</code>	No	<p>Will return a comma separated list of all serial ports enumerated on the system. No authentication required.</p> <p>Headers:</p> <ul style="list-style-type: none"> • <code>port</code> - The port path • <code>desc</code> - Description of port, if applicable
<code>bluetoothlist</code>	No	<p>List all 'bluetooth' devices that have been paired with the machine UniTerm is running on. The device may or may not be present. Currently only supported on Android and iOS.</p> <p>Headers:</p> <ul style="list-style-type: none"> • <code>name</code> - The textual name of the device as registered with the operating system. • <code>mac</code> - The device bluetooth MAC address • <code>uuid</code> - The device bluetooth UUID
<code>hidlist</code>	No	<p>List all supported HID (possibly USB-HID) devices that are currently attached to the machine UniTerm is running on.</p> <p>Headers:</p> <ul style="list-style-type: none"> • <code>devicetype</code> - The devicetype (device internal name) associated with the HID entry • <code>manufacturer</code> - The manufacturer as advertised by the device. • <code>model</code> - The pretty name for the device type as it is known to UniTerm • <code>product</code> - The product as advertised by the device. • <code>serialnum</code> - The serial number as advertised by the device.
<code>shutdown</code>	Yes	Terminates execution of the UniTerm. This should be called when the application software terminates.
<code>modifyconfig</code>	Yes	Allows a select number of <code>ini</code> configuration settings to be set via the API. In order to activate the ability to use this feature, an integrator must enable the shared secret in the configuration and the connection must come from the local machine.
<code>version</code>	No	Requests the current version of UniTerm. The version information is output in human-readable format in the <code>verbiage</code> response field. The version information also contains the build number.

deviceinfo	Yes	Requests the information about the connected device. Returns response parameters of: serialnum, device_manuf, device_model, device_app, device_appver, device_kernver
------------	-----	---

4.2.2 Interchange/Rate Qualification Requirements

UniTerm cannot generate all the parameters necessary for proper interchange qualification. An integrator must ensure they are passing all the required parameters for their industry, card brand, or special processing requirements. In general, there are a few parameters of greater importance than others, those that will apply to all merchants that integrators need to ensure they are aware of. For a complete list of parameters accepted, please reference the Monetra Client Interface Protocol Specification.

The table below contains a list of the most important parameters, please keep in mind this is not a complete list:

Key	Required When	Description
nsf	Card Present	<p>Required value: yes</p> <p>Approve transactions even if there are insufficient funds (NSF). Will result in a partial approval if there are insufficient funds, an authamount response parameter will be returned for partial authorizations. When a partial authorization is received, a merchant should request another payment method for the remaining funds. It is acceptable to request a reversal if no additional payment methods are possible.</p> <p>All card brands are requiring merchants support partial authorizations, merchants can be subjected to fines. Some issuers may return partial approvals even without this flag because of the requirements in place.</p>
laneid	Card Present	<p>The lane ID is a Mastercard requirement that each register or lane at a merchant's location be uniquely identified. This should be a numeric value no more than 8 digits in length, however some processors cannot support more than 2 or 4 digits. It should be sent on all transactions as it is not possible to know the card type prior to a request to UniTerm.</p>
ordernum	Restaurant, Card Not Present, Level 2	<p>A merchant order number is required on all card not present (mail order and ecommerce) transactions, Restaurant, and all Level2 cards such as purchase or corporate cards. Since it is not possible to know the card type prior to a request to UniTerm an Order Number should be sent on all transactions.</p>

		An order number is normally alpha-numeric up to 25 characters, however for restaurant a 6 digit order number should be used
examount	Restaurant	Extra Amount - Tip Amount. If a tip amount is known at the time of sale it must be populated, if using UniTerm's built-in tip-prompting, this field should not be passed as UniTerm will populate it.
zip	Key Entered	All key entered transactions should include at least a billing zipcode for best rate qualification. Often this is best accomplished by passing a <code>u_flags</code> of <code>AVS</code> , however there may be cases where the billing zipcode is already on file and will be presented separately.

4.3 UniTerm Response Parameters

The UniTerm module will return all standard response tags from the Monetra server such as `code=`, `cardtype=`, and so on. The additional tags listed below are for transaction flow handling, please see the EMV Receipt section for additional tags that may be returned specific to receipt formatting.

PARAMETER	VALUE
<code>u_emv_chip_malfunction</code>	(yes or not sent) = Indicates that there was a chip malfunction during EMV Complete. Note: Certain card brands require a note on the receipt stating there was a chip malfunction.
<code>u_need_signature</code>	(yes or not sent) = Monetra returns <code>rcpt_emv_cvm</code> which can have a value of "sig" saying signature is required. The <code>u_need_signature</code> means that a signature is required and it should be printed/obtained from the paper receipt. If an EMV requires a signature and one was not captured electronically, this flag indicates it should be obtained via a paper receipt.
<code>u_errorcode</code>	See section below.
<code>u_cancelable</code>	<code>u_action=status</code> only. Yes or No. Indicates if the current transaction state will allow a cancel to be sent. This is useful for showing and hiding a cancel button within an integration's GUI.
<code>trackdata</code>	<code>u_action</code> is <code>txnrequest</code> , <code>txnstart</code> , or <code>cardrequest</code> only. Also requires the <code>ini</code> configuration of <code>unsupportedcard=yes</code> . Will only be returned for non-financial cards that are returned unencrypted from the reader. Facilitates the use of manager cards as well as in-store private label gift systems that do not flow through Monetra. The <code>u_errorcode</code> returned with the response will always be <code>NONFINANCIAL</code> . Support during a <code>txnrequest/txnstart</code> is tailored to the use of

	private label gift cards and will only be returned when the cardholder selects GIFT from the payment type selection screen.
serialnum	u_action=deviceinfo only. Serial Number of connected device.
device_manuf	u_action=deviceinfo only. Device Manufacturer.
device_model	u_action=deviceinfo only. Device Model Name.
device_app	u_action=deviceinfo only. Application running on connected device.
device_appver	u_action=deviceinfo only. Version of the application running on the connected device.
device_kernver	u_action=deviceinfo only. EMV Level2 kernel version of the connected device.
device_encryption	u_action=deviceinfo only. Encryption type used by device, if any.
u_needreboot	u_action=deviceupload only. Will return "yes" when a device reboot is needed for the action performed to take effect.
u_signature	u_action=reqsignature only. Will return base64-encoded TIFF data representing the signature captured by the device.
u_confirmed	u_action=reqconfirm only. Will return "yes" or "no" depending on if the user confirmed the dialog.
u_input	u_action=reqinput only. Will return the user-entered data.
u_tip	u_action is txnrequest or txnfinish. Will return the tip amount chosen by the cardholder.
u_cashback	u_action is txnrequest or txnfinish. Will return the Cash Back amount chosen by the cardholder.
u_wasfood	u_action is txnrequest or txnfinish. Will return a boolean value indicating if the cardholder selected EBT Food Stamps (SNAP).
u_status	u_action is status. Machine readable status code. See UniTerm Status Codes.
u_flowflags	u_action is txnrequest, txnstart, or txnfinish. Pipe-delimited flags to provide integrators more insight into possible actions UniTerm has taken. <ul style="list-style-type: none"> • SIGCAPTURED - Signature was captured • REVERSED - The transaction was approved but then reversed. This is typically due to the customer canceling the transaction, or the card declined the transaction.

4.4 UniTerm Error Codes

Errors will be returned in the `u_errorcode` field. Each error code may be used for more than one error type. Please see the verbiage response for more details. Note: On a successful transaction the `u_errorcode` will be set to SUCCESS but that only indicates communications with the Monetra server were successful. It does not mean the transaction was approved.

u_errorcode	definition
MISSING_PARAM	A required parameter was missing.
INVALID_PARAM	A specified parameter was invalid
PENDING_TRAN	pending transaction already in progress
INVALID_USE	Typically means parameters specified should not have been specified together.
PERMISSION_ERROR	The user account within Monetra was misconfigured.
MONETRA_ERROR	There was an error communicating with Monetra.
DEVICE_ERROR	There was an error communicating with the card entry device.
CANCELED	User canceled request
FAILURE	Generic Failure
DEVICE_INUSE	The device specified is being used by another transaction.
UID_NOT_FOUND	A <code>u_id</code> was specified on a status or cancel request and no such <code>u_id</code> is actively being processed.
BAD_READ	The device returned a card read error.
MAC_FAILURE	The transaction was rejected because the MAC returned from the processor did not match the expected value.
EMV_CARD_DENY	The card locally declined the transaction.
EMV_CARD_REMOVED	The card was removed before the end of the transaction.
CARD_NOT_SUPPORTED	The card presented was not supported.
DEVICE_NOT_LOADED	The device needs to be loaded before it can run EMV transactions.
FALLBACK_NOTALLOWED	There was an error reading the chip and the card brand rule does not allow the card to be re-presented via another means.
INI_CANNOT_FIND	The <code>uniterm.ini</code> could not be found.
INI_CANNOT_READ	The <code>uniterm.ini</code> is not readable by the UniTerm process.
INI_CANNOT_WRITE	The <code>uniterm.ini</code> is not writable by the UniTerm process.
INI_INVALID_PARAM	The <code>uniterm.ini</code> has an invalid configuration parameter.
NONFINANCIAL	The card presented is not a financial card. This code will be returned when requesting and returning trackdata for non-financial cards when the configuration of <code>unsupportedcard=yes</code> is set.

4.5 UniTerm Status Codes

Status codes returned via the `u_status` response parameter. Each status code may be a generalization used for more than one phase of the transaction flow. Please refer to the `verbiage` response parameter for a more descriptive human-readable status message.

u_status	definition
WORKING	Generic status say UniTerm is processing.
CARD	Waiting for card presentation. With EMV card could be inserted and waiting for customer to choose language.
EMVFLOW	EMV processing. Typically waiting for customer to enter their PIN.
KEYED	Waiting for keyed account and related (zip, cvv).
PIN	Waiting for PIN entry. This may not be presented for EMV cards as the device may handle this internally.
CARDCLASS	Waiting for card class selection (Debit, EBT, Gift prompting)
TIP	Waiting for tip entry.
CASHBACK	Waiting for cash back entry.
SIGNATURE	Waiting for signature.
EMVCOMPLETE	EMV processing is completing.
CONFIRM	Waiting for user confirmation.
CONFIRMAMOUNT	Waiting for user to confirm the transaction amount.
CONFIRMFOOD	Waiting for user to confirm the food amount.
CONFIRMRETRY	Waiting for user to confirm to retry the transaction after a failure.
INPUT	Waiting on customer input (e.g. phone number).
MONETRA	Communication with Monetra. Typically waiting on a response from Monetra.
REMOVECARD	Waiting for card removal.
REVERSAL	Reversing transaction (typically due to card decline).
DEVICEPRINT	Printing receipt on device.
DEVICEOPEN	Waiting for device to open.
DEVICECLOSE	Waiting for device to close.
DEVICEREBOOT	Rebooting device.
CANCEL	Canceling transaction or operation.

4.6 Tip Prompting

UniTerm supports prompting the cardholder for a tip amount at the time of payment when the `[uniterm] tippercent` configuration setting is configured and the `NOTIP u_flags` parameter is NOT provided.

When a customer has chosen to add a tip amount to a transaction, the amount provided by the POS to UniTerm will be incremented to reflect the tip amount and the `examount` will be populated with the tip amount when the transaction is sent to Monetra.

In the response returned by UniTerm, the tip amount will be provided to the POS in the `u_tip` response parameter.



Note: Special care should be taken to validate if the `authamount` response parameter is returned, indicating a partial authorization occurred, that split tender operations can occur. When prompting for a second payment method, an integrator should use the `NOTIP u_flags` in order to avoid tip prompting on the second method of payment, and respect the returned `u_tip` response for the chosen tip amount from the original response.

4.7 Cash Back Prompting

UniTerm supports prompting a cardholder if they would like to request Cash Back when presenting a Debit or EBT Cash Benefits card for payment. UniTerm will automatically perform such prompting if the `[uniterm] cashbackamount` configuration parameter is set and the `NOCASHBACK u_flags` parameter is NOT set. The `[uniterm] cashbackmax` configuration parameter can be used to limit the amount of Cash Back that can be requested.

When a customer has chosen to request Cash Back with a transaction, the amount provided by the POS to UniTerm will be incremented to reflect the Cash Back amount and the `cashbackamount` parameter will be populated with the Cash Back amount when the transaction is sent to Monetra.

In the response returned by UniTerm, the Cash Back amount will be provided to the POS in the `u_cashback` response parameter.



Note: Special care should be taken to validate if the `authamount` response parameter is returned, indicating a partial authorization occurred. If the returned amount is less than the requested amount plus `u_cashback` then the POS must decide on the proper course of action. For instance if the `authamount` is greater than requested, but less than the amount plus `u_cashback` then partial Cash Back would be provided to the cardholder. Otherwise if the `authamount` is less than the requested amount, then the `u_cashback` returned should be completely ignored and the POS would need to prompt the cardholder for another method of payment.

4.8 EBT Processing

UniTerm supports prompting if the card presented is an EBT card. If the `u_foodamount` parameter is populated with a non-zero dollar amount indicating the amount of the transaction that applies to qualified food purchases (or for `txnstart` with a value of `maybe`), then the customer will also be prompted if they would like to use Food Stamps (SNAP) or Cash Benefits to complete the transaction. When the cardholder makes the selection, UniTerm will internally rewrite the `action=sale` request parameter to `action=ebtfsale` or `action=ebtcbsale` as appropriate.

For `txnstart` transactions where `u_foodamount=maybe`, the integrator must send a valid `u_foodamount` value with `txnfinish` otherwise the transaction will be aborted.

If Food Stamps (SNAP) was selected, `u_wasfood` will be returned as `yes/true` to indicate this. If the requested amount is greater than `u_foodamount`, then a partial authorization will be returned (as indicated by the `authamount` response parameter) indicating the amount of the authorization was less than the requested. This returned `authamount` may be less than the `u_foodamount` if there are insufficient funds, otherwise it will be equal to the `u_foodamount` requested.

If a partial authorization is performed, the merchant should perform a split-tender operation and prompt for another method of payment for the remainder, which may also be EBT. The requested amount and `u_foodamount` need to be adjusted accordingly on the next request based on the amounts previously authorized.

4.9 QuickChip

The card brands have coined the term QuickChip to refer to the modification of the EMV flow to reduce the amount of time a card must stay in the terminal, allowing the card to be presented as early as possible. The goal of QuickChip is to ensure no additional delay to the overall checkout process is incurred for EMV transactions when compared to an MSR transaction. It also is more similar to the existing MSR flow that customers may be acquainted with.

QuickChip is only available in the US Market, the card brands have not yet allowed this flow in other markets.

In order to use QuickChip with UniTerm, an integrator must use the `txnstart` and `txnfinish` messages rather than the `txnrequest` message. When the merchant opens the order to add items for purchase, they will immediately send the `txnstart` message, which will not contain an amount since the final amount is not yet known. Once the card holder has presented their card and completed any necessary cardholder verification, and removed their card, a response will be returned to the merchant. Once the final amount is known, the merchant will send a follow-up `txnfinish` message with the final amount and the transaction will go online for approval and the merchant will be returned all the receipt data just as if the request was a `txnrequest`.

If the amount is known at the time of the order, then the non-QuickChip `txnrequest` message should be used.

4.10 Pay at the Table

UniTerm provides all the tools needed for an integrator to support Pay at the Table. Though the method an integrator might choose can vary from system to system, we have outlined a suggested flow that should work for most environments when integrators choose to use a payment device specifically meant for pay at the table without necessitating the need for the use of an additional device such as a tablet. Those integrators that choose to use a tablet for pay at the table will not use the information contained in this section as the flow, in relation to UniTerm, would more closely resemble the standard Pay at the Counter flow.

The below flow assumes the customer will be entering their own invoice number, but a clerk may choose to perform that step on their behalf if there is only one ticket associated with the table.

- Print one or more detailed meal tickets for the table (split checks), and ensure a unique numeric order number for the day appears on the ticket. It is suggested these ticket numbers be 6 digits in length and randomly, not sequentially, generated to help prevent typos matching another open ticket. Deliver the tickets along with a payment device to the table, such as an Ingenico IWL250 that is wireless and contains a built-in receipt printer.
- Send a `u_action=reqconfirm` request with a useful message/instruction to the user such as "`u_message=Enter ticket number from top of ticket on next screen.`", wait on a response. Ignore the actual response returned.
- Send a `u_action=reqinput` with `u_input=INVOICENUM` and wait on a response.
- Look up the requested Invoice, and assuming it is found and not already paid, request the user confirm it is the right ticket and amount using `u_action=reqconfirm`, when the user accepts the dialog, precede to the next step, if rejected, start over. If the invoice was not found, use `u_action=reqconfirm` to send back an error and restart the flow.
- Start the payment flow with `u_action=txnrequest` as you would in a normal clerk-attended environment. Tip prompting, etc will take place if UniTerm is configured to do so. On error or user cancellation, restart the flow, otherwise continue to the next step.
- If a signature is required, and the device does not support signature capture, format a receipt for the printer size on the device and send `u_action=deviceprint` with the `u_text` set to the plain text, pre-formatted, MERCHANT receipt data with a signature line.
- If a merchant receipt was printed, and the device being used does not have an automatic cutter, then you should prompt the user for how to tear the receipt then press enter to continue using the `u_action=reqconfirm`, and ignore the result of the request.
- Format a receipt for the printer size on the device and send `u_action=deviceprint` with the `u_text` set to the plain text, pre-formatted, CUSTOMER receipt data (no signature line).
- Start the flow over for more tickets.

4.11 Signature Capture

During a transaction, if UniTerm decides a signature is necessary to complete a transaction and the device is capable of capturing a signature, UniTerm will automatically prompt for signature and save it with the transaction. The signature will be kept on file for as long as the record of the transaction is kept on file. All signatures are stored in the TIFF image format within Monetra and may be retrieved via the `action=admin, admin=getimages` function call. Please see the "Protocol Addendum: Signature Capture/Storage" for Monetra for more information.



Note: Some devices, especially mobile devices, or web browsers may not natively support displaying the `TIFF` image format. It is recommended to use an open source library such as `ImageMagick` to assist in the conversion for display purposes.

5 EMV transactions with UniTerm

- 5.1. Transaction Flow and Prompting 40
 - 5.1.1. Swipe prompts to insert 40
 - 5.1.2. Tap prompts to insert 40
 - 5.1.3. Insert prompts to swipe 40
 - 5.1.4. PIN required on Credit Cards 41
 - 5.1.5. Signature not requested 41
 - 5.1.6. Tap transaction run as MSR on chip card, no insert requested 41
 - 5.1.7. Immediate decline without contacting the processor 41
- 5.2. Common questions 41
 - 5.2.1. How do I add a gratuity/tip to a transaction? 41
 - 5.2.2. What industries are certified for EMV? 42

EMV transactions, by nature, are much more complex than traditional magnetic stripe transactions. UniTerm hides this complexity from the application software. In the case of magnetic stripe and EMV transaction, the application software will send the request to UniTerm. The device capabilities (EMV for example) will be determined by UniTerm, along with the merchant account configuration. From these UniTerm will handle the appropriate prompting and flow aspects related to the determined capabilities. The application software simply needs to send a `u_action=TXNREQUEST` and let UniTerm handle the rest.

5.1 Transaction Flow and Prompting

Integrators unfamiliar with EMV may notice some specific flow cases that seem counter-intuitive at first. This section is meant to address these EMV-specific cases.

5.1.1 Swipe prompts to insert

If a chip-enabled card is swiped on an EMV-capable terminal, it is mandated that the user be prompted to insert the card. This is an EMV certification requirement which cannot be lifted and it is meant to train consumers to insert their cards and to prevent fraud.

5.1.2 Tap prompts to insert

There are certain thresholds negotiated between the card and terminal which may request a chip-enabled card that is presented as a tap transaction be inserted instead. When this occurs, it can be due to a number of factors including fraud mitigation, or the card has determined it needs to be updated (for insert transactions, an issuer can choose to return issuer scripts to remotely reprogram cards).

5.1.3 Insert prompts to swipe

If a chip-enabled card is prompted to be swiped, this is usually an indication that there was a chip malfunction and the cardholder should have their card replaced, called a technical fallback. It is expected at some point in the future, technical fallback will be disallowed due to

fraud concerns. The other possibility is if the application id in use by the card is not supported by the terminal.

5.1.4 PIN required on Credit Cards

The cardholder verification method is negotiated between the card and the terminal. If both the card and terminal support PIN entry, it may be chosen as the desired verification method. Consumers in the US may not expect to enter a PIN on their credit cards, but it is common among foreign cards.

5.1.5 Signature not requested

The cardholder verification method is negotiated between the card and the terminal. They may negotiate Signature, PIN, or what is called `NO_CVM` which means no cardholder verification is required for the transaction. The decision is strictly made based on the terminal capabilities and card capabilities.

5.1.6 Tap transaction run as MSR on chip card, no insert requested

It is a requirement by the card brands that if a chip-capable card is presented as a tap that the card NOT be prompted for insertion. This can happen due to a terminal not being configured for contactless EMV support, or if a chip is malfunctioning.

5.1.7 Immediate decline without contacting the processor

EMV cards have the ability to make decisions about the transaction before it is even processed. From time to time a merchant may see a chip card presented that results in an immediate decline before requesting cardholder verification or connecting to a processing institution. This could happen because the card has exceeded some internal threshold, or the card has received a remote script on a previous transaction to explicitly block transactions, such as a card block or application block.

5.2 Common questions

5.2.1 How do I add a gratuity/tip to a transaction?

Tips are added to EMV authorizations just as they are with MSR authorizations, nothing has changed in the US rules. An integrator will simply send a `preauth` with the order amount, then when the tip amount is known, a `preauthcomplete` will be sent with the final order amount and `examount` will contain the tip amount. However, if the tip is greater than 20%, merchants should obtain a new authorization for the tip according to the card brand rules. Of course if the tip amount is known prior to the authorization, the tip amount should be included a part of the authorization request.

There is much confusion regarding tips in the US market with the introduction of EMV Chip and Pin, most of this is due to European rules which state the gratuity amount must be sent

with the initial authorization request. This does not currently apply to the US market, however there is discussion that Mastercard may start disallowing tip modification in the future for Chip cards when using PIN verification (but, presumably, not when using Signature or NoCVM verification).

Please refer to the below card brand documentation for more information:

- http://www.mastercard.com/us/merchant/pdf/TPR-Entire_Manual_public.pdf (page 70)
- https://www.visa.com/chip/merchants/grow-your-business/payment-technologies/credit-card-chip/docs/Play_it_Smart_With_US_Chip_Payment_Transactions.pdf (page 3)

5.2.2 What industries are certified for EMV?

EMV doesn't define certifications by industry, the industry-specific data is outside of the EMV-relevant data. Instead EMV works on what they call Terminal Types.

In general, there are 2 relevant terminal types, and those are "Attended" and "Unattended". For "Attended" terminal types, this is where there is a clerk present such as a supermarket, normal retail location, or restaurant. "Unattended" terminal types are used in Self Serve terminals such as kiosks or fuel pumps.

Examples of "Attended" industries in Monetra are "Retail", "Restaurant" and "Lodging".

Examples of "Unattended" industries in Monetra are "Retail Self Serve" and "Automated Fueling".

Please see the Certifications section for what devices and processors are certified for "Attended" vs "Unattended" to see what is currently supported. As long as the industry you support falls into the "Attended" or "Unattended" category that has an EMV certification for the given device and processor you choose, and Monetra itself supports the desired industry for the given processor, then it is a supported configuration.

6 UniTerm Protocol Examples

6.1. EMV Transaction [device load]	43
6.1.1. UniTerm Request Data	43
6.1.2. UniTerm Response Data	43
6.2. EMV Transaction [Interac]	44
6.2.1. UniTerm Request Data	44
6.2.2. UniTerm Response Data	44
6.3. Pin Debit (forced) Transaction Request	45
6.3.1. UniTerm Request Data	45
6.3.2. GUI output	46
6.3.3. UniTerm Response Data	46

Several examples are provided below which describe how to use the UniTerm protocol.

6.1 EMV Transaction [device load]

6.1.1 UniTerm Request Data

PARAMETER	VALUE
password	test123
u_action	deviceload
u_device	USB
u_deviceidlemessage	WELCOME
u_devicetype	ingenico_cpx
u_flags	DEVICEONLY
u_id	1182112391
username	moneris_ipp320x:sub

6.1.2 UniTerm Response Data

PARAMETER	VALUE
addltermcaps	F000F0F001
addltermcaps_desired	6000F0F001
addltermcaps_loa	F000F0A001
altered_termload	yes
code	AUTH
loa_id	3C
termcaps	E0B8C8
termcaps_desired	E0B8C8

UniTerm Protocol Examples

termcaps_loa	E0B8C8
termttype	22
termttype_desired	21
u_errorcode	SUCCESS
verbiage	Device loaded

6.2 EMV Transaction [Interac]

6.2.1 UniTerm Request Data

PARAMETER	VALUE
action	sale
amount	1.00
nsf	yes
ordernum	899065992
password	test123
u_action	txnrequest
u_device	USB
u_deviceidlemessage	WELCOME
u_devicetype	ingenico_cpx
u_flags	DEVICEONLY
u_id	899065992
username	moneris_ipp320x:sub

6.2.2 UniTerm Response Data

PARAMETER	VALUE
account	XXXXXXXXXXXXXXXXXXXX2145
auth	221093
batch	1
cardholdername	Test Card 14
cardtype	INTERAC
code	AUTH
item	793
language	en
merch_addr1	123 STREET NAME
merch_addr2	CITY, STATE ZIP

UniTerm Protocol Examples

merch_id	1625
merch_name	MERCHANT NAME
merch_phone	(888) 555-1234
msoft_code	INT_SUCCESS
pcllevel	0
phard_code	SUCCESS
rcpt_acct_type	checking
rcpt_custom	refnum:660136000010017930
rcpt_emv_ac	882D8427A268E214
rcpt_emv_actype	TC
rcpt_emv_aid	A0000002771010
rcpt_emv_cvm	pin
rcpt_emv_name	Interac
rcpt_emv_tsi	7800
rcpt_emv_tvr	8000008000
rcpt_entry_mode	C
rcpt_host_ts	072315151022
rcpt_issuer_resp_code	00
rcpt_resp_code	001
timestamp	1437678622
ttid	992
u_errorcode	SUCCESS

6.3 Pin Debit (forced) Transaction Request


6.3.1 UniTerm Request Data

PARAMETER	VALUE
action	sale
amount	1.00
nsf	yes
ordernum	899065992
password	test123
u_action	txnrequest
u_cardclass	DEBIT
u_device	USB
u_deviceidlemessage	WELCOME

UniTerm Protocol Examples

u_devicetype	ingenico_rba
u_id	899065992
username	transarmor_isc250:sub

6.3.2 GUI output



6.3.3 UniTerm Response Data

PARAMETER	VALUE
account	XXXXXXXXXXXX0027
auth	412303
batch	15
cardtype	MCDEBIT
code	AUTH
item	139
merch_id	0993
msoft_code	INT_SUCCESS
pcllevel	0
phard_code	SUCCESS
rcpt_entry_mode	S
timestamp	1437678765
ttid	200
u_errorcode	SUCCESS

7 UniTerm Test Application

Included with the UniTerm software distribution is a test application known as "UniTerm Tester". This test application is a simple graphical user interface which may be used to test the various functionality in UniTerm. This utility should be used by developers exploring the functionality of UniTerm as it will provide the request and response messages from UniTerm as well as generate sample receipts for each request. The test utility can be found in the same directory as the `uniterm` executable named `unitermtester`.

8 UniTerm Code Examples

Code examples are provided help you understand how easy it is to integrate your application with the UniTerm middleware. Please see Appendix C for complete code examples.

Examples are provided for the following languages:

- Microsoft C# using libmonetra
- Microsoft C# using XML and `HttpRequest`
- Java using libmonetra
- PHP using libmonetra
- Microsoft VB.Net using libmonetra
- Microsoft `vbscript` using XML and `MSXML2`
- Microsoft Visual Basic 6 using libmonetra

9 UniTerm Hardware Devices (Point of Interaction Devices)

- 9.1. Supported POI Devices 49
 - 9.1.1. Ingenico RBA information 50
 - 9.1.2. Verifone VX XPI information 54
 - 9.1.3. Ingenico CPX/uCPX information 55
- 9.2. Obtaining Devices 56
 - 9.2.1. Where to source devices with appropriate loads and keys 56

Card data is captured at the point of sale via a magnetic swipe reader or, in some cases (such as for telephone-based transactions), by manual entry of the card number via a keyboard, touch screen, or key pad. The device where card data is captured is called the Point of Interaction (POI) device or also may be referred to as the "point of capture" or "point of entry" device.



Note: The UniTerm module supports both encrypting and non encrypting POI devices. Using the UniTerm module with non encrypting devices can remove the application software (such as a POS application) from scope for the PCI Payment Application (PA-DSS) standard. Using encrypting POI devices can also reduce or eliminate PCI requirements for merchants.

9.1 Supported POI Devices

The table below describes POI devices currently supported. The column marked ENCRYPTION indicates the type of encryption the device supports (if any). CardShield encryption can be performed by a Monetra server while other types of encryption must be preformed by the transaction processor. The column marked EMV are devices that UniTerm can work with to perform EMV/Chip based transactions.



Note: UniTerm is currently only supporting devices which support EMV. This list may be expanded in the future to support non-EMV devices. This list also does not include keyboard-emulation devices (both encrypting and non-encrypting) which are supported when running in GUI mode.

If you are using a previous version of UniTerm which supported additional non-EMV devices, do not upgrade your version of UniTerm as those devices are not currently supported.

Model	Device S/W	u_devicetype	Notes	Encryption	EMV
Ingenico					
iPP320 CPX	CPX	ingenico_cpx	Canada, UniTerm v8.0 only	NONE	x
iUP250 uCPX	uCPX	ingenico_ucpx	Canada, UniTerm v8.0 only	NONE	x

UniTerm Hardware Devices
(Point of Interaction Devices)

Model	Device S/W	u_devicetype	Notes	Encryption	EMV
Ingenico RBA family (iPP320, iSC Touch 250, etc)	RBA	ingenico_rba	USA	CardShield, First Data TransArmor RSA	x
Verifone					
vx805	XPI	verifone_vx	USA	NONE	x

9.1.1 Ingenico RBA information

The minimum version of the RBA software load supported is v14.0.6 for running EMV transactions. The current recommended version is 19.0.4 if available for your device model, otherwise the latest RBA 18 series for your device should be used (18.0.4 through 18.0.12). Users of UniTerm versions prior to 8.2.0 should continue to use RBA 15.06 or 16.02 (16.02 has a known Mastercard Contactless issue). Please note 15.1X is known to be incompatible, and the entire 15 series should not be used on Bluetooth devices. Any device in the Ingenico RBA family may be used.



Note: RBA v20+ has a new EMV kernel that should not be used at this time as it requires full brand recertification to be used. Future Monetra and UniTerm versions will support the new releases.

The RBA family includes all Ingenico Telium2 devices that can run the RBA (Retail Base Application) software. This includes, but is not limited to:

- iCMP
- iSMP companion
- iWL250
- iPP320 - PCI PTS v3.x+ version
- iPP350 - PCI PTS v3.x+ version
- iSC Touch 250
- iSC Touch 350
- iSC Touch 480

9.1.1.1 Communication Methods

UniTerm supports communicating with RBA via these communication methods (given the proper cables and add-on options from Ingenico):

- USB-HID - No drivers are necessary, select HID as the device connectivity in UniTerm
- USB<>Serial Conv - Requires Telium or Jungo drivers on Windows, will show up as a virtual COM port and be used as a Serial device in UniTerm (Linux and MacOSX do not need drivers, they will show up as serial ports).
- Serial - Settings: 115200 8N1 - No flow control
- Bluetooth - Android native, on Windows it should show up as a virtual COM port and be usable as a Serial device in UniTerm.
- Ethernet - Settings: IP server mode



Note: Not all devices support Bluetooth or USB-HID even if the menu lists it as an available option.

9.1.1.2 Device configuration

RBA devices can be configured by entering the management menu during device boot in order to set up the communication method. When a device is shipped to you, it can often be left in a state which is not compatible with the cabling being used and must be reconfigured. Please ensure you only select one of the supported communication methods as documented in the previous section.

In order to reboot a device, you may either disconnect it from power, or use the reboot key sequence. The key sequence is either the yellow CLEAR button plus the "* . , # " key or the "- " key, depending on which device is being used.

While booting, wait until the RBA splash screen appears with the scroll bars and system information. Then quickly press the management password, which by default is 2 6 3 4 and then the green ENTER key. Follow the on-screen prompts.

The communication method configuration is available via TDA -> Configuration -> Communication.

9.1.1.2.1 Contactless Support

Some devices such as the iPP320 have contactless as an optional module. It is possible when such a device is shipped to you, the optional module is installed but not activated. If you are certain the device has the necessary hardware for contactless, but contactless is not working, you may need to activate it. For the iPP320 this can be confirmed by observing the existence of a contactless chip behind the rear door of the device. Contactless must not be enabled if the device does not have the proper hardware.

In order to enable contactless, use the key sequence documented in the prior section to enter management mode. Then navigate to Telium manager -> Initialization -> Parameters -> Contactless and make sure it is set to Yes -> Internal.

9.1.1.3 Hardware Information

It is important to ensure the device being ordered is the latest hardware revision. Ingenico often introduces newer revisions without changing the model number, however their Part Numbers do in fact differ. The easiest way to request the most recent revision is to ensure you are requesting the PCI PTS v3 or v4 version of the devices. Older hardware revisions comply with PCI PTS v2 and should not be used for new deployments as you may experience issues due to limitations in the hardware.



Note: There have been recent reports of customers receiving iPP320 units that have been sent out as PCI PTS v2 devices. These devices do NOT support RBA12 and higher, even though they may come with a later RBA release. The part number on the supported devices will start with 11, while the part number on unsupported devices will start with 01. If you experience lockups or unexpected behavior, please verify your device is a PCI PTS v3 or higher device.

9.1.1.4 Forms and Images

UniTerm depends on the stock forms and images that ship by default on terminals with RBA. In addition, UniTerm does require a few UniTerm-specific forms and images to be available on the device. These will be generated and uploaded automatically to the device if UniTerm can not find them.

UniTerm will check if it has all the necessary forms on the first transaction run by a device. It will then load any missing forms. When loading forms is required, a message is presented on the device and there is an additional delay until the upload is complete.

It is possible for integrators to fully customize the look and feel of the forms displayed on the device. Such integrators should contact Ingenico and sign up for the developer portal available at <https://developer.ingenico.us/> in order to obtain the necessary form building tools. UniTerm provides the `u_action=deviceupload` function to assist integrators in uploading any custom forms and images they have created directly from their POS. Device distributors can also assist with pre-loading forms and images prior to shipping to end users if more convenient. When uploading forms and images, the `u_filename` should only contain the filename and does not need to reference the `HOST` path on the device.

The forms used and their requirements are listed below.

Forms and Images used by UniTerm:

- `UTAD.K3Z` - The form displayed when the device is idle, also known as the "ADs" screen. This form may be customized to present an image or a series of rotating images, but must not contain buttons. The default form loaded contains a single image, `UTAD.PNG` (or `UTAD.BMP` on `iUP250/iUC285` devices). It is recommended that the images created be specific to the device for best appearance even though the device will scale the image if too small or large.
- `UTCCOD.K3Z` - Form used for card entry / selection. The form loaded is the same as the default Ingenico `CCOD.K3Z` form, with the exception that the `cancelenabled='true'` attribute has been added to allow the cardholder to press the physical cancel button to exit the request payment screen. Integrators wishing to modify this screen need to comply with the capabilities of the stock form.
- `UTCSEL.K3Z` - Form used for tender selection (credit, debit, etc). The form loaded is identical to the default Ingenico `PAY1.K3Z` form. It is duplicated due to an Ingenico limitation that does not allow the use of the stock form when using the "on demand" command mode. Integrators wishing to modify this form must comply with the capabilities of the stock form, especially the mapping of the button names available (e.g. `Bbtna` - debit, `Bbtnc` - credit, etc).
- `MSG.K3Z` - Form used to display single line messages. This is a stock form, any replacements should adhere to the capabilities of the stock form.
- `MSGTHICK.K3Z` - Form used to display double line messages. This is a stock form, any replacements should adhere to the capabilities of the stock form.

- `AMTV.K3Z` - Form used to display confirmation prompts, both for arbitrary prompts and amount confirmation. This is a stock form, any replacements should adhere to the capabilities of the stock form.
- `UTASEL.K3Z` - Form used to display tip and Cash Back prompts, based on the `cashba.K3Z` stock form. Button IDs must be:
 - `O` - Other
 - `N` - No (won't be shown on smaller devices)
 - `A` - Amount 1
 - `B` - Amount 2
 - `C` - Amount 3
- Ingenico may internally call additional forms during the EMV payment processing flow. For information on how to customize these screens, integrators should contact Ingenico.

9.1.1.5 First Data TransArmor RSA Encryption

The Ingenico devices support First Data's TransArmor RSA encryption. TransArmor is First Data's P2PE encryption solution along with tokenization which must be enabled on the account both within First Data's systems as well as within Monetra. When configuring a Monetra account for TransArmor encryption, set the `Encryption` merchant configuration value to `IngenicoRSA`.

As part of the device loading procedure, a key request will be made to Monetra which will request the current key to use from First Data's systems. Monetra will then send that key identifier to `takeys.monetra.com:443` to look for an available signed package to load onto the Ingenico device. Due to limitations in the Ingenico TransArmor implementation it is not possible to directly load the key from First Data's systems into the device. If the requested key package is not yet available, the existing key will be continued to be used until which time the updated package is made available.

TransArmor keys typically expire after 2 years, and new keys will be provided 90 days prior to expiration. All terminals on a given merchant account will share the same RSA public key.

9.1.1.6 Updating RBA firmware with UniTerm

As of UniTerm v8.2, firmware updating is supported through UniTerm. As part of the RBA integration kit provided by Ingenico, there are firmware files provided for multiple upgrade options. The format supported by UniTerm is the `OGZ` format, which is a single-file firmware update. Each device in the RBA family has its own firmware file. For instance, an `iSC 250` cannot use the same firmware file as an `iPP320`.

Upgrading should take place via `USB<>Serial Conv` mode if possible. `USB-HID` mode will add significant time (20+ minutes) to the upgrade process. `Ethernet` mode is quick, but it is known that if a device is configured with a static IP address, the firmware update may reset the device to `DHCP`.

The firmware files are not currently provided by Main Street Softworks, and must be obtained directly from Ingenico. This may change in the future to further aid integrators with deployment updates.



Note: Upgrading the firmware can take several minutes and may wipe all custom settings (including encryption), forms, and images. Only firmware upgrading is tested and supported, downgrading is not recommended. It is also only recommended to update to firmware versions which have been approved for use by UniTerm to ensure compatibility. Please ensure power is not unplugged during an upgrade or the device could be required to be sent in for repair.

Provided below is the recommended steps to perform in order to upgrade the RBA firmware via UniTerm.

1. Request the current device model and RBA version via the `u_action=deviceinfo` command. Ensure the current firmware version needs to be updated before continuing, take note of any additional information returned such as the encryption type.
2. Locate the proper OGZ for the desired RBA version to load for the device model and send it to UniTerm via the `u_action=deviceupload` command. The upgrade process may take 5 minutes or more depending on the connectivity method used. The device will reboot and apply the update and UniTerm should return once the update is complete.
3. Perform a `u_action=deviceinfo` request to ensure the firmware was successfully updated to the desired version.
4. Perform a `u_action=deviceload` with the `u_forceload=yes` parameter to ensure UniTerm re-downloads all EMV settings to the device. The device will reboot after this process.
5. Upload any custom forms or images to the device using the `u_action=deviceupload` command. These forms or images may be uploaded one at a time, or in bulk by packaging them into a TGZ file.
6. Upload any security files such as encryption activation or BIN exclusion lists using the `u_action=deviceupload` command.

If keys are loaded for Monetra/CardShield encryption, RBA includes a file known as `MONETRA.PGZ` or `MONXXYY.PGZ` where the `XXYY` corresponds to the RBA version. This file must be re-loaded in order to ensure the device outputs encrypted data otherwise all data will be output unencrypted. The encryption type loaded prior to the upgrade is returned via the `deviceinfo` request in the first step. It is important to ensure that the encryption file used is the one for the specific RBA version in use or the device may refuse to boot or otherwise behave in abnormal ways.

7. If any files were uploaded to the device after the `deviceload`, it is necessary to call `u_action=devicereboot` before the device is ready to be used.

9.1.2 Verifone v_X XPI information

The version of the XPI software load supported is v8.23a for running EMV transactions. Prior versions of XPI may work for non-EMV transactions, however this functionality has not been extensively tested. Newer versions are known to have issues which prevent them from properly functioning in some EMV test cases.

9.1.2.1 Communication Methods

UniTerm supports communicating with the Verifone vx via these communication methods (given the proper cables and add-on options from Verifone):

- USB - Requires vx USB Drivers available from www.verifone.com on Windows, will show up as a virtual COM port and be used as a Serial device in UniTerm (MacOSX and Linux do not require a driver, will show up as a serial port).
- Serial (COM1) - 9600

When a device is shipped to you, it can often be left in a state which is not compatible with the cabling being used and must be reconfigured.

9.1.2.2 Device configuration

During device boot-up, it is possible to change the connectivity setting to match the cabling. When the XPI version is displayed during startup, press the alpha and 8 buttons simultaneously. You can then change the connectivity method by pressing the appropriate F<n> key.

9.1.3 Ingenico CPX/uCPX information

Ingenico CPX (attended) and uCPX (unattended) software loads are supported for Canadian merchants. These loads support both contact and contactless EMV processing for multiple card brands including Interac debit cards. The required software versions are 10.14 for CPX and 02.02 for uCPX.



Note: The MasterCard PayPass v2.1 kernel must be loaded into the device if supporting contactless MasterCard EMV. If the device is loaded with the PayPass v3.0 kernel, it will fail to accept PayPass transactions. Due to limitations in the Ingenico software, it is impossible for UniTerm to detect the version of the PayPass kernel in use, and the CPX and uCPX software versions are not tied to any PayPass kernel version.

9.1.3.1 Communication Methods

UniTerm supports communicating with CPX/uCPX via these communication methods (given the proper cables and add-on options from Ingenico):

- USB->Serial - Requires Telium or Jungo drivers on Windows, will show up as a virtual COM port.
- Serial - 9600 7bits Even Parity - No flow control
- IP/Ethernet - Even Parity



Note: Please contact Ingenico for assistance with configuring your device for proper communication. It is known that the on-screen menu system does NOT work when configuring Ethernet mode due to the inability to set the Parity to Even. The parity configuration is a crucial step in ensuring Ethernet connectivity is functional.

9.2 Obtaining Devices

Obtaining the right device for use with UniTerm requires care to ensure a few major factors:

- Is the device supported by UniTerm?
 - Please see the prior section: Section 9.1
- Is the device certified for the Processing Institution being used?
 - Please see the next chapter: Section 10.1
- Does the device come preloaded with both the right software and version?
 - Please see section specific to the chosen device under Section 9.1 for supported software revisions running on the device.
- Is the vendor the device is sourced from able to load the appropriate keys (Pin Debit or Encryption) as required?
 - Please see the next section: Section 9.2.1

9.2.1 Where to source devices with appropriate loads and keys

Most providers of POS hardware also offer loading and injection services. It is recommended that you work with one or more providers that can offer these services to ensure smooth deployments and reduced shipping costs. When a device is ordered, other than the device model being ordered, you must also indicate the software load and version to be installed on the device. Most device manufacturers have multiple software loads available so it is essential that you adhere to any documented software requirements to ensure compatibility.

In addition to the software loads on the device, most devices will require a Pin Debit key be loaded into the device. In the US market this is a 3DES DUKPT key used for encrypting pins. Though commonly referred to as a Pin Debit key, it is also required for EMV Credit Card Online PIN verification which uses the same infrastructure for verification of PINs. If EMV is being used, and the certification states Online PIN is used, you **MUST** have a PIN Debit key injected into your device. Unfortunately there are dozens of potential keys, and the correct one for the processing institution and acquirer being used must be injected into the device. You should contact your merchant account provider or acquiring bank to get the Key Serial ID needed for injecting into your device and work with your hardware provider to ensure they have that key available. Only secure key injection facilities can load PIN keys into a device, it is not possible for a merchant to load their own PIN keys.



Note: A single processing institution may process transactions for more than one acquiring bank, and each acquiring bank may mandate their own PIN keys. It is absolutely necessary to not simply rely on obtaining a PIN key that works with your processing institution, but also one that works for the specific acquiring bank. Only your merchant account provider can assist you with identifying who your acquiring bank is and what PIN key identifier should be used.

If Point to Point Encryption is also desired, it is necessary to have your key injection facility also load that key into your device and enable the appropriate encryption support in the software to utilize the key before shipping the device. One notable exception is First Data's RSA TransArmor on Ingenico RBA devices does not need to be loaded as UniTerm can load the appropriate keys itself. If using CardShield encryption, it is necessary to have first

shared a Base Derivation Key with your key injection facility from your instance of Monetra, in order for them to be able to load the key into your device and enable the support before shipping.

Some device distributors that provide loading and key injection facilities are listed below in alphabetical order:

- JRS POS Depot
- The Phoenix Group
- POS Portal
- Scan Source
- TASQ

10 Certifications and Device Configurations

10.1. Certification List 58
 10.2. Configuration Definitions 60

10.1 Certification List

EMV Certifications are tied to specific device versions, device configurations, and software versions. During deployment, it is crucial that only certified configurations are used.

Device configurations are based on the EMV kernel version in the device. The available configurations are listed as part of the EMV LOA (Letter of Approval) for the Level 2 kernel for the device. The approval letters can be obtained from EMVCO: <http://www.emvco.com/approvals.aspx?id=85>

Device	EMVKern/Conf	UniTerm	Module Version	Config
Chase Paymentech				
Ingenico iPP320 CPX	4.66/3C	8.0 only (not supported on 8.2)	Paymentech Tampa 3.2.0 (Done Jan 2015)	Canada, Attended, OfflinePin, Sig
Verifone vx805	6.2.0/1C	8.0+	Paymentech Tampa 3.2.0 (Done Nov 2015)	USA, Attended, OnlinePin, OfflinePin, Sig
Ingenico RBA family	4.67/1C	8.0+	Paymentech Tampa 3.2.0 (Done Feb 2016)	USA, Attended, OnlinePin, OfflinePin, Sig
Moneris				
Ingenico iPP320 CPX	4.66/3C	8.0 only (not supported on 8.2)	Moneris SPDH 2.0.0 (Done Oct 2015)	Canada, Attended, OfflinePin, Sig
Ingenico iUN uCPX	4.66/15C	8.0 only (not supported on 8.2)	Moneris SPDH 2.0.0 (Done Oct 2015)	Canada, Unattended, OfflinePin, NoSig
First Data				
Ingenico RBA family	4.67/1C	8.3+	First Data Cardnet or Nashville EDC 4.1.1 (Done Feb 2017)	USA, Attended, OnlinePin, OfflinePin, Sig, EMV Debit, EMV Contactless


Certifications and
Device Configurations

Device	EMVKern/Conf	UniTerm	Module Version	Config
Ingenico RBA family	4.67/1C	8.0+	First Data Cardnet or Nashville EDC 4.1.0 (Done Jan 2016)	USA, Attended, OnlinePin, OfflinePin, Sig
Verifone vx805	6.2.0/1C	8.0+	First Data Cardnet or Nashville EDC 4.1.0 (Done Feb 2016)	USA, Attended, OnlinePin, OfflinePin, Sig
Tsys				
Ingenico RBA family	4.67/1C	8.0+	TSYS (aka Vital/VisaNet) 3.0.0 (Done Feb 2016)	USA, Attended, OnlinePin, OfflinePin, Sig
Global Payments				
Ingenico RBA family	4.67/1C	8.0+	Global Payments East 3.0.0 (Done Nov 2015)	USA, Attended, OnlinePin, OfflinePin, Sig
Verifone vx805	6.2.0/1C	8.0+	Global Payments East 3.0.0 (Done Nov 2015)	USA, Attended, OnlinePin, OfflinePin, Sig
WorldPay				
Ingenico RBA family	4.67/1C	8.0+	RBS WorldPay TCMP 2.0.0 (Done Feb 2016)	USA, Attended, OnlinePin, OfflinePin, Sig
Vantiv				
Ingenico RBA family	4.67/1C	8.0+	Vantiv/FifthThird 610 2.1.0 (Done Jan 2016)	USA, Attended, OnlinePin, OfflinePin, Sig

10.2 Configuration Definitions

EMV configurations are strictly certified in an "all or nothing" manner. You must choose an explicit certification from the list in the prior section and all configuration parameters must be adhered to. For instance, if the certification lists both `OnlinePin` and `OfflinePin`, you cannot simply choose to support only `OfflinePin`.

The meanings of the various configurations listed in the prior section are below:

Key	Description
USA	Certified for use in the United States
Canada	Certified for use in Canada
Attended	The environment is monitored by a clerk such as Retail, Restaurant, or Lodging. Not usable in a Kiosk environment such as a parking meter or gas pump.
Unattended	The environment is NOT monitored by a clerk, for use in kiosk type environments.
OnlinePin	<p>An encrypted PIN can be obtained from a cardholder and sent to the processor with the transaction. When supporting Online PIN it is required that the device be injected with a 3DES DUKPT PIN key specific to the processing institution in use prior to deployment by a merchant.</p> <div style="background-color: #f0f0f0; padding: 5px; margin-top: 10px;">  <p>Note: <code>OnlinePin</code> may not be supported for all card brands of a given processing institution. UniTerm will automatically adjust support for the processor's card brand limitations where necessary.</p> </div>
OfflinePin	The terminal will negotiate the PIN directly with the chip embedded into the card without the need to send the PIN to the processing institution. A terminal does not need a Pin Debit key injected into it if only <code>OfflinePin</code> (and not <code>OnlinePin</code>) is supported.
Sig	Signature cardholder verification is supported. This may either be a signature capture capable device or a signature obtained via paper receipt.

A UniTerm Device Loading

When loading a device with UniTerm, UniTerm will send Monetra a list of terminal configurations from the Letter of Approval (LOA) as provided by device manufacturer for the device's EMV kernel. Monetra will compare this list to merchant defined settings. Monetra will then select a usable LOA configuration and return to UniTerm loading data which has been merged with the merchant's settings.

Some terminal loading data is mandatory and cannot deviate from a LOA configuration. Other data is merchant configurable and is allowed to be changed. Data that is configurable will be merged into an LOA configuration by Monetra based on the merchant's settings.

In the event no LOA configuration is valid for the merchant's settings then Monetra will respond with an error. Also, If the device's EMV kernel version is not certified for use with UniTerm loading will result in an error.

After a successful load the integration must check `altered_termload`. If it is "yes" then not all of the merchant's settings could be used and some of the values have been ignored. The integration can compare the selected values with the `*_desired` and `*_loa` values to determine what was ignored. It is the choice of the integration to either accept the load with the selected values or return an error if the merchant's setting have been altered due to being unsupported by the devices LOA configurations.



Note: If using implicit/auto device loading and not calling `u_action=device_load` directly, an integrator will have no ability to retrieve the `device_load` parameters.

PARAMETER	OVERVIEW
<code>altered_termload</code>	If no LOA configuration matches the merchant's settings a valid LOA will be used and the merchant's settings will be overridden. This indicates this has happened.
<code>termtype_desired</code>	The terminal type Monetra has determined fits the merchant's settings.
<code>termcaps_desired</code>	Terminal capabilities configured in Monetra. These are features that the merchant has selected for use.
<code>addltermcaps_desired</code>	Additional terminal capabilities configured in Monetra. These are features that the merchant has selected for use.
<code>termcaps_loa</code>	Terminal capabilities from the LOA configuration Monetra has selected.
<code>addltermcaps_loa</code>	Additional terminal capabilities from the LOA configuration Monetra has selected.
<code>loa_id</code>	The LOA configuration id Monetra has selected for use. This is the id in the device certification document for the kernel version located at: http://www.emvco.com/approvals.aspx?id=85
<code>termtype</code>	The terminal type from the LOA configuration that will be loaded into the device.

UniTerm Device Loading

termcaps	Terminal capabilities from the merged LOA configuration and merchant's settings that will be loaded into the device. Note: mandatory LOA configuration data will not be changed.
addltermcaps	Additional terminal capabilities from the merged LOA configuration and merchant's settings that will be loaded into the device. Note: mandatory LOA configuration data will not be changed.

Example device load response:

```
u_errorcode = SUCCESS
code = AUTH
verbiage = Device loaded
altered_termload = no
termtype_desired = 21
termcaps_desired = E0B8C8
addltermcaps_desired = 6000F0F001
termcaps_loa = 60B8C8
addltermcaps_loa = 6000F0A001
loa_id = 18C
termtype = 22
termcaps = E0B8C8
addltermcaps = 6000F0F001
```

B EMV Receipt Requirements

The UniTerm application never generate receipts. It is the integrator's responsibility to generate all proper receipts for both customer and merchant retention. What constitutes a proper receipt is dependent on a number of factors such as industry, card present vs card not present, and card entry method (for card present).

The purpose of this section is to provide general information about the receipt data UniTerm will return and how to use it generate a receipt. This does not cover all aspects of receipt generation. It also does not cover processor specific formatting requirements. It is recommended to verify receipts and receipt formatting with your processor before going into production.

Also there are typically two types of receipts printed. A merchant and a customer copy. Each one will have most of the same information but there are slight differences between the two.

B.1 Receipt content

B.1.1 Base receipt content

Receipts should include the following blocks and data elements in roughly the order provided below. All data is required if returned by UniTerm, or otherwise available, unless otherwise noted.

- Merchant Info Header
 - Name - `merch_name`
 - Address - `merch_addr1`, `merch_addr2`, `merch_addr3`
 - Phone (optional) - `merch_phone`
 - Email (optional) - `merch_email`
 - Website (optional) - `merch_url`
 - Merchant ID - required by some processors. Recommended to omit or truncate, see `merch_id` response documentation for more information.
 - Lane ID (optional) - `laneid` or `stationid` request parameter.
- Transaction type - request parameter `action` or equivalent text
- Card information
 - Type - `cardtype`
 - Entry mode - `rcpt_entry_mode` - or equivalent text, some processors may have explicit mappings they require.
 - Interac Account Type - `rcpt_acct_type` or for Interac Flash (contactless) transactions, must display `INTERAC FLASH DEFAULT`. Integrators must convert the UniTerm-returned value of `checking` to `chequing` to comply with Interac requirements.
 - Masked Account Number - `account`
- Transaction reference info
 - Date and time - `rcpt_host_ts` or `timestamp`
 - Identifier - request parameters `ordernum` or `ptransnum`
 - Additional identifiers (optional) - request parameters such as `custref`
 - `ttid` (optional) - either request or response `ttid`
 - Batch number - `batch`

- Auth number (if authorized) - `auth`
- Trace information - `stan`
- Processor response code (some processors may require this) - `rcpt_resp_code`
- Issuer response code (some processors may require this) - `rcpt_issuer_resp_code`
- Processor specific custom data - see `rcpt_custom`
- Monetary amounts
 - Tip - Request parameter `examount`
 - Tax - Request parameter `tax`
 - Cash back - Request parameter `cashbackamount`
 - Authorized Amount - `authamount` if returned, otherwise request parameter `amount`
 - Balance - `balance`
- Transaction disposition
 - Card disposition - See Card Disposition documentation
 - Partial Approval Indicator - if `authamount` returned
 - Overall disposition (approved/declined) - `code`
- Additional Print Data - `printdata`, Additional data meant to be printed on the receipt as provided by the processor. Often used for gift/loyalty programs.
- Cardholder Verification
 - Signature line (if necessary) - `u_need_signature=yes`
 - Cardholder Name, centered under signature line if a signature line is shown (optional) - `cardholdername`
- EMV data
 - Application name - `rcpt_emv_name`
 - AID - `rcpt_emv_aid`
 - TVR - `rcpt_emv_tvr`
 - TSI - `rcpt_emv_tsi`
 - Application Cryptogram Type and Cryptogram Value (optional) - `rcpt_emv_actype` and `rcpt_emv_ac`
- Cardholder Notice (such as stating merchant vs customer copy) (optional) - see receipt examples

B.2 Receipt Data Returned by UniTerm

PARAMETER	OVERVIEW
<code>timestamp</code>	Unix timestamp representing the time and date the transaction took place, this should be used to derive the transaction date if <code>rcpt_host_ts</code> is not returned.
<code>rcpt_host_ts</code>	(REQUIRED): The time and date recorded from the processor the transaction took place. MMDDYYHHMMSS format. Use <code>timestamp</code> if this value is not present in the response.
<code>rcpt_entry_mode</code>	(REQUIRED): Indicates how the card data was captured. Possible values are: <ul style="list-style-type: none"> • G: Keyed entry (EMV Fallback) • M: Keyed entry • T: EMV Contactless

EMV Receipt Requirements

	<ul style="list-style-type: none"> • C: EMV Contact • F: Swipe (EMV Fallback) • R: MSD (RFID) Contactless • S: Swipe • I: MICR Check Read
rcpt_acct_type	Interac specific account type chosen by the customer.
rcpt_emv_cvm	<p>For EMV transactions this is the cardholder verification method performed. Possible values are:</p> <ul style="list-style-type: none"> • none • sig • pin • pinsig • skipped - Used for some contactless transactions below the CVM floor. • cdsvm - Card Holder Device verification. The user's device (usually smart phone) validated the user's identity. • unknown <p>For "pin" and "pinsig" the receipt should say "VERIFIED BY PIN". For "sig" a signature should be captured.</p>
rcpt_resp_code	Response code returned from the processing institution.
rcpt_issuer_resp_code	Response code returned from the issuer.
language	Cardholder's language preference. The receipt should be created using this language if possible and shall contain the 2 character ISO language code.
batch	The batch number associated with the transaction.
cardtype	Monetra cardtype value. This is the value that would have been configured in supported card types for the account. Use this to take card specific action in receipt generation.
balance	Current balance on the card after the transaction.
rcpt_emv_aid	Card Application ID (AID) used
rcpt_emv_name	Textual name of card application used.
rcpt_emv_tvr	Transaction verification results.
rcpt_emv_tsi	Transaction status information.

EMV Receipt Requirements

rcpt_emv_actype	(optional). Application Cryptogram type. <ul style="list-style-type: none"> • AAC - Application Authentication Cryptogram (decline) • ARQC - Application Request Cryptogram (intermediate or contactless) • TC - Transaction Certificate (offline or final approval)
rcpt_emv_ac	(optional). Application Cryptogram.
code	Used to determine if the transaction was approved or declined.
account	Masked account number.
cardholdername	Customers name as encoded on the card.
auth	Authorization code.
stan	Processor system trace information (mainly used for pin-debit transactions).
authamount	If the amount authorized is different than the requested amount this is the amount that must show on the receipt. It is possible that the integration could pool multiple transactions on one receipt and in that case the authamount needs to be present for each card along with other card specific receipt data. Note that some processors do not allow pooling card data onto one receipt and require separate receipts per card.
rcpt_custom	List of comma separated key:value pairs with additional processor specific data that needs to appear on the receipt.
u_errorcode	On failure this will provide some information about the failure. Specifically important to receipt processing are the EMV_CARD_REMOVED and EMV_CARD_DENY values.
u_need_signature	Used to determine if a signature line is required.
printdata	Additional processor-provided data returned by some processors that is intended to be printed on receipts. Often used for Gift/Loyalty programs. Please consult with your processor for more information.
issuer_decline	Boolean (yes/no). Currently this value is only returned by Moneris, and is used to indicate if a decline was due to an issuer decline or a local processor decline. The purpose of this response

EMV Receipt Requirements

	parameter is that <code>Moneris</code> has different receipt messaging requirements based on who declined the transaction.
<code>merch_name</code>	Merchant Name if configured in merchant profile. Cached by UniTerm from <code>merchinfo</code> request and sent on every transaction response.
<code>merch_addr1</code>	Merchant Address Line 1 if configured in merchant profile. Cached by UniTerm from <code>merchinfo</code> request and sent on every transaction response.
<code>merch_addr2</code>	Merchant Address Line 2 if configured in merchant profile. Cached by UniTerm from <code>merchinfo</code> request and sent on every transaction response.
<code>merch_addr3</code>	Merchant Address Line 3 if configured in merchant profile. Cached by UniTerm from <code>merchinfo</code> request and sent on every transaction response.
<code>merch_phone</code>	Merchant Phone Number if configured in merchant profile. Cached by UniTerm from <code>merchinfo</code> request and sent on every transaction response.
<code>merch_email</code>	Merchant Contact Email if configured in merchant profile. Cached by UniTerm from <code>merchinfo</code> request and sent on every transaction response.
<code>merch_url</code>	Merchant URL or Website if configured in merchant profile. Cached by UniTerm from <code>merchinfo</code> request and sent on every transaction response.
<code>merch_id</code>	Merchant ID truncated to only the last 4 digits if available. Cached by UniTerm from <code>merchinfo</code> request and sent on every transaction response. The Merchant ID is required by some processors for EMV, though due to rampant "return fraud", we strongly discourage integrators from providing the full Merchant ID on receipts. Instead, if you choose to display the merchant id, it should display only the last 4 digits. This field can be used for that purpose.
<code>merch_proc</code>	Merchant Processing Institution (internal name) used. Cached by UniTerm from <code>merchinfo</code> request and sent on every transaction response. This may be used to trigger different

	receipt formats based on processor-specific requirements.
--	---

B.3 Receipt Data NOT Returned by UniTerm

This is information is data that may have been sent to UniTerm on the request that should be on the receipt.

PARAMETER	OVERVIEW
Transaction Type	The initiating application should know which transaction type is being preformed (Sale, Refund etc.).
Transaction Identifier	ordernum or ptrannum if present.
Additional Identifier	custref if present.
ttid	When performing a transaction such as return by ttid the referenced ttid should be present on the receipt. This will aid in tracking the original transaction that was returned.
Amount Information	<ul style="list-style-type: none"> • Tip - Tip amount for order as provided in the examount field in request. • Tax - Tax amount for order • Amount - Authorized amount, either the amount passed in or the partially approved amount provided in the authamount field. • Cash Back Amount - Amount of Cash Back
Card Disposition	<ul style="list-style-type: none"> • When u_errorcode is EMV_CARD_REMOVED, should say: "CARD REMOVED" • When u_errorcode is EMV_CARD_DENY, should say: "DECLINED BY CARD" • When rcpt_emv_cvm is pin or pinsig, should say: "VERIFIED BY PIN" • When rcpt_entry_mode is F or G, should say: "CHIP CARD SWIPED" • When authamount is returned and is not equal to requested amount, should say: "TRANSACTION PARTIALLY APPROVED" • When code is CALL, should say: "CALL ISSUER"

B.4 Signature Line Requirements

The only time a signature line is necessary when using UniTerm is when u_need_signature=yes. Internally UniTerm will handle logic to determine if the signature line is needed on the paper receipt.

When set to yes this indicates that a signature line is required on the receipt. If possible UniTerm will attempt to capture the signature thought the device. If this fails or is not possible then this value will indicate that signature is still required.

B.5 Merchant vs Customer Copy

For the most part merchant and customer receipt requirements are identical, though there are a couple of minor exceptions.

Merchant receipts must NOT contain a balance line

Customer receipt must not contain a signature line

B.6 Moneris Requirements

Moneris has additional receipt requirements that are not covered by this section due to direct contradictions with requirements as provided by other processing institutions and the card brands themselves. The receipt requirements documented are insufficient to comply with Moneris requirements but do comply with the card brand requirements. The additional requirements imposed are specific to Moneris and appear to be arbitrary, a large enough merchant might be able to negotiate different receipt formats since there is no industry regulation being followed.

If intending to work with Moneris, it is required that integrators create a custom receipt template specific to Moneris that is used only on Moneris, and a separate template that is used for all other processors. Integrators must contact Moneris directly to receive their receipt formatting requirements. UniTerm does return sufficient data to format the Moneris-specific receipts, it simply may require some data to be manipulated, formatted, or translated to different languages to comply with their requirements.

B.7 Receipt Examples

Main Street successfully certified EMV, across several processors, using the examples provided below. Note these examples were designed to format properly on a common 25 character receipt printer.



Note: Receipt requirements required for the card brands for EMV and various processors tend to be very strict. We strongly recommend integrators make their receipts resemble those of the examples as closely as possible. Any divergence from the receipt examples provided below may require you seek validation of such receipts from your processor.

B.7.1 EMV Insert, Signature Required

B.7.1.1 UniTerm Response Data

PARAMETER	VALUE
account	XXXXXXXXXXXX0119
auth	152013
batch	1
cardholdername	VISA ACQUIRER TEST/CARD 01

EMV Receipt Requirements

cardlevel	VISA_TRADITIONAL
cardtype	VISA
code	AUTH
item	27
language	en
merch_addr1	123 STREET NAME
merch_addr2	CITY, STATE ZIP
merch_id	1834
merch_name	MERCHANT NAME
merch_phone	(888) 555-1234
merch_proc	GLOBALPAY
msoft_code	INT_SUCCESS
pcllevel	0
phard_code	SUCCESS
rcpt_custom	REC #:000027,TRN REF #:355724280069888,VAL CODE:BBCD
rcpt_emv_ac	8F73ED36C8F2C099
rcpt_emv_actype	TC
rcpt_emv_aid	A0000000031010
rcpt_emv_cvm	sig
rcpt_emv_name	CREDITO DE VISA
rcpt_emv_tsi	F800
rcpt_emv_tvr	0280008000
rcpt_entry_mode	C
rcpt_host_ts	092215174640
rcpt_issuer_resp_code	00
rcpt_resp_code	000
stan	378222
timestamp	1442944083
ttid	29
u_errorcode	SUCCESS
u_need_signature	yes
verbiage	AP

B.7.1.2 Example Receipt

MERCHANT NAME 123 STREET NAME

EMV Receipt Requirements

CITY, STATE ZIP
(888) 555-1234

SALE

MID: 1834 Lane: 1
VISA C
Card: XXXXXXXXXXXXX0119
Time: 09/22/15 17:46:40
Order #: 1842
TTID: 29
RespCode: 00/000
Auth: 152013 Batch: 1
STAN: 378222
REC #: 000027
TRN REF #:355724280069888
VAL CODE: BCD

AMOUNT: 1.00

APPROVED

SIGNATURE

X

VISA ACQUIRER TEST/CARD
01

CARDHOLDER WILL PAY CARD
ISSUER ABOVE AMOUNT
PURSUANT TO CARDHOLDER
AGREEMENT

CREDITO DE VISA
AID A0000000031010
TVR 0280008000
TSI F800
TC 8F73ED36C8F2C099

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

MERCHANT COPY

MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

SALE

MID: 1834 Lane: 1
VISA C
Card: XXXXXXXXXXXXX0119
Time: 09/22/15 17:46:40
Order #: 1842
TTID: 29
RespCode: 00/000
Auth: 152013 Batch: 1
STAN: 378222
REC #: 000027
TRN REF #:355724280069888

EMV Receipt Requirements

VAL CODE: BBCD

AMOUNT: 1.00

APPROVED

CREDITO DE VISA

AID A0000000031010

TVR 0280008000

TSI F800

TC 8F73ED36C8F2C099

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

CUSTOMER COPY

B.7.2 EMV Insert, PIN Verified**B.7.2.1 UniTerm Response Data**

PARAMETER	VALUE
account	XXXXXXXXXXXX0036
auth	602664
batch	1
cardholdername	VISA ACQUIRER TEST/CARD 03
cardlevel	VISA_TRADITIONAL
cardtype	VISA
code	AUTH
item	7
language	en
merch_addr1	123 STREET NAME
merch_addr2	CITY, STATE ZIP
merch_id	1834
merch_name	MERCHANT NAME
merch_phone	(888) 555-1234
merch_proc	GLOBALPAY
msoft_code	INT_SUCCESS
pcllevel	0
phard_code	SUCCESS
rcpt_custom	REC #:000007,TRN REF #:638114437174992,VAL CODE:BBCD
rcpt_emv_ac	2F0346EBCA494BF4
rcpt_emv_actype	TC
rcpt_emv_aid	A0000000031010
rcpt_emv_cvm	pin
rcpt_emv_name	CREDITO DE VISA
rcpt_emv_tsi	F800
rcpt_emv_tvr	0080008000
rcpt_entry_mode	C
rcpt_host_ts	092215172258
rcpt_issuer_resp_code	00
rcpt_resp_code	000
stan	563536

EMV Receipt Requirements

timestamp	1442942662
ttid	7
u_errorcode	SUCCESS
verbiage	AP

B.7.2.2 Example Receipt

```
MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

SALE

MID: 1834          Lane: 1
VISA              C
Card:  XXXXXXXXXXXX0036
Time:  09/22/15 17:22:58
Order #:          5705
TTID:            7
RespCode:        00/000
Auth: 602664     Batch: 1
STAN:           563536
REC #:          000007
TRN REF #:638114437174992
VAL CODE:        BBCD

AMOUNT:          337.00

VERIFIED BY PIN

APPROVED

CREDITO DE VISA
AID A0000000031010
TVR 0080008000
TSI F800
TC 2F0346EBCA494BF4

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

MERCHANT COPY

-----

MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

SALE

MID: 1834          Lane: 1
VISA              C
Card:  XXXXXXXXXXXX0036
Time:  09/22/15 17:22:58
Order #:          5705
TTID:            7
RespCode:        00/000
```

EMV Receipt Requirements

Auth: 602664 Batch: 1
STAN: 563536
REC #: 000007
TRN REF #:638114437174992
VAL CODE: BCD

AMOUNT: 337.00

VERIFIED BY PIN

APPROVED

CREDITO DE VISA
AID A0000000031010
TVR 0080008000
TSI F800
TC 2F0346EBCA494BF4

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

CUSTOMER COPY

B.7.3 EMV Insert, No CVM**B.7.3.1 UniTerm Response Data**

PARAMETER	VALUE
account	XXXXXXXXXXXX1005
auth	232508
batch	1
cardholdername	AEIPS 32/VER 1.0
cardtype	AMEX
code	AUTH
item	2
language	en
merch_addr1	123 STREET NAME
merch_addr2	CITY, STATE ZIP
merch_id	1836
merch_name	MERCHANT NAME
merch_phone	(888) 555-1234
merch_proc	GLOBALPAY
msoft_code	INT_SUCCESS
pcllevel	0
phard_code	SUCCESS
rcpt_custom	REC #:000002,TRN REF #:416237190201752
rcpt_emv_ac	5C221DC28EB72FCF
rcpt_emv_actype	TC
rcpt_emv_aid	A000000025010801
rcpt_emv_cvm	none
rcpt_emv_name	AMERICAN EXPRESS
rcpt_emv_tsi	F800
rcpt_emv_tvr	0000008000
rcpt_entry_mode	C
rcpt_host_ts	092515194045
rcpt_issuer_resp_code	000
rcpt_resp_code	000
stan	000514
timestamp	1443210133

EMV Receipt Requirements

ttid	79
u_errorcode	SUCCESS
verbiage	AP

B.7.3.2 Example Receipt

```
MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

SALE

MID: 1836          Lane: 1
AMEX                C
Card:              XXXXXXXXXXXX1005
Time:              09/25/15 19:40:45
Order #:           41
TTID:              79
RespCode:          000/000
Auth: 232508      Batch: 1
STAN:              000514
REC #:             000002
TRN REF #:416237190201752

AMOUNT:            62.00

APPROVED

AMERICAN EXPRESS
AID A000000025010801
TVR 0000008000
TSI F800
TC 5C221DC28EB72FCF

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

MERCHANT COPY

-----

MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

SALE

MID: 1836          Lane: 1
AMEX                C
Card:              XXXXXXXXXXXX1005
Time:              09/25/15 19:40:45
Order #:           41
TTID:              79
RespCode:          000/000
Auth: 232508      Batch: 1
STAN:              000514
REC #:             000002
TRN REF #:416237190201752
```

EMV Receipt Requirements

AMOUNT: 62.00

APPROVED

AMERICAN EXPRESS
AID A000000025010801
TVR 0000008000
TSI F800
TC 5C221DC28EB72FCF

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

CUSTOMER COPY

B.7.4 EMV Insert, Card Decline

B.7.4.1 UniTerm Response Data

PARAMETER	VALUE
account	XXXXXXXXXXXX0010
cardtype	VISA
code	DENY
merch_addr1	123 STREET NAME
merch_addr2	CITY, STATE ZIP
merch_id	1834
merch_name	MERCHANT NAME
merch_phone	(888) 555-1234
merch_proc	GLOBALPAY
rcpt_emv_ac	BA9BD3FAC8ADD6C7
rcpt_emv_actype	AAC
rcpt_emv_aid	A0000000031010
rcpt_emv_cvm	pin
rcpt_emv_name	CREDITO DE VISA
rcpt_emv_tsi	E800
rcpt_emv_tvr	0280A08000
rcpt_entry_mode	C
rcpt_host_ts	092215134154
u_errorcode	EMV_CARD_DENY
verbiage	Transaction aborted - declined by card

B.7.4.2 Example Receipt

```

MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

SALE

MID: 1834          Lane: 1
VISA              C
Card:  XXXXXXXXXXXX0010
Time:  09/22/15 13:41:54
Order #:          17421

AMOUNT:          22.00
    
```

EMV Receipt Requirements

```
DECLINED BY CARD
VERIFIED BY PIN

DECLINED

CREDITO DE VISA
AID A0000000031010
TVR 0280A08000
TSI E800
AAC BA9BD3FAC8ADD6C7

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

MERCHANT COPY

-----

MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

SALE

MID: 1834 Lane: 1
VISA C
Card: XXXXXXXXXXXXX0010
Time: 09/22/15 13:41:54
Order #: 17421

AMOUNT: 22.00

DECLINED BY CARD
VERIFIED BY PIN

DECLINED

CREDITO DE VISA
AID A0000000031010
TVR 0280A08000
TSI E800
AAC BA9BD3FAC8ADD6C7

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

CUSTOMER COPY
```

B.7.5 EMV Insert, Card Removed (Decline)

B.7.5.1 UniTerm Response Data

PARAMETER	VALUE
code	DENY
merch_addr1	123 STREET NAME
merch_addr2	CITY, STATE ZIP
merch_id	1818
merch_name	MERCHANT NAME
merch_phone	(888) 555-1234
merch_proc	GLOBALPAY
u_errorcode	EMV_CARD_REMOVED
verbiage	Card Removed

B.7.5.2 Example Receipt

```

MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

      SALE

MID: 1818           Lane: 1
Time: 09/24/15 14:43:46
Order #:           6224

AMOUNT:           1.00

      CARD REMOVED

      DECLINED

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

      MERCHANT COPY

-----

MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

      SALE

MID: 1818           Lane: 1
Time: 09/24/15 14:43:46
Order #:           6224
    
```

EMV Receipt Requirements

AMOUNT: 1.00

CARD REMOVED

DECLINED

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

CUSTOMER COPY

B.7.6 EMV Insert, Interac**B.7.6.1 UniTerm Response Data**

PARAMETER	VALUE
account	XXXXXXXXXXXX1933
auth	175180
avs	UNKNOWN
batch	1
cardholdername	Test Card 1
cardtype	INTERAC
code	AUTH
item	10
language	en
merch_addr1	123 STREET NAME
merch_addr2	CITY, STATE ZIP
merch_id	3636
merch_name	MERCHANT NAME
merch_phone	(888) 555-1234
merch_proc	PAYMENTECH
msoft_code	INT_SUCCESS
pcllevel	0
phard_code	SUCCESS
rcpt_acct_type	checking
rcpt_emv_ac	882D8427A268E214
rcpt_emv_actype	TC
rcpt_emv_aid	A0000002771010
rcpt_emv_cvm	pin
rcpt_emv_name	Interac
rcpt_emv_tsi	7800
rcpt_emv_tvr	8000008000
rcpt_entry_mode	C
rcpt_host_ts	092515155118
rcpt_resp_code	A
stan	00298722
timestamp	1443210676

EMV Receipt Requirements

ttid	10
u_errorcode	SUCCESS
verbiage	APPROVED

B.7.6.2 Example Receipt

```
MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

      SALE

MID: 3636          Lane: 1
INTERAC           C
Acct Type:        CHEQUING
Card:             XXXXXXXXXXXXX1933
Time:             09/25/15 15:51:18
Order #:          899065992
TTID:             10
RespCode:         A
Auth: 175180      Batch: 1
STAN:             00298722

AMOUNT:           5.01

      VERIFIED BY PIN

      APPROVED

Interac
AID A0000002771010
TVR 8000008000
TSI 7800
TC 882D8427A268E214

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

      MERCHANT COPY

-----

      MERCHANT NAME
      123 STREET NAME
      CITY, STATE ZIP
      (888) 555-1234

            SALE

MID: 3636          Lane: 1
INTERAC           C
Acct Type:        CHEQUING
Card:             XXXXXXXXXXXXX1933
Time:             09/25/15 15:51:18
Order #:          899065992
TTID:             10
RespCode:         A
Auth: 175180      Batch: 1
STAN:             00298722
```

EMV Receipt Requirements

AMOUNT: 5.01

VERIFIED BY PIN

APPROVED

Interac

AID A0000002771010

TVR 8000008000

TSI 7800

TC 882D8427A268E214

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

CUSTOMER COPY

B.7.7 EMV Contactless, Interac Flash Decline**B.7.7.1 UniTerm Response Data**

PARAMETER	VALUE
account	XXXXXXXXXXXXXXXXX1311
cardtype	INTERAC
code	DENY
issuer_decline	yes
language	en
merch_addr1	123 STREET NAME
merch_addr2	CITY, STATE ZIP
merch_id	1625
merch_name	MERCHANT NAME
merch_phone	(888) 555-1234
msoft_code	INT_SUCCESS
phard_code	GENERICFAIL
printdata	CARD CANCELLED*REFER TO BRANCH
rcpt_acct_type	flash
rcpt_custom	refnum:660136000010016710
rcpt_emv_ac	ED538D29D3390729
rcpt_emv_actype	ARQC
rcpt_emv_aid	A0000002771010
rcpt_emv_cvm	unknown
rcpt_emv_name	Interac
rcpt_emv_tvr	0080008000
rcpt_entry_mode	T
rcpt_host_ts	072015180303
rcpt_issuer_resp_code	05
rcpt_resp_code	058
sequenceid	671
timestamp	1437429783
ttid	861
u_errorcode	MONETRA_ERROR
verbiage	DECLINED * CARD CANCELLED

B.7.7.2 Example Receipt

```
MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

SALE

MID: 1625           Lane: 1
INTERAC           T
Acct Type: FLASH DEFAULT
Card: XXXXXXXXXXXXXXXX1311
Date/Time: 072015180303
Order #: 899065992
TTID: 861
refnum:660136000010016710

AMOUNT:           1.09

DECLINED

Interac
AID A0000002771010
TVR 0080008000
ARQC ED538D29D3390729

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS

MERCHANT/CUSTOMER COPY
```

B.7.8 EMV Contactless, Decline**B.7.8.1 UniTerm Response Data**

PARAMETER	VALUE
account	XXXXXXXXXXXX0010
cardholdername	ETEC/PAYPASS
cardtype	MC
code	DENY
language	en
merch_addr1	123 STREET NAME
merch_addr2	CITY, STATE ZIP
merch_id	1625
merch_name	MERCHANT NAME
merch_phone	(888) 555-1234
msoft_code	INT_SUCCESS
phard_code	GENERICFAIL
rcpt_custom	refnum:660136000010016700
rcpt_emv_ac	16D1284D85A29DF2
rcpt_emv_actype	ARQC
rcpt_emv_aid	A0000000041010
rcpt_emv_cvm	none
rcpt_emv_name	PPC MCD 01 v2 2
rcpt_emv_tvr	0000008000
rcpt_entry_mode	T
rcpt_issuer_resp_code	51
rcpt_resp_code	481
sequenceid	670
timestamp	1437429662
ttid	860
u_errorcode	MONETRA_ERROR
verbiage	DECLINED *

B.7.8.2 Example Receipt

```

MERCHANT NAME
123 STREET NAME
CITY, STATE ZIP
(888) 555-1234

```

EMV Receipt Requirements

SALE
MID: 1625 Lane: 1
MC T
Card: XXXXXXXXXXXXX0010
Date/Time: 072015180102
Order #: 899065992
TTID: 860
refnum:660136000010016700
AMOUNT: 10.51

DECLINED
PPC MCD 01 v2 2
AID A0000000041010
TVR 0000008000
ARQC 16D1284D85A29DF2

IMPORTANT - RETAIN THIS
COPY FOR YOUR RECORDS
MERCHANT/CUSTOMER COPY

C UniTerm Code Examples

C.1 Microsoft C# using libmonetra

```
1  /* UniTerm example program in C#
2  *
3  * Depends on the libmonetra C# .Net native API
4  *
5  * Implemented based on the UniTerm Guide in conjunction with the
6  * Monetra Client Interface Protocol Specification
7  *
8  * Please contact support@monetra.com with any questions
9  */
10 using System;
11 using System.Collections;
12 using System.Diagnostics;
13 using System.IO;
14 using System.Text;
15 using System.Threading;
16 using libmonetra;
17
18 /* NOTE: if compiling with Mono, you can use
19 *       gmcs /unsafe utest.cs libmonetra.cs
20 */
21
22 class UTest {
23     /* Uniterm Connectivity Information
24     * NOTE: this is the default, it is possible to change, but 99%
25     *       of deployments will probably use this Uniterm information
26     *       as-is
27     */
28     private const string uniterm_host    = "localhost";
29     private const int   uniterm_port    = 8123;
30
31     /* Authentication information
32     * NOTE: This information corresponds with the public test server
33     *       at testbox.monetra.com:8665 */
34     private const string monetra_user    = "test_retail:public";
35     private const string monetra_pass   = "publlct3st";
36
37
38     static string uniterm_path()
39     {
40         switch (Environment.OSVersion.Platform) {
41             case PlatformID.Win32NT:
42             case PlatformID.Win32S:
43             case PlatformID.Win32Windows:
44             case PlatformID.WinCE:
45                 return "C:\\Program Files\\Main Street Softworks\\UniTerm\\uniterm.exe";
46             default:
47                 return "/usr/local/uniterm/bin/uniterm";
48         }
49     }
50
51     /*! Function to launch the Uniterm from the current process.
```

```
52  * If we don't launch it from the current process, it won't be given
53  * focus! (at least on Windows this is true, until the first
54  * manual focus is performed by an end-user) */
55  static void uniterm_launch()
56  {
57      Process uniterm                = new Process();
58      uniterm.StartInfo.FileName     = uniterm_path();
59      uniterm.StartInfo.CreateNoWindow = true;
60
61      uniterm.Start();
62
63      /* Make sure Uniterm is ready before returning,
64       * Sleep 1000ms (1s) */
65      System.Threading.Thread.Sleep(1000);
66  }
67
68
69  /*! Function to connect to an endpoint which uses the standard 'monetra'
70   * style protocol (so either Monetra itself, or Uniterm)
71   * \param[in] host      Resolvable hostname or IP address to connect to
72   * \param[in] port      Port associated with hostname to establish an SSL
73   *                      connection to
74   * \param[out] errorstr Textual error message if returns null
75   * \return Initialized connection class on success. null on failure
76   */
77  static Monetra uniterm_connect_host(string host, int port, ref string errorstr)
78  {
79      /* Initialize the Class */
80      Monetra conn = new Monetra();
81
82      errorstr = "";
83
84      /* We always want to use an SSL connection to Monetra and Uniterm */
85      conn.SetSSL(host, port);
86
87      /* Do not verify the SSL certificate, Monetra and the Uniterm
88       * use self-signed certificates by default which cannot be validated.
89       * The connection is still encrypted, the endpoint just isn't strictly
90       * validated */
91      conn.VerifySSLCert(false);
92
93      /* This makes it so TransSend() will block until a response is
94       * received from Monetra. Simplifies the API since we will never
95       * have more than one outstanding transaction per connection in
96       * this application */
97      conn.SetBlocking(true);
98
99      /* Connect! */
100     if (!conn.Connect()) {
101         errorstr = conn.ConnectionError();
102         return null;
103     }
104
105     return conn;
106 }
107
108
109 /*! Wrapper function to connect to Uniterm
```

```

110  * \param[out] errorstr Textual error message if returns null
111  * \return Initialized connection class on success. null on failure
112  */
113  static Monetra uniterm_connect(ref string errorstr)
114  {
115      Monetra conn;
116      string myerror = "";
117      conn = uniterm_connect_host(uniterm_host, uniterm_port, ref myerror);
118      if (conn == null) {
119          errorstr = "Connection to Uniterm Failed: " + myerror;
120      }
121      return conn;
122  }
123
124
125  /*! Request a transaction from Uniterm as documented in the Uniterm Guide.
126  * The Key/Value pair params are a combination of the Parameters as
127  * documented in the Uniterm Guide and the Monetra Client Interface
128  * Protocol Spec.
129  * \param[in] uniterm_conn Initialized connection to Uniterm
130  * as returned by uniterm_connect()
131  * \param[in] mparams Array of key/value parameters to send to
132  * Uniterm
133  * \return Hashtable of string key/value pairs from response. Please refer
134  * to the Uniterm Guide and Monetra Client Interface Protocol
135  * specification for the applicable list based on the action being
136  * performed. "code" and "u_errorcode" are always guaranteed to
137  * be returned.
138  */
139  static Hashtable uniterm_sendrequest(Monetra uniterm_conn, Hashtable mparams)
140  {
141      int id;
142
143      Hashtable response = new Hashtable();
144
145      /* Request a new transaction from libmonetra */
146      id = uniterm_conn.TransNew();
147
148      /* For each item in the params hashtable, add it to the transaction */
149      foreach (DictionaryEntry kv in mparams) {
150          uniterm_conn.TransKeyVal(id, (String)kv.Key, (String)kv.Value);
151      }
152
153      /* Send the request to the Uniterm. It will not return until
154      * a response is available, or a disconnect is detected */
155      if (!uniterm_conn.TransSend(id)) {
156          /* Disconnect detected, return an appropriate error condition!
157          * This should really never happen though... */
158          response["code"] = "DENY";
159          response["u_errorcode"] = "CONN_ERROR";
160          response["verbiage"] = "Connection to Uniterm failed: "
161              + uniterm_conn.ConnectionError();
162          return response;
163      }
164
165      /* Save the response parameters from the Uniterm into a
166      * HashTable as our function prototype states. */
167      string[] keys = uniterm_conn.ResponseKeys(id);

```

```
168     for (int i=0; i < keys.Length; i++) {
169         response[keys[i]] = uniterm_conn.ResponseParam(id, keys[i]);
170     }
171
172     /* Free up some memory by purging unneeded data */
173     uniterm_conn.DeleteTrans(id);
174
175     return response;
176 }
177
178
179 /*! Tell Uniterm to shutdown. Since we start it up, we should make sure
180 * we turn it off prior to exiting otherwise the user will be prompted
181 * with an error message stating the Uniterm is already running on the
182 * next execution of this application!
183 * \param[in] uniterm_conn Initialized connection to the Uniterm
184 * as returned by uniterm_connect()
185 */
186 static void uniterm_shutdown(Monetra uniterm_conn)
187 {
188     Hashtable mparams = new Hashtable();
189     mparams["u_action"] = "shutdown";
190     uniterm_sendrequest(uniterm_conn, mparams);
191 }
192
193
194 /*! Main entry point to this application to be executed */
195 static void Main()
196 {
197     Monetra uniterm_conn;
198     string errorstr = "";
199     Hashtable response;
200
201     /* Step1: Launch the Uniterm */
202     uniterm_launch();
203     Console.WriteLine("Uniterm Launched");
204
205     /* Step2: Connect to the Uniterm */
206     uniterm_conn = uniterm_connect(ref errorstr);
207     if (uniterm_conn == null) {
208         Console.WriteLine("Failure: " + errorstr);
209         return;
210     }
211     Console.WriteLine("Connected to Uniterm");
212
213
214     /* Step3: Send txnrequest to Uniterm */
215     Hashtable mparams = new Hashtable();
216     /* Append the parameters for the txnrequest */
217     mparams["username"] = monetra_user;
218     mparams["password"] = monetra_pass;
219     mparams["u_action"] = "txnrequest";
220     mparams["u_devicetype"] = "ingenico_rba";
221     mparams["u_device"] = "HID";
222
223     /* Append the parameters for the transaction that will also get passed
224     * to Monetra such as the 'action', 'amount', etc. as described in the
225     * Monetra Client Interface Protocol Specification */
```

```

226     mparams["action"]    = "sale";
227     mparams["amount"]   = "12.00";
228     mparams["ordernum"] = "123456";
229     mparams["comments"] = "u_txnrequest";
230
231     response = uniterm_sendrequest(uniterm_conn, mparams);
232     if (String.Compare((string)response["code"], "AUTH", true) != 0) {
233         Console.WriteLine("Transaction failed.");
234     } else {
235         Console.WriteLine("Transaction SUCCESSFUL!");
236     }
237
238     /* Print out all the response key/value pairs ... */
239     foreach (DictionaryEntry kv in response) {
240         Console.WriteLine("\t" + (string)kv.Key + " = " + (string)kv.Value);
241     }
242
243     /* NOTE: No real reason to exit here ... we could just keep running
244     *        Step 3 all day long as long as you keep the uniterm_conn handle.
245     *        No reason to keep disconnecting and reconnecting, or
246     *        starting/stopping the Uniterm.
247     */
248
249     /* Step4: Cleanup */
250     uniterm_shutdown(uniterm_conn);
251
252     /* Connections will be automatically closed when the uniterm_conn
253     *    initialized class is closed by the destructor/garbage
254     *    collector */
255 }
256
257 }
258
259

```

C.2 Microsoft C# using XML and `HttpWebRequest`

```

1  /* UniTerm example program in C# using XML and HttpWebRequest
2  *
3  * Works with .Net Compact Framework v2
4  *
5  * Implemented based on the UniTerm Guide in conjunction with the
6  * Monetra Client Interface Protocol Specification
7  *
8  * Please contact support@monetra.com with any questions
9  */
10 using System;
11 using System.Diagnostics;
12 using System.Collections.Generic;
13 using System.Text;
14 using System.IO;
15 using System.Threading;
16 using System.Collections;
17 using System.Net;
18 using System.Xml;
19 using System.ComponentModel;

```

```
20 using System.Windows.Forms;
21 using System.Security.Cryptography.X509Certificates;
22
23 /* NOTE: if compiling with Mono, you can use
24 *      gmcs -r:System.Windows.Forms.dll utest_xml.cs
25 */
26
27 class utest_xml
28 {
29     /* Uniterm Connectivity Information
30     * NOTE: this is the default, it is possible to change, but 99%
31     *       of deployments will probably use this Uniterm information
32     *       as-is
33     */
34     private const string uniterm_host = "localhost";
35     private const int   uniterm_port = 8123;
36
37     /* Authentication information
38     * NOTE: This information corresponds with the public test server
39     *       at testbox.monetra.com:8665 */
40     private const string monetra_user = "test_retail:public";
41     private const string monetra_pass = "publlct3st";
42
43
44     static string uniterm_path()
45     {
46         switch (Environment.OSVersion.Platform) {
47             case PlatformID.Win32NT:
48             case PlatformID.Win32S:
49             case PlatformID.Win32Windows:
50             case PlatformID.WinCE:
51                 return "C:\\Program Files\\Main Street Softworks\\UniTerm\\uniterm.exe";
52             default:
53                 return "/usr/local/uniterm/bin/uniterm";
54         }
55     }
56
57
58     /*! Function to launch Uniterm from the current process.
59     * If we don't launch it from the current process, it won't be given
60     * focus! (at least on Windows this is true, until the first
61     * manual focus is performed by an end-user) */
62     static void uniterm_launch()
63     {
64         Process uniterm = new Process();
65         uniterm.StartInfo.FileName = uniterm_path();
66         /* Not supported on CE
67         * uniterm.StartInfo.CreateNoWindow = true;
68         */
69
70         uniterm.Start();
71
72         /* Make sure Uniterm is ready before returning,
73         * Sleep 1000ms (1s) */
74         System.Threading.Thread.Sleep(1000);
75     }
76
77
```

```

78  /*! Trust all SSL server certificates */
79  internal class AcceptAllCertificatePolicy : ICertificatePolicy
80  {
81      public AcceptAllCertificatePolicy()
82      {
83      }
84      public bool CheckValidationResult(ServicePoint sPoint,
85                                     X509Certificate cert,
86                                     WebRequest wRequest, int certProb)
87      {
88          // *** Always accept
89          return true;
90      }
91  }
92
93
94  /*! Function to POST and XML message to a Monetra-like entity
95  * (Monetra or Uniterm) via HTTPS. It will return
96  * the key/value pairs from the XML response
97  * \param[in] host      Host to connect to
98  * \param[in] port      Port to connect to (via SSL/HTTPS)
99  * \param[in] xml       String-form XML to post
100 * \return True on successful communication, False if communication failed.
101 *      Note: True doesn't mean the transaction itself was successful.
102 */
103 static Hashtable uniterm_https_post(string host, int port, string xml)
104 {
105     Hashtable      response = new Hashtable();
106     string         url      = "https://" + host + ":" + port.ToString();
107     HttpWebRequest req      = (HttpWebRequest)WebRequest.Create(url);
108     string         xmlout;
109
110     try {
111         /* POST Request */
112
113         /* Disable SSL Server Certificate Checking */
114         System.Net.ServicePointManager.CertificatePolicy =
115             new AcceptAllCertificatePolicy();
116
117         byte[] bytes;
118         bytes          = System.Text.Encoding.ASCII.GetBytes(xml);
119         req.Method     = "POST";
120         req.ContentType = "text/xml";
121         req.ContentLength = bytes.Length;
122         Stream reqStream = req.GetRequestStream();
123         reqStream.Write(bytes, 0, bytes.Length);
124         reqStream.Close();
125
126         /* Read Response */
127         /* Note issues with .Net CF v2 as per below:
128         *   http://blogs.msdn.com/b/andrewarnottms/archive/2007/11/19/why-net-compact-framework-fa
129         *   http://support.microsoft.com/kb/970549
130         * If the Server is OpenSSL, this can be worked around by setting
131         * SSL_OP_DONT_INSERT_EMPTY_FRAGMENTS
132         */
133         HttpWebResponse resp = (HttpWebResponse)req.GetResponse();
134         Stream respStream   = resp.GetResponseStream();
135         StreamReader rdr    = new StreamReader(respStream);

```

```

136     xmlout                = rdr.ReadToEnd();
137     rdr.Close();
138 } catch (System.Net.WebException e) {
139     response["code"]      = "DENY";
140     response["u_errorcode"] = "CONN_ERROR";
141     response["verbiage"]  = "Connection to " + url + " failed: " +
142                             e.Message;
143     return response;
144 }
145 XmlDocument    xmldoc    = new XmlDocument();
146 xmldoc.LoadXml(xmlout);
147
148 XmlNodeList    trans     = xmldoc.DocumentElement.
149                             SelectSingleNode("Resp").ChildNodes;
150 foreach (XmlNode kv in trans) {
151     response[kv.Name] = kv.InnerText;
152 }
153 return response;
154 }
155
156
157 /*! Request a ttransaction from Uniterm as documented in the Monetra
158 * Uniterm Guide. The Key/Value pair params are a combination of the
159 * Parameters as documented in the Uniterm Guide and the Monetra Client
160 * Interface Protocol Spec.
161 * \param[in] mparams    Array of key/value parameters to send to Uniterm
162 * \return Hashtable of string key/value pairs from response. Please refer
163 *         to the Uniterm Guide and Monetra Client Interface Protocol
164 *         specification for the applicable list based on the action being
165 *         performed. "code" and "u_errorcode" are always guaranteed to
166 *         be returned.
167 */
168 static Hashtable uniterm_sendrequest(Hashtable mparams)
169 {
170     string XML;
171
172     XML = "<MonetraTrans>" +
173         "<Trans identifier='1'>";
174
175     /* For each item in the params hashtable, add it to the transaction */
176     foreach (DictionaryEntry kv in mparams) {
177         XML = XML + "<" + (String)kv.Key + ">" + (String)kv.Value + "</" +
178             (string)kv.Key + ">";
179     }
180
181     XML = XML + "</Trans></MonetraTrans>";
182
183     return uniterm_https_post(uniterm_host, uniterm_port, XML);
184 }
185
186
187 /*! Tell Uniterm to shutdown. Since we start it up,
188 * we should make sure we turn it off prior to exiting otherwise
189 * the user will be prompted with an error message stating
190 * Uniterm is already running on the next execution
191 * of this application!
192 */
193 static void uniterm_shutdown()

```

```
194 {
195     Hashtable mparams = new Hashtable();
196     mparams["u_action"] = "shutdown";
197     uniterm_sendrequest(mparams);
198 }
199
200
201 /*! Main entry point to this application to be executed */
202 static void Main()
203 {
204     Hashtable response;
205
206     /* Step1: Launch Uniterm */
207     uniterm_launch();
208     MessageBox.Show("Uniterm Launched");
209
210
211     /* Step2: Send txnrequest to Uniterm */
212     Hashtable mparams = new Hashtable();
213     /* Append the parameters for the ticket request as per the Monetra
214      * Uniterm Guide, section 4 */
215     mparams["username"] = monetra_user;
216     mparams["password"] = monetra_pass;
217     mparams["u_action"] = "txnrequest";
218     mparams["u_devicetype"] = "ingenico_rba";
219     mparams["u_device"] = "HID";
220
221     /* Append the parameters for the transaction that will also get passed
222      * to Monetra such as the 'action', 'amount', etc. as described in the
223      * Monetra Client Interface Protocol Specification */
224     mparams["action"] = "sale";
225     mparams["amount"] = "12.00";
226     mparams["ordernum"] = "123456";
227     mparams["comments"] = "u_txnrequest";
228
229     response = uniterm_sendrequest(mparams);
230     string resultMsg = "";
231     if (String.Compare((string)response["code"], "AUTH", true) != 0) {
232         resultMsg = "Transaction failed.\r\n";
233     } else {
234         resultMsg = "Transaction SUCCESSFUL!\r\n";
235     }
236
237     /* Print out all the response key/value pairs ... */
238     foreach (DictionaryEntry kv in response) {
239         resultMsg = resultMsg + (string)kv.Key + " = " + (string)kv.Value +
240             "\r\n";
241     }
242
243     MessageBox.Show(resultMsg);
244
245     /* NOTE: No real reason to exit here ... we could just keep running
246      * Step 2 all day long as long.
247      * No reason to keep starting/stopping Uniterm.
248      */
249
250     /* Step3: Cleanup */
251     uniterm_shutdown();
```

```

252
253     /* Connections will be automatically closed when the uniterm_conn
254     * initialized class is closed by the destructor/garbage
255     * collector */
256     }
257 }
258

```

C.3 Java using libmonetra

```

1  /* Uniterm example program in Java
2  *
3  * Depends on the libmonetra Java native API
4  *
5  * Implemented based on the UniTerm Guide in conjunction with the
6  * Monetra Client Interface Protocol Specification
7  *
8  * Please contact support@monetra.com with any questions
9  */
10 import java.util.Hashtable;
11 import java.util.Enumeration;
12 import com.mainstreetsoftworks.MONETRA;
13
14 /* Compile/run with:
15 *   javac -classpath MONETRA.jar utest.java
16 *   java -cp "./MONETRA.jar:." utest
17 */
18
19 class utest {
20     /* Uniterm Connectivity Information
21     * NOTE: this is the default, it is possible to change, but 99%
22     *       of deployments will probably use this uniterm information
23     *       as-is
24     */
25     private static String uniterm_host      = "localhost";
26     private static int    uniterm_port     = 8123;
27
28     /* Authentication information
29     * NOTE: This information corresponds with the public test server
30     *       at testbox.monetra.com:8665 */
31     private static String monetra_user     = "test_retail:public";
32     private static String monetra_pass    = "publ1ct3st";
33
34
35     static String uniterm_path()
36     {
37         if (System.getProperty("os.name").startsWith("Windows")) {
38             return "C:\\Program Files\\Main Street Softworks\\UniTerm\\uniterm.exe";
39         } else {
40             return "/usr/local/uniterm/bin/uniterm";
41         }
42     }
43
44
45     /*! Function to launch Uniterm from the current process. If we don't
46     * launch it from the current process, it won't be given focus!

```

```
47  * (at least on Windows this is true, until the first manual focus is
48  * performed by an end-user) */
49  static void uniterm_launch()
50  {
51      try {
52          Process p = new ProcessBuilder(uniterm_path()).start();
53      } catch (java.io.IOException e) {
54          System.out.println(e.getMessage());
55          System.exit(1);
56      }
57      /* Make sure Uniterm is ready before returning,
58      * Sleep 1000ms (1s) */
59      try {
60          Thread.sleep(1000);
61      } catch (InterruptedException e) {
62      }
63  }
64
65
66  /*! Function to connect to an endpoint which uses the standard 'monetra'
67  * style protocol (so either Monetra itself, or Uniterm)
68  * \param[in] host      Resolvable hostname or IP address to connect to
69  * \param[in] port      Port associated with hostname to establish an SSL
70  *                       connection to
71  * \param[out] errorstr Textual error message if returns null
72  * \return Initialized connection class on success. null on failure
73  */
74  static MONETRA uniterm_connect_host(String host, int port,
75                                     StringBuilder errorstr)
76  {
77      /* Initialize the Class */
78      MONETRA conn = new MONETRA("");
79
80      errorstr.setLength(0);
81
82      /* We always want to use an SSL connection to Monetra and Uniterm */
83      conn.SetSSL(host, port);
84
85      /* Do not verify the SSL certificate, Monetra and Uniterm
86      * use self-signed certificates by default which cannot be validated.
87      * The connection is still encrypted, the endpoint just isn't strictly
88      * validated */
89      conn.VerifySSLCert(0);
90
91      /* This makes it so TransSend() will block until a response is
92      * received from Monetra. Simplifies the API since we will never
93      * have more than one outstanding transaction per connection in
94      * this application */
95      conn.SetBlocking(1);
96
97      /* Connect! */
98      if (conn.Connect() == 0) {
99          errorstr.append(conn.ConnectionError());
100         return null;
101     }
102
103     return conn;
104 }
```

```

105
106
107  /*! Wrapper function to connect to Uniterm
108  * \param[out] errorstr Textual error message if returns null
109  * \return Initialized connection class on success. null on failure
110  */
111  static MONETRA uniterm_connect(StringBuilder errorstr)
112  {
113      MONETRA conn;
114      StringBuilder myerror = new StringBuilder();
115      conn = uniterm_connect_host(uniterm_host, uniterm_port, myerror);
116      if (conn == null) {
117          errorstr.setLength(0);
118          errorstr.append("Connection to Uniterm Failed: " +
119                          myerror.toString());
120      }
121      return conn;
122  }
123
124
125  /*! Request a transaction from Uniterm as documented in the Monetra
126  * Uniterm Guide. The Key/Value pair params are a combination of the
127  * Parameters as documented in the Uniterm Guide and the Monetra Client
128  * Interface Protocol Spec.
129  * \param[in] uniterm_conn Initialized connection to Uniterm
130  *                               as returned by uniterm_connect()
131  * \param[in] mparams      Array of key/value parameters to send to
132  *                               Uniterm
133  * \return Hashtable of string key/value pairs from response. Please refer
134  *         to the Uniterm Guide and Monetra Client Interface Protocol
135  *         specification for the applicable list based on the action being
136  *         performed. "code" and "u_errorcode" are always guaranteed to
137  *         be returned.
138  */
139  static Hashtable<String,String> uniterm_sendrequest(MONETRA uniterm_conn,
140              Hashtable<String,String> mparams)
141  {
142      long id;
143
144      Hashtable response = new Hashtable<String,String>();
145
146      /* Request a new transaction from libmonetra */
147      id = uniterm_conn.TransNew();
148
149      /* For each item in the params hashtable, add it to the transaction */
150      for (String key : mparams.keySet()) {
151          String value = mparams.get(key);
152          uniterm_conn.TransKeyVal(id, key, value);
153      }
154
155      /* Send the request to the Uniterm. It will not return until
156      * a response is available, or a disconnect is detected */
157      if (uniterm_conn.TransSend(id) == 0) {
158          /* Disconnect detected, return an appropriate error condition!
159          * This should really never happen though... */
160          response.put("code", "DENY");
161          response.put("u_errorcode", "CONN_ERROR");
162          response.put("verbiage", "Connection to Uniterm failed:"

```

```

163                                     + uniterm_conn.ConnectionError());
164     return response;
165 }
166
167 /* Save the response parameters from the Uniterm into a
168  * HashTable as our function prototype states. */
169 String[] keys = uniterm_conn.ResponseKeys(id);
170 for (int i=0; i < keys.length; i++) {
171     response.put(keys[i], uniterm_conn.ResponseParam(id, keys[i]));
172 }
173
174 /* Free up some memory by purging unneeded data */
175 uniterm_conn.DeleteTrans(id);
176
177 return response;
178 }
179
180
181 /*! Tell Uniterm to shutdown. Since we start it up,
182  * we should make sure we turn it off prior to exiting otherwise
183  * the user will be prompted with an error message stating the
184  * Uniterm is already running on the next execution
185  * of this application!
186  * \param[in] uniterm_conn Initialized connection to Uniterm
187  *                               as returned by uniterm_connect()
188  */
189 static void uniterm_shutdown(MONETRA uniterm_conn)
190 {
191     Hashtable mparams = new Hashtable<String,String>();
192     mparams.put("u_action", "shutdown");
193     uniterm_sendrequest(uniterm_conn, mparams);
194 }
195
196
197 /*! Main entry point to this application to be executed */
198 public static void main(String[] args)
199 {
200     MONETRA uniterm_conn;
201     StringBuilder errorstr = new StringBuilder();
202     Hashtable<String,String> response;
203     String ticket;
204
205     /* Step1: Launch Uniterm */
206     uniterm_launch();
207     System.out.println("Uniterm Launched");
208
209     /* Step2: Connect to Uniterm */
210     uniterm_conn = uniterm_connect(errorstr);
211     if (uniterm_conn == null) {
212         System.out.println("Failure: " + errorstr.toString());
213         return;
214     }
215     System.out.println("Connected to Uniterm");
216
217     /* Step3: Send a txnrequest to Uniterm */
218     Hashtable<String,String> mparams = new Hashtable<String,String>();
219     /* Append the parameters for the txnrequest */
220     mparams.put("username", monetra_user);

```

```

221  mparams.put("password",    monetra_pass);
222  mparams.put("u_action",    "txnrequest");
223
224  mparams.put("u_devicetype", "ingenico_rba");
225  mparams.put("u_device",    "HID");
226
227  /* Append the parameters for the transaction that will also get passed
228   * to Monetra such as the 'action', 'amount', etc. as described in the
229   * Monetra Client Interface Protocol Specification */
230  mparams.put("action",     "sale");
231  mparams.put("amount",    "12.00");
232  mparams.put("ordernum",  "123456");
233  mparams.put("comments",  "u_txnrequest");
234
235  response = uniterm_sendrequest(uniterm_conn, mparams);
236  if (!response.get("code").equalsIgnoreCase("AUTH")) {
237    System.out.println("Transaction failed.");
238  } else {
239    System.out.println("Transaction SUCCESSFUL!");
240  }
241
242  /* Print out all the response key/value pairs ... */
243  for (String key : response.keySet()) {
244    String value = response.get(key);
245    System.out.println("\t" + key + " = " + value);
246  }
247
248  /* NOTE: No real reason to exit here ... we could just keep running
249   *       Step 3 all day long as long as you keep the uniterm_conn handle.
250   *       No reason to keep disconnecting and reconnecting, or
251   *       starting/stopping the Uniterm.
252   */
253
254  /* Step4: Cleanup */
255  uniterm_shutdown(uniterm_conn);
256
257  /* Connections will be automatically closed when the uniterm_conn
258   * initialized classe is closed by the destructor/garbage
259   * collector */
260 }
261 }
262 }
263
264

```

C.4 PHP using libmonetra

```

1  <?php
2  /* UniTerm example program in PHP
3   *
4   * Depends on the libmonetra PHP native API
5   *
6   * Implemented based on the UniTerm Guide in conjunction with the
7   * Monetra Client Interface Protocol Specification
8   *
9   * Please contact support@monetra.com with any questions

```

```

10  */
11  error_reporting(E_ALL);
12  require_once("libmonetra.php");
13
14
15
16  /* Uniterm Connectivity Information
17  * NOTE: this is the default, it is possible to change, but 99%
18  *       of deployments will probably use this uniterm information
19  *       as-is
20  */
21  $uniterm_host      = "localhost";
22  $uniterm_port      = 8123;
23
24  /* Authentication information
25  * NOTE: This information corresponds with the public test server
26  *       at testbox.monetra.com:8665 */
27  $monetra_user      = "test_retail:public";
28  $monetra_pass      = "publlct3st";
29
30
31  /* Sets the path of the Uniterm executable.  Currently using
32  * the default locations */
33  if (strtoupper(substr(PHP_OS, 0, 3)) === 'WIN') {
34  /* Windows path */
35  $uniterm_path      = "C:\\Program Files\\Main Street Softworks\\UniTerm\\uniterm.exe";
36  } else {
37  /* Unix path */
38  $uniterm_path      = "/usr/local/uniterm/bin/uniterm";
39  }
40
41
42  /*! Function to launch Uniterm from the current process.
43  * If we don't launch it from the current process, it won't be given
44  * focus! (at least on Windows this is true, until the first
45  * manual focus is performed by an end-user) */
46  function uniterm_launch()
47  {
48  global $uniterm_path;
49  if (class_exists("COM")) {
50  /* Must be running windows */
51  $WshShell = new COM("WScript.Shell");
52  $oExec    = $WshShell->Run('"' . $uniterm_path . '"', 10, false);
53  } else {
54  /* Must be on a Unix system */
55  system('"' . $uniterm_path . '" . " > /dev/null 2>&1 &");
56  }
57
58  /* Make sure Uniterm is ready before returning,
59  * sleep 2s */
60  sleep(2);
61  }
62
63
64  /*! Function to connect to an endpoint which uses the standard 'monetra'
65  * style protocol (so either Monetra itself, or Uniterm)
66  * \param[in] host      Resolvable hostname or IP address to connect to
67  * \param[in] port      Port associated with hostname to establish an SSL

```

```
68 *           connection to
69 * \param[out] errorstr Textual error message if returns null
70 * \return Initialized connection on success. null on failure
71 */
72 function uniterm_connect_host($host, $port, &$errorstr)
73 {
74     /* Initialize the Connection */
75     $conn = M_InitConn();
76
77     $errorstr = "";
78
79     /* We always want to use an SSL connection to Monetra and Uniterm */
80     M_SetSSL($conn, $host, $port);
81
82     /* Do not verify the SSL certificate, Monetra and Uniterm
83      * use self-signed certificates by default which cannot be validated.
84      * The connection is still encrypted, the endpoint just isn't strictly
85      * validated */
86     M_VerifySSLCert($conn, false);
87
88     /* This makes it so TransSend() will block until a response is
89      * received from Monetra. Simplifies the API since we will never
90      * have more than one outstanding transaction per connection in
91      * this application */
92     M_SetBlocking($conn, true);
93
94     /* Connect! */
95     if (!M_Connect($conn)) {
96         $errorstr = M_ConnectionError($conn);
97         return null;
98     }
99
100     return $conn;
101 }
102
103
104 /*! Wrapper function to connect to Uniterm
105 * \param[out] errorstr Textual error message if returns null
106 * \return Initialized connection on success. null on failure
107 */
108 function uniterm_connect(&$errorstr)
109 {
110     global $uniterm_host, $uniterm_port;
111
112     $myerror = "";
113     $conn = uniterm_connect_host($uniterm_host, $uniterm_port, &$myerror);
114     if ($conn == null) {
115         $errorstr = "Connection to Uniterm Failed: " . $myerror;
116     }
117     return $conn;
118 }
119
120
121 /*! Request a transaction from Uniterm as documented in the Uniterm Guide.
122 * The Key/Value pair params are a combination of the Parameters as
123 * documented in the Uniterm Guide and the Monetra Client Interface Protocol
124 * Spec.
125 * \param[in] uniterm_conn Initialized connection to Uniterm as returned by
```

UniTerm Code Examples

```
126 *                               uniterm_connect()
127 * \param[in] params           Array of key/value parameters to send to Uniterm
128 *
129 * \return Array of string key/value pairs from response. Please refer to the
130 *       Uniterm Guide and Monetra Client Interface Protocol specification
131 *       for the applicable list based on the action being performed.
132 *       "code" and "u_errorcode" are always guaranteed to be returned.
133 */
134 function uniterm_sendrequest($uniterm_conn, $params)
135 {
136     $response = array();
137
138     /* Request a new transaction from libmonetra */
139     $id = M_TransNew($uniterm_conn);
140
141     /* For each item in the params array, add it to the transaction */
142     foreach ($params as $key => $value) {
143         M_TransKeyVal($uniterm_conn, $id, $key, $value);
144     }
145
146     /* Send the request to the Uniterm. It will not return until a
147     * response is available, or a disconnect is detected */
148     if (!M_TransSend($uniterm_conn, $id)) {
149         /* Disconnect detected, return an appropriate error condition!
150         * This should really never happen though... */
151         $response["code"] = "DENY";
152         $response["u_errorcode"] = "CONN_ERROR";
153         $response["verbiage"] = "Connection to Uniterm failed: " .
154             M_ConnectionError($uniterm_conn);
155         return $response;
156     }
157
158     /* Save the response parameters from the Uniterm into a HashTable
159     * as our function prototype states. */
160     $keys = M_ResponseKeys($uniterm_conn, $id);
161     foreach ($keys as $value) {
162         $response[$value] = M_ResponseParam($uniterm_conn, $id, $value);
163     }
164
165     /* Free up some memory by purging unneeded data */
166     M_DeleteTrans($uniterm_conn, $id);
167
168     return $response;
169 }
170
171
172 /*! Tell Uniterm to shutdown. Since we start it up,
173 * we should make sure we turn it off prior to exiting otherwise
174 * the user will be prompted with an error message stating the
175 * Uniterm is already running on the next execution
176 * of this application!
177 * \param[in] uniterm_conn Initialized connection to Uniterm
178 *                       as returned by uniterm_connect()
179 */
180 function uniterm_shutdown($uniterm_conn)
181 {
182     uniterm_sendrequest($uniterm_conn, array("u_action" => "shutdown"));
183 }
```

```
184
185
186
187 /* CODE TO EXECUTE ... */
188
189 $errorstr = "";
190
191 /* Step1: Launch Uniterm */
192 uniterm_launch();
193 echo "Uniterm Launched\r\n";
194
195 /* Step2: Connect to Uniterm */
196 $uniterm_conn = uniterm_connect(&$errorstr);
197 if ($uniterm_conn == null) {
198     echo "Failure: " . $errorstr . "\r\n";
199     return;
200 }
201
202 echo "Connected to Uniterm\r\n";
203
204
205 /* Step3: Send a txnrequest to the Uniterm */
206 $params = array();
207
208 /* Append the parameters for the txnrequest */
209 $params["username"] = $monetra_user;
210 $params["password"] = $monetra_pass;
211 $params["u_action"] = "txnrequest";
212 $params["u_devicetype"] = "ingenico_rba";
213 $params["u_device"] = "HID";
214
215 /* Append the parameters for the transaction that will also get passed to
216 * Monetra such as the 'action', 'amount', etc. as described in the Monetra
217 * Client Interface Protocol Specification */
218 $params['action'] = 'sale';
219 $params['amount'] = '12.00';
220 $params['ordernum'] = '123456';
221 $params['comments'] = 'u_txnrequest';
222
223 $response = uniterm_sendrequest($uniterm_conn, $params);
224 if (strcasecmp($response["code"], "AUTH") != 0) {
225     echo "Transaction Failed.\r\n";
226 } else {
227     echo "Transaction SUCCESSFUL!\r\n";
228 }
229
230 /* Print out all the response key/value pairs ... */
231 foreach ($response as $key => $value) {
232     echo "\t" . $key . " = " . $value . "\r\n";
233 }
234
235 /* NOTE: No real reason to exit here ... we could just keep running
236 * Step 3 all day long as long as you keep the uniterm_conn handle.
237 * No reason to keep disconnecting and reconnecting, or
238 * starting/stopping Uniterm.
239 */
240
241 /* Step4: Cleanup */
```

```

242 uniterm_shutdown($uniterm_conn);
243
244 /* Connections will be automatically closed when the uniterm_conn
245    * initialized connection is closed by the destructor/garbage collector */
246
247 ?>
248
249

```

C.5 Microsoft VB.Net using libmonetra

```

1  ' UniTerm example program in VB.Net
2  '
3  ' Depends on the libmonetra C# .Net native API (DLL)
4  '
5  ' Implemented based on the UniTerm Guide in conjunction with the
6  ' Monetra Client Interface Protocol Specification
7  '
8  ' Please contact support@monetra.com with any questions
9
10 Option Explicit On
11 Option Strict On
12
13 Imports System
14 Imports System.Collections
15 Imports System.Diagnostics
16 Imports System.Threading
17 Imports libmonetra
18
19 ' On unix, compile using:
20 '   gmcs /target:library /unsafe libmonetra.cs
21 '   vbnc2 -r:libmonetra.dll utest.vb
22
23 Module Module1
24     ' Uniterm Connectivity Information
25     ' NOTE: this is the default, it is possible to change, but 99%
26     '       of deployments will probably use this Uniterm information
27     '       as-is
28     Private Const uniterm_host As String = "localhost"
29     Private Const uniterm_port As Integer = 8123
30
31     ' Authentication information
32     ' NOTE: This information corresponds with the public test server
33     '       at testbox.monetra.com:8665
34     Private Const monetra_user As String = "test_retail:public"
35     Private Const monetra_pass As String = "publlct3st"
36
37     Private Function uniterm_path As String
38         Select Case Environment.OSVersion.Platform
39             Case PlatformID.Win32NT, PlatformID.Win32S, _
40                 PlatformID.Win32Windows, PlatformID.WinCE
41                 Return "C:\\Program Files\\Main Street Softworks\\UniTerm\\uniterm.exe"
42             Case Else
43                 Return "/usr/local/uniterm/bin/uniterm"
44         End Select
45     End Function

```

UniTerm Code Examples

```
46
47
48 '! Function to launch Uniterm from the current process.
49 ' If we don't launch it from the current process, it won't be given
50 ' focus! (at least on Windows this is true, until the first
51 ' manual focus is performed by an end-user)
52 Private Sub uniterm_launch()
53 Dim uniterm As New Process()
54 uniterm.StartInfo.FileName = uniterm_path
55 uniterm.StartInfo.CreateNoWindow = True
56
57 uniterm.Start()
58
59 ' Make sure Uniterm is ready before returning,
60 ' Sleep 1000ms (1s)
61 System.Threading.Thread.Sleep(1000)
62 End Sub
63
64
65 '! Function to connect to an endpoint which uses the standard 'monetra'
66 ' style protocol (so either Monetra itself, or Uniterm)
67 ' \param[in] host      Resolvable hostname or IP address to connect to
68 ' \param[in] port      Port associated with hostname to establish an SSL
69 '                      connection to
70 ' \param[out] errorstr Textual error message if returns null
71 ' \return Initialized connection class on success. null on failure
72 Private Function uniterm_connect_host(ByVal host As String, ByVal port _
73                                     As Integer, ByRef errorstr As String) _
74                                     As Monetra
75 ' Initialize the Class
76 Dim conn As New Monetra
77
78 errorstr = ""
79
80 ' We always want to use an SSL connection to Monetra and Uniterm
81 conn.SetSSL(host, port)
82
83 ' Do not verify the SSL certificate, Monetra and Uniterm
84 ' use self-signed certificates by default which cannot be validated.
85 ' The connection is still encrypted, the endpoint just isn't strictly
86 ' validated
87 conn.VerifySSLCert(False)
88
89 ' This makes it so TransSend() will block until a response is
90 ' received from Monetra. Simplifies the API since we will never
91 ' have more than one outstanding transaction per connection in
92 ' this application
93 conn.SetBlocking(True)
94
95 ' Connect!
96 If Not conn.Connect() Then
97     errorstr = conn.ConnectionError()
98     Return Nothing
99 End If
100
101 Return conn
102 End Function
103
```

UniTerm Code Examples

```
104
105 ' ! Wrapper function to connect to the Uniterm
106 ' \param[out] errorstr Textual error message if returns null
107 ' \return Initialized connection class on success. null on failure
108 Private Function uniterm_connect(ByRef errorstr As String) As Monetra
109     Dim conn As Monetra
110     Dim myerror As String = ""
111     conn = uniterm_connect_host(uniterm_host, uniterm_port, myerror)
112     If conn Is Nothing Then
113         errorstr = "Connection to Uniterm Failed: " + myerror
114     End If
115
116     Return conn
117 End Function
118
119 ' Request a transaction from Uniterm as documented in the Uniterm Guide.
120 ' The Key/Value pair params are a combination of the Parameters as
121 ' documented in the Uniterm Guide and the Monetra Client Interface
122 ' Protocol Spec.
123 ' \param[in] uniterm_conn Initialized connection to the Uniterm
124 '                               as returned by uniterm_connect()
125 ' \param[in] mparams        Array of key/value parameters to send to Uniterm
126 ' \return Hashtable of string key/value pairs from response. Please refer
127 '         to the Uniterm Guide and Monetra Client Interface Protocol
128 '         specification for the applicable list based on the action being
129 '         performed. "code" and "u_errorcode" are always guaranteed to
130 '         be returned.
131 Private Function uniterm_sendrequest(ByVal uniterm_conn As Monetra, ByVal _
132                                     mparams As Hashtable) As Hashtable
133     Dim id As Integer
134     Dim response As New Hashtable
135
136     ' Request a new transaction from libmonetra
137     id = uniterm_conn.TransNew()
138
139     ' For each item in the params hashtable, add it to the transaction
140     Dim kv As DictionaryEntry
141     For Each kv In mparams
142         uniterm_conn.TransKeyVal(id, CType(kv.Key, String), _
143                                     CType(kv.Value, String))
144     Next kv
145
146     ' Send the request to the Uniterm. It will not return until a
147     ' response is available, or a disconnect is detected
148     If Not uniterm_conn.TransSend(id) Then
149         ' Disconnect detected, return an appropriate error condition!
150         ' This should really never happen though...
151         response("code") = "DENY"
152         response("u_errorcode") = "CONN_ERROR"
153         response("verbiage") = "Connection to Uniterm failed:" _
154                                 + uniterm_conn.ConnectionError()
155     End If
156     Return response
157
158     ' Save the response parameters from Uniterm into a
159     ' HashTable as our function prototype states. */
160     Dim keys() As String = uniterm_conn.ResponseKeys(id)
161     Dim i As Integer
```

UniTerm Code Examples

```
162 For i = 0 To keys.Length - 1
163     response(keys(i)) = uniterm_conn.ResponseParam(id, keys(i))
164 Next i
165
166 ' Free up some memory by purging unneeded data
167 uniterm_conn.DeleteTrans(id)
168
169 Return response
170 End Function
171
172
173 '! Tell Uniterm to shutdown. Since we start it up,
174 ' we should make sure we turn it off prior to exiting otherwise
175 ' the user will be prompted with an error message stating the
176 ' Uniterm is already running on the next execution
177 ' of this application!
178 ' \param[in] uniterm_conn Initialized connection to Uniterm
179 ' as returned by uniterm_connect()
180 Private Sub uniterm_shutdown(ByVal uniterm_conn As Monetra)
181     Dim mparams As New Hashtable
182
183     mparams("u_action") = "shutdown"
184     uniterm_sendrequest(uniterm_conn, mparams)
185 End Sub
186
187 '! Main entry point to this application to be executed
188 Public Sub Main()
189     Dim uniterm_conn As Monetra
190     Dim errorstr As String = ""
191     Dim response As Hashtable
192     Dim ticket As String
193
194     ' Step1: Launch Uniterm
195     uniterm_launch()
196     Console.WriteLine("Uniterm Launched")
197
198     ' Step2: Connect to Uniterm
199     uniterm_conn = uniterm_connect(errorstr)
200     If uniterm_conn Is Nothing Then
201         Console.WriteLine("Failure: " + errorstr)
202         Return
203     End If
204     Console.WriteLine("Connected to Uniterm")
205
206     ' Step3: Send a txnrequest to Uniterm
207     Dim mparams As New Hashtable
208     ' Append the parameters for the ticket request as per the Monetra
209     ' Uniterm Guide
210     mparams("username") = monetra_user
211     mparams("password") = monetra_pass
212     mparams("u_action") = "txnrequest"
213     mparams("u_devicetype") = "ingenico_rba"
214     mparams("u_device") = "HID"
215
216     ' Append the parameters for the transaction that will also get passed
217     ' to Monetra such as the 'action', 'amount', etc. as described in the
218     ' Monetra Client Interface Protocol Specification
219     mparams("action") = "sale"
```

```

220  mparams("amount") = "12.00"
221  mparams("ordernum") = "123456"
222  mparams("comments") = "u_txnrequest"
223
224  response = uniterm_sendrequest(uniterm_conn, mparams)
225  If StrComp(CType(response("code"), String), "AUTH", _
226             vbTextCompare) <> 0 Then
227     Console.WriteLine("Transaction failed.")
228 Else
229     Console.WriteLine("Transaction SUCCESSFUL!")
230 End If
231
232 ' Print out all the response key/value pairs ...
233 Dim kv As DictionaryEntry
234 For Each kv In response
235     Console.WriteLine("  " + CType(kv.Key, String) + " = " + _
236                       CType(kv.Value, String))
237 Next kv
238
239 ' NOTE: No real reason to exit here ... we could just keep running
240 '       Step 3 all day long as long as you keep the uniterm_conn handle.
241 '       No reason to keep disconnecting and reconnecting, or
242 '       starting/stopping Uniterm.
243
244 ' Step4: Cleanup
245 uniterm_shutdown(uniterm_conn)
246
247 ' Connections will be automatically closed when the uniterm_conn
248 ' initialized class is closed by the destructor/garbage
249 ' collector
250 End Sub
251
252 End Module
253
254

```

C.6 Microsoft vBScript using XML and MSXML2

```

1  ' UniTerm example program in VBScript
2  '
3  ' Depends on the MSXML, and Microsoft Scripting Runtime
4  '
5  ' Implemented based on the UniTerm Guide in conjunction with the
6  ' Monetra Client Interface Protocol Specification
7  '
8  ' Please contact support@monetra.com with any questions
9
10 Option Explicit
11
12 ' Monetra Connectivity Information
13 Dim monetra_user
14 Dim monetra_pass
15
16 ' Uniterm Connectivity Information
17 Dim uniterm_host
18 Dim uniterm_port

```

UniTerm Code Examples

```
19 Dim uniterm_path
20
21
22 '! Function to launch Uniterm from the current process.
23 ' If we don't launch it from the current process, it won't be given
24 ' focus! (at least on Windows this is true, until the first
25 ' manual focus is performed by an end-user)
26 Sub uniterm_launch()
27 Dim objShell
28 Dim res
29 Set objShell = CreateObject("Wscript.Shell")
30 res = objShell.Run(""" & uniterm_path & """, 10, FALSE)
31
32 ' Make sure Uniterm is ready before returning,
33 ' Sleep 1000ms (1s)
34 WScript.Sleep 1000
35 End Sub
36
37
38 '! Function to POST and XML message to a Monetra-like entity
39 ' (Monetra or the Uniterm) via HTTPS. It will return
40 ' the key/value pairs from the XML response
41 '\param[in] host      Host to connect to
42 '\param[in] port      Port to connect to (via SSL/HTTPS)
43 '\param[in] xml       String-form XML to post
44 '\param[out] errorstr If returning False, the error message, typically comms
45 '                   error
46 '\param[out] myresponse Dictionary of string key/value pairs from the response.
47 '\return True on successful communication, False if communication failed.
48 ' Note: True doesn't mean the transaction itself was successful.
49 Function uniterm_https_post(ByVal host, ByVal port, ByVal xml, ByVal errorstr, _
50                             ByRef myresponse)
51 Dim xmlhttp
52 Dim xmldoc
53
54 Set xmlhttp = CreateObject("MSXML2.ServerXMLHTTP")
55
56 xmlhttp.open          "POST", "https://" & host & ":" & port, False
57 xmlhttp.setOption     2, 13056
58 ' Set Timeouts (in milliseconds)
59 ' DNS: 5s, Connect: 5s, Send: 30s, Receive: 120s
60 xmlhttp.setTimeouts  5000, 5000, 30000, 120000
61 xmlhttp.setRequestHeader "Content-Type", "text/xml"
62
63 On Error Resume Next
64 xmlhttp.send          xml
65
66 If Not Err.Number = 0 Then
67 errorstr = "HTTPS POST Failed to https://" & host & ":" & port & _
68           " " & Err.Description
69 uniterm_https_post = False
70 Exit Function
71 End If
72
73 Set xmldoc = CreateObject("Microsoft.XMLDOM")
74
75 xmldoc.async = "false"
76 xmldoc.loadxml(xmlhttp.responseText)
```

```

77
78 Dim Trans
79 Set Trans = xmldoc.documentElement.selectSingleNode("Resp").childNodes
80
81 Dim kv
82 For Each kv In Trans
83     myresponse(kv.nodeName) = kv.text
84 Next
85
86 uniterm_https_post = True
87 End Function
88
89
90 '! Request a transaction from Uniterm as documented in the Uniterm Guide.
91 ' The Key/Value pair params are a combination of the Parameters as documented
92 ' the Uniterm Guide and the Monetra Client Interface Protocol Spec.
93 ' \param[in] mparams Dictionary of key/value parameters to send to the
94 ' Uniterm
95 ' \param[out] errorstr If returning False, the error message, typically comms
96 ' error
97 ' \param[out] myresponse Dictionary of string key/value pairs from response.
98 ' Please refer to the Uniterm Guide and Monetra Client
99 ' Interface Protocol specification for the applicable
100 ' list based on the action being performed. "code" and
101 ' "u_errorcode" are always guaranteed to be returned.
102 ' \return True on successful communication, False if communication failed.
103 ' Note: True doesn't mean the transaction itself was successful.
104 Function uniterm_sendrequest(ByVal mparams, ByRef errorstr, ByRef myresponse)
105 Dim xml
106
107 xml = "<MonetraTrans><Trans identifier='1'>"
108
109 ' For each item in the params dictionary, add it to the transaction
110 Dim key
111 For Each key In mparams
112     xml = xml & "<" & key & ">" & mparams(key) & "</" & key & ">"
113 Next
114
115 xml = xml & "</Trans></MonetraTrans>"
116
117 uniterm_sendrequest = uniterm_https_post(uniterm_host, uniterm_port, xml, _
118     errorstr, myresponse)
119 End Function
120
121
122 '! Tell Uniterm to shutdown. Since we start it up,
123 ' we should make sure we turn it off prior to exiting otherwise
124 ' the user will be prompted with an error message stating the
125 ' Uniterm is already running on the next execution
126 ' of this application!
127 Sub uniterm_shutdown()
128 Dim myresponse
129 Dim errorstr
130 Dim mparams
131
132 Set mparams = CreateObject("Scripting.Dictionary")
133 mparams("u_action") = "shutdown"
134

```

UniTerm Code Examples

```
135  uniterm_sendrequest mparams, errorstr, myresponse
136  ' No need for error checking in this function as we don't
137  ' care if this fails
138  End Sub
139
140
141  '! Main entry point to this application to be executed
142
143  ' Uniterm Connectivity Information
144  ' NOTE: this is the default, it is possible to change, but 99%
145  '       of deployments will probably use this Uniterm information
146  '       as-is
147  uniterm_host = "localhost"
148  uniterm_port = 8123
149  uniterm_path = "C:\\Program Files\\Main Street Softworks\\UniTerm\\uniterm.exe"
150
151  ' Authentication information
152  ' NOTE: This information corresponds with the public test server
153  '       at testbox.monetra.com:8665
154  monetra_user = "test_retail:public"
155  monetra_pass = "publlct3st"
156
157
158  Dim errorstr
159  Dim mparams
160  Dim myresp
161  Dim msg
162
163  errorstr = ""
164
165  ' Step1: Launch Uniterm
166  uniterm_launch
167  MsgBox("Uniterm Launched")
168
169
170  ' Step2: Send txnrequest to Uniterm
171
172  Set myresp = CreateObject("Scripting.Dictionary")
173  Set mparams = CreateObject("Scripting.Dictionary")
174  ' Append the parameters for the txnrequest
175  mparams("username") = monetra_user
176  mparams("password") = monetra_pass
177  mparams("u_action") = "txnrequest"
178  mparams("u_devicetype") = "ingenico_rba"
179  mparams("u_device") = "HID"
180
181  ' Append the parameters for the transaction that will also get passed
182  ' to Monetra such as the 'action', 'amount', etc. as described in the
183  ' Monetra Client Interface Protocol Specification
184  mparams("action") = "sale"
185  mparams("amount") = "12.00"
186  mparams("ordernum") = "123456"
187  mparams("comments") = "u_txnrequest"
188
189  If Not uniterm_sendrequest(mparams, errorstr, myresp) Then
190  MsgBox errorstr
191  WScript.Quit 1
192  End If
```

```

193
194 If StrComp(myresp("code"), "AUTH", vbTextCompare) <> 0 Then
195   msg = "Transaction failed." & vbCrLf
196 Else
197   msg = "Transaction SUCCESSFUL!" & vbCrLf
198 End If
199
200 ' Print out all the response key/value pairs ...
201 Dim key
202 For Each key In myresp
203   msg = msg & "  " & key & " = " & myresp(key) & vbCrLf
204 Next
205
206 MsgBox (msg)
207
208
209 ' NOTE: No real reason to exit here ... we could just keep running
210 '       Step 2 all day long. No reason to keep starting/stopping the
211 '       Uniterm.
212
213 ' Step3: Cleanup
214 uniterm_shutdown
215
216
217
218
219

```

C.7 Microsoft Visual Basic 6 using libmonetra

```

1  Attribute VB_Name = "Module1"
2  ' UniTerm example program in VB6
3  '
4  ' Depends on the libmonetra C# .Net native API (DLL) (has COM hooks)
5  '
6  ' Must add reference to libmonetra and Microsoft Scripting Runtime
7  '
8  ' Implemented based on the UniTerm Guide in conjunction with the
9  ' Monetra Client Interface Protocol Specification
10 '
11 ' Please contact support@monetra.com with any questions
12
13 Option Explicit
14
15 ' MonetraInformation
16 Dim monetra_user As String
17 Dim monetra_pass As String
18
19 ' Uniterm Connectivity Information
20 Dim uniterm_host As String
21 Dim uniterm_port As Integer
22 Dim uniterm_path As String
23
24 Private Declare Sub Sleep Lib "kernel32.dll" (ByVal dwMilliseconds As Long)
25
26 '! Function to launch Uniterm from the current process.

```

UniTerm Code Examples

```
27 ' If we don't launch it from the current process, it won't be given
28 ' focus! (at least on Windows this is true, until the first
29 ' manual focus is performed by an end-user)
30 Sub uniterm_launch()
31 Dim id As Double
32 id = Shell(""" & uniterm_path & """, vbNormalFocus)
33
34 ' Make sure Uniterm is ready before returning,
35 ' Sleep 1000ms (1s)
36 Sleep (1000)
37 End Sub
38
39
40 '! Function to connect to an endpoint which uses the standard 'monetra'
41 ' style protocol (so either Monetra itself, or Uniterm)
42 ' \param[in] host Resolvable hostname or IP address to connect to
43 ' \param[in] port Port associated with hostname to establish an SSL
44 ' connection to
45 ' \param[out] errorstr Textual error message if returns null
46 ' \return Initialized connection class on success. null on failure
47 Function uniterm_connect_host(ByVal host As String, ByVal port As Integer, _
48 ByRef errorstr As String) As IMonetra
49 'Initialize the Class
50 Dim conn As IMonetra
51 Set conn = New Monetra
52
53 errorstr = ""
54
55 ' We always want to use an SSL connection to Monetra and Uniterm
56 conn.SetSSL host, port
57
58 ' Do not verify the SSL certificate, Monetra and Uniterm
59 ' use self-signed certificates by default which cannot be validated.
60 ' The connection is still encrypted, the endpoint just isn't strictly
61 ' validated
62 conn.VerifySSLCert False
63
64 ' This makes it so TransSend() will block until a response is
65 ' received from Monetra. Simplifies the API since we will never
66 ' have more than one outstanding transaction per connection in
67 ' this application
68 conn.SetBlocking True
69
70 ' Connect!
71 If Not conn.Connect() Then
72 errorstr = conn.ConnectionError()
73 Set uniterm_connect_host = Nothing
74 Exit Function
75 End If
76
77 Set uniterm_connect_host = conn
78 End Function
79
80
81 '! Wrapper function to connect to Uniterm
82 ' \param[out] errorstr Textual error message if returns null
83 ' \return Initialized connection class on success. null on failure
84 Function uniterm_connect(ByRef errorstr As String) As IMonetra
```

UniTerm Code Examples

```
85 Dim conn As IMonetra
86 Dim myerror As String
87
88 myerror = ""
89 Set conn = uniterm_connect_host(uniterm_host, uniterm_port, myerror)
90 If conn Is Nothing Then
91     errorstr = "Connection to Uniterm Failed: " & myerror
92 End If
93 Set uniterm_connect = conn
94 End Function
95
96
97 ' Request a transaction from Uniterm as documented in the UniTerm
98 ' Guide. The Key/Value pair params are a combination of the Parameters as
99 ' Uniterm Guide and the Monetra Client Interface Protocol Spec.
100 ' \param[in] uniterm_conn Initialized connection to Unitermas returned by
101 '                          connect_to_uniterm()
102 ' \param[in] mparams      Dictionary of key/value parameters to send to
103 '                          Uniterm
104 ' \return Dictionary of string key/value pairs from response. Please refer
105 ' to the Uniterm Guide and Monetra Client Interface Protocol
106 ' specification for the applicable list based on the action being
107 ' performed. "code" and "u_errorcode" are always guaranteed to
108 ' be returned.
109 Function uniterm_sendrequest(ByVal uniterm_conn As IMonetra, _
110     ByVal mparams As Dictionary) _
111     As Dictionary
112     Dim id As Integer
113     Dim myresponse As New Dictionary
114
115     ' Request a new transaction from libmonetra
116     id = uniterm_conn.TransNew()
117
118     ' For each item in the params dictionary, add it to the transaction
119     Dim key
120     For Each key In mparams
121         uniterm_conn.TransKeyVal id, key, mparams(key)
122     Next key
123
124     ' Send the request to the Uniterm. It will not return until a
125     ' response is available, or a disconnect is detected
126     If Not uniterm_conn.TransSend(id) Then
127         ' Disconnect detected, return an appropriate error condition!
128         ' This should really never happen though...
129         myresponse("code") = "DENY"
130         myresponse("u_errorcode") = "CONN_ERROR"
131         myresponse("verbiage") = "Connection to Uniterm failed: " _
132             & uniterm_conn.ConnectionError()
133         Set uniterm_sendrequest = myresponse
134     Exit Function
135 End If
136
137     ' Save the response parameters from the Uniterm into a HashTable
138     ' as our function prototype states.
139     Dim keys() As String
140     keys = uniterm_conn.ResponseKeys(id)
141     Dim i As Integer
142     For i = LBound(keys) To UBound(keys)
```

UniTerm Code Examples

```
143     myresponse(keys(i)) = uniterm_conn.ResponseParam(id, keys(i))
144     Next i
145
146     ' Free up some memory by purging unneeded data
147     uniterm_conn.DeleteTrans (id)
148
149     Set uniterm_sendrequest = myresponse
150 End Function
151
152
153 '! Tell Uniterm to shutdown. Since we start it up, we should make sure we
154 ' turn it off prior to exiting otherwise the user will be prompted with an
155 ' error message stating Uniterm is already running on the next execution
156 ' of this application!
157 ' \param[in] uniterm_conn Initialized connection to Uniterm as returned by
158 '         connect_to_uniterm()
159 Sub uniterm_shutdown(ByVal uniterm_conn As IMonetra)
160     Dim mparams As New Dictionary
161
162     mparams("u_action") = "shutdown"
163     uniterm_sendrequest uniterm_conn, mparams
164 End Sub
165
166
167 '! Main entry point to this application to be executed
168 Sub Main()
169     ' Uniterm Connectivity Information
170     ' NOTE: this is the default, it is possible to change, but 99%
171     '       of deployments will probably use this Uniterm information
172     '       as-is
173     uniterm_host = "localhost"
174     uniterm_port = 8123
175     uniterm_path = "C:\\Program Files\\Main Street Softworks\\UniTerm\\uniterm.exe"
176
177     ' Authentication information
178     ' NOTE: This information corresponds with the public test server
179     '       at testbox.monetra.com:8665
180     monetra_user = "test_retail:public"
181     monetra_pass = "publlct3st"
182
183     Dim uniterm_conn As IMonetra
184     Dim errorstr As String
185     Dim myresp As Dictionary
186     Dim msg As String
187
188     errorstr = ""
189
190     ' Step1: Launch Uniterm
191     uniterm_launch
192     MsgBox ("Uniterm Launched")
193
194     ' Step2: Connect to Uniterm
195     Set uniterm_conn = uniterm_connect(errorstr)
196     If uniterm_conn Is Nothing Then
197         MsgBox ("Failure: " & errorstr)
198     Exit Sub
199 End If
200
```

UniTerm Code Examples

```
201 MsgBox ("Connected to the Uniterm")
202
203 ' Step3: Send a txnrequest to Uniterm
204 Dim mparams As New Dictionary
205 ' Append the parameters for the ticket request as per the Uniterm Guide
206 mparams("username") = monetra_user
207 mparams("password") = monetra_pass
208 mparams("u_action") = "txnrequest"
209 mparams("u_devicetype") = "ingenico_rba"
210 mparams("u_device") = "HID"
211
212 ' Append the parameters for the transaction that will also get passed
213 ' to Monetra such as the 'action', 'amount', etc. as described in the
214 ' Monetra Client Interface Protocol Specification
215 mparams("action") = "sale"
216 mparams("amount") = "12.00"
217 mparams("ordernum") = "123456"
218 mparams("comments") = "u_txnrequest"
219
220 Set myresp = uniterm_sendrequest(uniterm_conn, mparams)
221 If StrComp(myresp("code"), "AUTH", vbTextCompare) <> 0 Then
222     msg = "Transaction failed." & vbNewLine
223 Else
224     msg = "Transaction SUCCESSFUL!" & vbNewLine
225 End If
226
227 ' Print out all the response key/value pairs ...
228 Dim key
229 For Each key In myresp
230     msg = msg & " " & key & " = " & myresp(key) & vbNewLine
231 Next key
232 MsgBox (msg)
233
234 ' NOTE: No real reason to exit here ... we could just keep running
235 '       Step 3 all day long as long as you keep the uniterm_conn handle.
236 '       No reason to keep disconnecting and reconnecting, or
237 '       starting/stopping Uniterm.
238
239 ' Step4: Cleanup
240 uniterm_shutdown uniterm_conn
241
242 ' Connections will be automatically closed when the uniterm_conn initialized
243 ' class is cleaned up by the destructor/garbage collector
244 End Sub
245
246
247
```

D PCI Security and Implementation

The below details the various security and PCI requirements and how deployments may be impacted. Integrators and distributors should read this section prior to any production deployments.

UniTerm depends on an instance of Monetra v8.y.z being accessible. Monetra may run on customer-hosted equipment or be provided as a service or gateway via a third party.

TOPIC	DISCUSSION
Delete sensitive authentication data stored by previous payment application versions.	UniTerm has never stored any sensitive authentication data.
Delete any sensitive authentication data (pre-authorization) gathered as a result of troubleshooting the payment application.	UniTerm has never stored any sensitive authentication data, even for troubleshooting purposes.
Securely delete cardholder data after customer-defined retention period.	UniTerm never stores cardholder data.
Mask PAN when displayed so only personnel with a business need can see the full PAN.	UniTerm mandates the use of users with the <code>obscured</code> flag, therefore it is not possible that the full PAN can ever be returned.
Render PAN unreadable anywhere it is stored (including data on portable digital media, backup media, and in logs).	UniTerm never stores cardholder data, nor does it have its own logging facilities.
Protect keys used to secure cardholder data against disclosure and misuse.	UniTerm never stores cardholder data and therefore does not utilize keys.
Implement key-management processes and procedures for cryptographic keys used for encryption of cardholder data.	UniTerm never stores cardholder data and therefore does not utilize keys.
Implement secure key-management functions.	UniTerm never stores cardholder data and therefore does not utilize keys.
Provide a mechanism to render irretrievable cryptographic key material or cryptograms stored by the payment application.	UniTerm never stores cardholder data and therefore does not utilize keys.

Use unique user IDs and secure authentication for administrative access and access to cardholder data.	UniTerm does not provide or facilitate administrative access.
Use unique user IDs and secure authentication for access to PCs, servers, and databases with payment applications.	UniTerm does not provide or facilitate administrative or remote access. Use unique user names and secure authentication to access any PCs, servers, and databases with payment applications and/or cardholder data.
Implement automated audit trails.	UniTerm does not provide its own logging facilities, instead all requests are sent to Monetra which logs and maintains the audit trails on behalf of UniTerm.
Facilitate centralized logging.	Since UniTerm sends all requests and metadata to Monetra, Monetra is responsible for facilitating centralized logging.
Implement and communicate application versioning methodology.	Please see the Versioning section.
Securely implement wireless technology.	UniTerm is not designed to use or facilitate the use of wireless technologies.
Secure transmissions of cardholder data over wireless networks.	UniTerm is not designed to use or facilitate the use of wireless technologies.
Provide instructions for secure use of wireless technology.	Integrators should ensure they secure any wireless technologies in use in compliance with the requirements in PA-DSS Requirement 6.3
Use only necessary and secure services, protocols, components and dependent software and hardware, including those provided by third parties.	UniTerm communicates only via TLS using proprietary protocols to a Monetra server (hosted or customer-owned) across an intranet or the Internet. A customer may choose to deploy UniTerm with one or more hardware card entry devices or terminals directly attached to the System via USB, Serial, BlueTooth, or Ethernet Integrators must ensure only necessary and secure protocols, services, etc., are used on the system.
Store cardholder data only on servers not connected to the Internet	UniTerm never stores cardholder data.
Implement two-factor authentication for all remote access to payment application that originates from outside the customer environment.	UniTerm never stores cardholder data, nor does it provide access to cardholder data. Integrators must ensure that all remote access originating from outside the customer's network to a payment application (Monetra) must use two-factor authentication.
Securely deliver remote payment application updates.	Integrators must securely deliver updates to UniTerm in compliance with the Deployment section. Deployments must

	be done in accordance with the PCI PA-DSS requirement 10.3.
Securely implement remote-access software.	Main Street Softworks will never reach out to a remote customer network. If an Integrator chooses to support remote access for management they must do so in compliance with PA-DSS Requirement 10.3.2.
Secure transmissions of cardholder data over public networks.	<p>UniTerm communicates only via TLS to Monetra using proprietary protocols.</p> <p>UniTerm communicates using the PCI DSS required protocols and cipher suites automatically (TLSv1.2 TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384). No configuration is required of UniTerm to comply, nor is it possible to reconfigure UniTerm to a less secure protocol or cipher suite. Future versions may implement new protocols and cipher suites as they become available.</p>
Encrypt cardholder data sent over end-user messaging technologies.	UniTerm does not facilitate or support the use of end-user messaging technologies.
Encrypt non-console administrative access.	UniTerm does not provide or facilitate administrative access.